

Configuration WWI Pack:

“Airplane”	Servo 1	Servo 2	Servo 3	Servo 4
One:	Fokker D VII	Gun 1 vickers	“clear”	“clear prop”
Two:	Real Gnome	9Cyl	3Cyl	Burst
Three:	Le Rhone	Gun 1	“clear”	“contact”
Four:	Gnome	Gun 1	“clear prop”	“contact”
Five:	Tiger Moth	Gun 1	“clear”	“contact”
Six:	Stearman	Gun 1	“clear”	“contact”