

NO.	Part name (number req'd)	NO.	Part name (number req'd)	NO.	Part name (number req'd)
N I	Wing nut M6	N 22	Key 5×5×14 (2)	N 43	Rotor
N 2	Lock washer	N 23	Sealed ball bearing #6202(2)	N44	Cushion plate
N3	Lever spring	N 24	Clutch shaft	N45	P • screw M5×0.8 (3)
N 4	Spring adjustment rod	N 25	Movable bearing pipe	N46	2 thickness washer (3)
N 5	Lever	N 26	Front cover	N47	Stator
N 8	Lever pin 10	N27A	Brake shoe	N 48	Motor housing
N7	E + shape lock ring #8 (2)	N28A	Clutch wheel	N 49	Belt adjusting screw M10
N 8	Smooth ball joint	N29A	Clutch Lining	N 50	Rating plate
N 9	Adjusting pivot M10	N 30	Spring washer 6 (4)	N 51	Capacitor
N10	Fastening screw M6	N 31	Screw M8×1 (4)	N 52	Capacitor saddle
NII	Fixed nut M10	N32A	Washer with internal tooth	N 53	Spring washer 5 (2)
N12	Half belt cover	N 33	Lock nut M14	N 54	P · screw M5×0.8 (2)
N13	Washer	N 34	Washer with Internal tooth	N 55	End cover
N14	Plane washer 5 (2)	N 35	Flywheel	N 56	Plane washer 5 (2)
N15	P + screw M5×0.8 (2)	N 36	P • screw \$15 × 0. 8 (3)	N.57	P · screw M5×0.8 (2)
N18	P • screw M5×0.8 (2)	N 37	Spring washer 5 (3)	N 58	E · shape lock ring #9 (2)
N17	Plane washer 5 (2)	N 38	Intermediate bracket	N 59	Connection pin 10
N18	Full belt cover	N 39	Preload spring	N 60	Slide base
N19	Lock nut M12	N40	Key 5×5×19	N 61	Mounting screw (3)
N20	Spring washer 12m	N41	Sealed ball bearing # 6203 (2)	N 62	Rubber cushlon (3)
N21	Pulley	N 42	Rotor shaft		