成品尺寸:64*175mm　　60g双胶纸　　5折6页风琴页

175mm

64mm

封面

BLOW　**44-590#**

Electric salt and pepper grinder

User manual

BEFORE USING FOR THE FIRST TIME

To ensure safety and maintain the high quality of the product, we recommend that you read and follow the instructions carefully.
- Do not immerse the appliance in water or any other liquid to avoid harm to human or the product.
- Use for pepper and salt only, please do not use for others purposes.
- Do not force the grinder to tighten or twist it or attempt to speed up the mechanism.
- Keep body parts (e.g. finger) and utensils away from the grinding head to avoid damage. Please hold the grinder tightly when using.
- Keep this product away from childern.
- Do not dismantle the product by yourself, or otherwise warranty will be invalid.
- Please take out the batteries if do not use for a long time.
- Kepp away from flammable, explosive gas, high temperature.

PRODUCT DESCRIPTION





1. Battery cover
2. On/Off Button
3. Container
4. Container Cover
5. Storage Base
6. Light
7. Adjuster

HOW TO INSTALL THE BATTERIES

- Pull back the buckle of the battery cover with fingers to lift up the battery cover.



- Insert 4 AAA batteries according to the positive and negative poles. Close the battery cover.



HOW TO USE

- Hold the grinder tightly , and switch the container cover to open according to the indication icons. Put pepper or salt into the container, then restore and lock the cover.



- rotate the adjuster to adjust the coarseness according to personal preferences.

- press and hold the on/off button to grind, release the button to stop.

- This product adopts an adjustment knob. The adjuster could be rotated from multiple circles between the finest and the coarsest grinding.
- Adjust to Fine: Rotate the adjuster from "COARSE" to "FINE". Continue to rotate for a few circles until the desired fineness achived.
- Adjust to Coarse: Rotate the adjuster from "FINE" to "COARSE",. If the adjuster loosens, it could be caused by some pepper grains stuck in the burr. Start the product to rotate for 1 second, then the burr will beloosened and you can continue to adjust. This is a normal situation of ceramic burr and will not affect it's normal use.
*If the adjuster falls off, please assemble the components in the orders shown below.



* With seasoning in the container, please do not turn the grinder upside down for a long time in case grains of seasoning might get into the battery compartment and cause battery corrosion.

TROUBLESHOOTING

If the grinder does not work or stops while grinding:
- Please check that the batteries are alkaline batteries.
- Please check that the batteries are installed correctly.
- Please confirm there is sufficient battery power.
- Please adjust the adjuster with counter-clockwise direction.
If the above operations are correct and the grinder still works abnormally, please contact the vendor for mintanace service.

封底

Declaration of Conformity

Producer: PROLECH SP. Z O.O., STARY PUZNÓW 58 B, 08-400 GARWOLIN, POLSKA

Product name: Electric salt and pepper grinder
Brand: BLOW
Item number: 44-590#

The company Prolech Sp. z o.o., Stary Puznów 58B, 08-400 Garwolin, Poland hereby declares that the Electric salt and pepper grinder product with the code 44-590# complies with the directives: 2014/30/EU, 2011/65/EU, 2015/863/EU, 2017/2102.
The full text of the EU declaration of conformity is available at the website www.prolech.com.pl

Manufactured in the People's Republic of China forProlech Sp. z o.o. Stary Puznów 58B, 08-400 Garwolin, Poland

Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

BLOW　**44-590#**

Młynki elektryczne do pieprzu i soli

Instrukcja obsługi

PRZED PIERWSZYM UŻYCIEM

Aby zapewnić bezpieczeństwo i utrzymać wysoką jakość produktu, zalecamy uważne przeczytanie instrukcji i przestrzeganie jej.- Nie zanurzaj urządzenia w wodzie ani żadnym innym płynie, aby uniknąć obrażeń u ludzi lub produktu.- Używaj wyłącznie do pieprzu i soli, nie używaj go do innych celów.- Nie dokręcaj młynka na siłę ani nie przekręcaj go, ani nie próbuj przyspieszać mechanizmu.- Trzymaj części ciała (np. palce) i przybory kuchenne z dala od głowicy mielącej, aby uniknąć uszkodzeń. Podczas używania trzymaj młynek mocno.- Trzymaj ten produkt z dala od dzieci.- Nie rozmontowuj produktu samodzielnie, w przeciwnym razie gwarancja będzie nieważna.- Wyjmij baterie, jeśli nie używasz go przez dłuższy czas.- Trzymaj z dala od łatwopalnych, wybuchowych gazów i wysokiej temperatury.

OPIS PRODUKTU





1. Pokrywa baterii
2. Przycisk włączania/wyłączania
3. Pojemnik
4. Pokrywa pojemnika
5. Podstawa do przechowywania
6. Światło
7. Regulator

JAK ZAINSTALOWAĆ BATERIE

- Odciągnij palcami zatrzask pokrywy baterii, aby podnieść pokrywę baterii.



- Włóż 4 baterie AAA zgodnie z biegunami dodatnimi i ujemnymi.
- Zamknij pokrywę baterii.



JAK UŻYWAĆ

- Trzymaj mocno młynek i otwórz pokrywę pojemnika zgodnie z ikonami wskazującymi. Wsyp pieprz lub sól do pojemnika, a następnie zamknij i zablokuj pokrywę.



- obracaj regulatorem, aby dostosować grubość do osobistych preferencji.

- naciśnij i przytrzymaj przycisk on/off, aby zmielić, zwolnij przycisk, aby zatrzymać.

- Ten produkt posiada pokrętło regulacyjne. Regulator można obracać w zakresie od najdrobniejszego do najgrubszego mielenia.- Dostosuj do drobnego: Obróć regulator z „GRUBO" na „DROBNO". Kontynuuj obrót przez kilka obrotów, aż do uzyskania pożądanego stopnia zmielenia.- Dostosuj do grubego: Obróć regulator z „DROBNO" na „GRUBO". Jeśli regulator się poluzuje, może to być spowodowane przez ziarna pieprzu utknięte w żarnie. Uruchom produkt, aby obracał się przez 1 sekundę, a następnie żarno się poluzuje i możesz kontynuować regulację. Jest to normalna sytuacja w przypadku żarna ceramicznego i nie będzie miała wpływu na jego normalne użytkowanie.*Jeśli regulator odpadnie, zmontuj elementy w kolejności pokazanej poniżej.

* Jeśli w pojemniku znajduje się przyprawa, nie należy na dłuższy czas odwracać młynka do góry nogami, ponieważ ziarenka przypraw mogą dostać się do komory baterii i spowodować jej korozję.

ROZWIĄZYWANIE PROBLEMÓW

Jeśli młynek nie działa lub zatrzymuje się podczas mielenia:
- Sprawdź, czy baterie są bateriami alkalicznymi.
- Sprawdź, czy baterie są prawidłowo zainstalowane.
- Potwierdź, że bateria ma wystarczającą moc.
- Wyreguluj regulator w kierunku przeciwnym do ruchu wskazówek zegara.Jeśli powyższe czynności są prawidłowe, a młynek nadal działa nieprawidłowo, skontaktuj się ze sprzedawcą w celu uzyskania serwisu.

Deklaracja zgodności

Producent: PROLECH SP. Z O.O., STARY PUZNÓW 58 B, 08-400 GARWOLIN, POLSKA

Nazwa wyrobu: Młynki elektryczne do pieprzu i soli
Marka: BLOW
Kod produktu: 44-590#

Firma Prolech Sp. z o.o., Stary Puznów 58B, 08-400 Garwolin, Polska niniejszym oświadcza, że produkt Młynki elektryczne do pieprzu i soli o kodzie 44-590# jest zgodny z dyrektywami: 2014/30/EU, 2011/65/EU, 2015/863/EU, 2017/2102.
Pełny tekst deklaracji zgodności UE jest dostępny pod adresem strony internetowej www.prolech.com.pl

Wyprodukowano w Ch.R.L. dla
Prolech Sp. z o.o. Stary Puznów 58B, 08-400 Garwolin, Polska

Prawidłowe utylizacja tego produktu

Oznakowanie to wskazuje, że produkt ten nie powinien być wyrzucany wraz z innymi odpadami z gospodarstw domowych w całej UE. Aby zapobiec ewentualnym szkodom dla środowiska lub zdrowia ludzkiego wynikającym z niekontrolowanego usuwania odpadów, należy poddać je odpowiedzialnemu recyklingowi w celu promowania zrównoważonego ponownego wykorzystania zasobów materiałowych. Aby zwrócić używane urządzenie, skorzystaj z systemów zwrotu i odbioru lub skontaktuj się ze sprzedawcą, u którego produkt został zakupiony.