BUY ON
www.cablematic.com

OPERATION FOR DIGITAL TIMR

一、SEE THE PICTURE AS FOLLOW



Fig1 When counting down, the buzzer will make three sounds for last one minute. In the last five second, the buzzer will make a sound again.	
Fig2 With the description to tell you how to adjust time	
Fig3 Time accelerate 10%	
Fig4 COIN INSERT and PLAY TIMES adjust. Use “ DOWN ” is 1:1,and “ UP ” is 2:1	
Fig5 Reset	
Fig6 The electric wire can adjust both alternating current and direct current	AC 9V，DC 12V。
Fig7 Connect with joystick	
Fig8 Coin acceptor	

二、ADJUST TIME SW-DIP

SW-DIP							
1	2	3	4	5	6	TIME MIN	MULTPLE
				OFF	OFF		1
				ON	OFF		2
				OFF	ON		5
				ON	ON		10
OFF	OFF	OFF	OFF			1	
ON	OFF	OFF	OFF			2	
OFF	ON	OFF	OFF			3	
ON	ON	OFF	OFF			4	
OFF	OFF	ON	OFF			5	
ON	OFF	ON	OFF			6	
OFF	ON	ON	OFF			7	
ON	ON	ON	OFF			8	
OFF	OFF	OFF	ON			9	
ON	OFF	OFF	ON			10	
OFF	ON	OFF	ON			11	
ON	ON	OFF	ON			12	
OFF	OFF	ON	ON			13	
ON	OFF	ON	ON			14	
OFF	ON	ON	ON			15	
ON	ON	ON	ON			16	