# Jeep Renegade Light Bar Mount

Installation instructions by MADNESS Autoworks

**Tools needed:**

- Flathead screwdriver or small pry tool
- 5mm allen wrench or allen bit
- Towels to protect paint *(optional)*
- Cardboard or towels to wedge below roof rails and bar *(optional)*

On top of the factory roof rails, look for the removable caps covering a small 5mm allen bolt underneath. The caps will simply pry off with a flathead screwdriver, pick, or knife.

At minimum, you'll need to undo the front bolts completely. Loosening the bolts further back from the front helps make the job easier, in that you can raise the roof rails a little higher for more clearance on the install.





Complete removal of the rails is not needed, though it can help to wedge something beneath the rails to hold them in an elevated position temporarily while positioning the light bar.

At this time, you may wish to lay a towel down at the front and inside areas of the rails to protect your roof paint while positioning the light bar. You may also wish to wedge something beneath the light bar as well to keep it from leaning forward.

On the underside of the roof rails, you will notice these square-shaped protrusions that correspond with the cutouts at the feet of the light bar mount. Please use the image below as reference.




Position the light bar such that the cutouts in the light bar are matched with the protrusions underside the rail. This will be done by feel, and when properly positioned, the light bar will be held in place by the protrusions.

Once in position, you can simply bolt the rails back down to complete installation.

Please let us know if you have any questions.

**MADNESS Autoworks**
**CA:** 562-981-6800
**TX:** 512-982-9393
**Email:** *info@madnessautoworks.com*