Not for Resale

HTX 500

1/8" Plywood

Hollow Out

Crease after spars in place

Cut Line
50% Cut Line
Crease Line

10 20 30 40 50 60 70 80 90 100mm
1 2 3 4 5 6 inches

Morane-Saulnier M.S.406
Design By : Vincent Unrau
RCFBAirCraft
Email : unrauv@gmail.com

Cut Line
50% Cut Line
Crease Line

Remove after wing placement

B-1 B-2 B-2a B-2b B-3 B-4 B-5 B-6 B-7 B-8 B-9 B-10 B-11

Turnigy NTM 28x30 Power Pod

Bottom Sheet

1/16" Hobby Plywood Joiner
foam Joiner
foam Joiner

Wing Construction Prop

Canopy
Canopy

1/8" Plywood Spar
1/8" Plywood Spar
Foam Spar
Foam Spar
Foam Spar
Foam Spar
Foam Spar
Foam Spar

1/8" plywood Motor Mount
1/16" Balsa Top
28 x 30 Power Pod
Air Vent
Air Vent

Build Helpers
Build Helpers
Build Helpers