

Instruction Manual

ENGLISH

RS Pro LED Bench Magnifier, 3 dioptre, 5 dioptre, Table Clamp Mount, 8W



Description	Long reach LED Magnifier Lamp, with 5D lens
Voltages Available	220V & 240 V , 50 Hz
Magnifier	125 mm (5") diameter lens - Removable
Magnification	Fitted 3 dioptre lens;1.75x mag. & includes 5 dioptre lens;2.25x mag.
Sun Protector Cap	Yes
Light type	56 piece SMD LED, 9W
Cable length	1.6m
Table clamp/base	Table Clamp

HOW TO USE

1. Securely fasten the table clamp included to a solid horizontal surface with thicknesses between 12.5 - 62.5mm (0.5 - 2.5"). Ideal for household tables, study desks and work benches
2. Insert the stem of the lamp into the clamp hole
3. Insert the 220v or 240v plug into a conveniently located electrical socket
4. Switch the lamp on by using the on/off switch located on top of the head. The lamp is now ready to use.
5. Adjust your lamp head position to suit your need and tighten the locking nuts as required

REMOVING THE LENS

You may wish to remove the lens for cleaning purposes or to replace with the 5 dioptre / 2.25x magnification lens

1. Please switch the lamp off and remove the plug from the mains socket
2. Turn the plastic lens retainer anti-clockwise and carefully remove the lens
3. Replace lens and turn the plastic lens retainer clockwise to fix securely into position

IMPORTANT! - SAFETY INSTRUCTIONS

WARNING: When using electrical products, important safety precautions must be adhered to in order to reduce the risk of fire, electric shock and personal injury.

PLEASE READ THE FOLLOWING CAREFULLY:

1. Indoor use only: a. Room temperature from -20 to +40 degrees centigrade b. Humidity: Less than or equal to 95%
2. Do not expose the lamp to:
 - a. High temperatures
 - b. Water, steam or damp conditions
 - c. Corrosive, flammable liquids, or gaseous / explosive atmospheres
3. Do not abuse the cord. Never carry the lamp by the cord or pull the cord to disconnect the lamp. Keep the cord away from heat, oil or sharp objects
4. Disconnect your lamp when not in use.
5. Never attempt to disassemble or repair the lamp, unless you are a qualified electrician
6. **CAUTION:** Never leave the magnifier lens unattended in direct sunlight or where light can shine through it - This constitutes a fire hazard!

CE Declaration of Conformity

We declare that this product complies with the Electromagnetic Compatibility Directive and the Low Voltage Directive

RS COMPONENTS UK
PO BOX 99 CORBY
NORTHANTS,
NN17 9RS United Kingdom

Tel: +44 (0)8457 201201
Fax: +44 (0)845 8509911
WEB: rswww.com RoHS Compliant

