

USING FUMIGUARD BAGS

Fumiguard bags are made from a special nylon based film-like material that is highly resistant to the passage of Zythor gas. In order to adequately protect the contents placed inside the bag, the bags must be packed and sealed according to the following directions. Bags can be placed inside refrigerators and freezers.

Only use Fumiguard bags to protect items against exposure to Zythor. Regular garbage-type plastic bags do not provide protection.

Keep Fumiguard bags out of the reach of children.



Step Three - Sealing the Bag

Double the twisted neck of the bag over on itself and secure it with a twist tie, tape, string or rubber band.



Step One - Packing a Bag

Place items to be protected inside a Fumiguard bag. Fill the bag only half to two-thirds full to allow it to be closed properly.



Step Four - Double Bagging

Place the sealed bag inside of a second bag. Secure this second bag according to steps two and three.



Step Two - Closing the Bag

Twist the top of the bag tightly into a long neck.



Step Five - Testing the Seal

Test the seal of the outer bag by pushing gently against its sides and listening for an air leak.

Ensystem II, Inc. Revised 03/06

Thor and Zythor are trademarks of Ensystem II, Inc.