



Quality Acrylic Bath

ICS Quality Acrylic Baths

www.ICSqualitybaths.com

Cast Iron Claw Feet attach with slide in bolts and are marked with letters for foot Placement. Match letters on tub to letters on feet. Sometimes feet have more than one letter so it can be used in either position. Shims may be needed for a tight fit of foot to tub. Insert shims as needed under the foot against tub mount.



Match feet to letters on tub bottom.

Use Shims only if needed, under foot on mounting bracket.

Do not ship or transport tub on feet , installed Feet will damage tub finish.

www.ICSqualitybaths.com