

## **R710**

# Digital counter module



#### Summary

The R710 digital counter module is a microprocessor-controlled, communicative 4 binary input counter module. The module uses Modbus RTU on a RS485 bus for communication, and can be easily integrated in a variety of supervision and control systems.

#### **Application**

 HVAC and industrial control systems – pulse counting from meters, load shedding etc.

#### **Function**

The M710 module has four binary inputs which provide 12 V for external contact or open collector signal. The COM terminals are interconnected inside of the module and are common for all inputs.

The module communicates by means of a RS485 data bus. The Modbus RTU communication protocol ensures smooth and easy integration in a number of control and data acquisition systems.

The counters provide 4 byte values (longint). The module offers advanced functions for load shedding algorithm (E-Max): use CNT1 for energy pulses, CNT2 for 15 min. sync pulses. Additional variables are:

- pulses in current 15 min. period (resets with each sync pulse)
- pulses in last 15 min. period (copy of pulses in current period on period end)
- seconds in current 15 min. period (resets with each sync pulse).

Removable connectors are used for incoming and outgoing data line so that mounting is fast and easy. The module is mounted on a DIN rail.

The communication circuits are protected against overvoltage and galvanically separated from the rest of the module. If the module is terminating the communication bus, i.e. it is the last in line, a terminating 120  $\Omega$  resistor may be

switched on by short-circuiting of the BUS END jumpers. Two LEDs located inside of the housing enable fast diagnostics – power up and communication. To set the module to factory defaults (9600 bps, address 1), set the INIT switch to ON and remove power for 2...3 secs.

See domat - Technical application notes for connection examples.

All the settings are backed up in a EEPROM chip. The module is equipped with a watchdog circuit and the communication part is galvanically separated.

#### **Technical data**

Power 24 V AC/DC ±20 %

Consumption 0.8 W

Communication Modbus RTU RS485, 1200...115200 bit/s

Galvanic isolation 1 kV

Max. bus length 1200 m

Max. amount of modules on the bus 256

Number of inputs 4 × dry contact or open collector, 5 mA

Max. input frequency50 HzMin. duty time10 msMax. distance to contact10 m

SW ModComTool 4.2.4.6 or higher for parameters setting,

Merbon IDE, SoftPLC IDE – predefined Modbus devices

Housing Polycarbonate box (certification UL94V0)

elbox 4

Terminals screw terminals M3 (bus, power), M2 (Al inputs)

Dimensions  $70.4 \times 98.7 \times 61.5 \text{ mm}$ 

Protection degree IP20 (EN 60529)

Recommended wire 0.14...1.5 mm<sup>2</sup>

Ambient temperature external conditions: -5...45 °C; 5...95 % relative humidity;

non-condensing gases and chemically non-aggressive conditions (according to EN 60721-3-3 climatic class 3K5)

storage: -5...45 °C; 5...95 % relative humidity; non-condensing gases and chemically non-aggressive conditions

(according to EN 60721-3-1 climatic class 1K3)


Standards conformity EMC EN 61000-6-2 ed.3:2005, EN 61000-6-4 ed.2:2006 +

A1:2010 (industrial environment)

Electrical safety EN 60950-1 ed.2:2006 + A11:2009 + A12:2011 + A1:2010 + A2:2014 + Opr.1:2012 + Z1:2016

Hazardous substances reduction EN 50581:2012

#### **Terminals**



#### **Terminals and connectors**

RS485 K+ port COM1 - serial link RS485, positive RS485 K- port COM1 - serial link RS485, negative

G power supplyG0 go power supply

TE optional connection for shielding, technical ground

**COM** common terminals for inputs Al1...Al8

CNT1 ... CNT4 inputs 1...8

**LED** indication

TxD red LED - RS485 transmitting data at COM1

(flashing: transmitting data; OFF: no data traffic) green LED – power supply (ON: power OK; OFF: no power applied, weak or damaged power supply, ...)

**DIP** switches

**PWR** 

ADR AUTO – if all switches are OFF, the address is used

according to Modbus register 4 LSB

USER – address is set by DIP switches configuration

INIT - if are all switches ON at power-up, configuration parameters are set to defaults DIP 8 = bit 0; switches increase their bit weight


from right to left, see below

BUS END Switch for bus RS485 termination (located at the


RS485 connector); ON = bus end; the first and last

devices on bus should have bus end ON

## **Connection**



# **Dimensions**




Dimensions are in mm.

#### Installation

The R710 module is fixed on standard DIN rail (by snapping).


When removing the module from the DIN rail proceed as follows: Place a screwdriver in the plastic slot which is in the middle of bottom part of the module (1). Then push the screwdriver upwards (2). After that, the module can be removed by tilting it upwards (3).



## **Addressing**

The Modbus address can be set as follows:

- hardwarewise: using DIP switches. The switches increase their bit weight from right to left, see image with example where address of 21 is set by activation of switches 4, 6, and 8 with bit weight of 16, 4, and 1 respectively. Valid settable range is 1 to 254. Address 0 (all switches OFF) means that the address is set as entered in the Modbus table. Address 255 (all switches ON) brings the module to INIT mode, where Modbus address is 1 and communication parameters are set to N, 8, 1, see image below. All changes apply after the module is switched off and on again.



- **softwarewise** using the ModComTool software, available for free at **www.domat-int.com/en/**. The default address (factory setting) is 1, default communication parameters are 9600, 8, N, 1. Parity and stopbits can be set in Modbus register 1005 LSB.

The software address is only active if the hardware addressing switch is set to 0

All changes apply after the module is switched off and on again.

## Safety note

The device is designed for monitoring and control of heating, ventilation, and air conditioning systems. It must not be used for protection of persons against health risks or death, as a safety element, or in applications where its failure could lead to physical or property damage or environmental damage. All risks related to device operation must be considered together with design, installation, and operation of the entire control system which the device is part of.

**Changes in** 01/2020 – First datasheet version.

versions 08/2021 – Stylistic adjustments, change of logo.