Mersive Solstice: How to Connect

University of **Strathclyde** Glasgow

1: To wirelessly connect to the Mersive Sosltice Pod and display content from your device on to the screen, you will need to first be connected to the 'eduroam' wifi network. The instructions of how to connect are displayed on the screen.

2: You will need to have the Mersive Solstice App installed on your device. If you get your University Laptop from Professional Services you can download and install the App (Mersive Solstice Client (x64))and the required Mersive Solstice Conference Drivers V 1.3.2 If you get your laptop from your faculty IT Team you may need to get them to install it on your laptop. If you are using your own laptop you can download it from www.mersive.com. It can also be installed on phones and tablets via the relevant App store.


3: When the app is installed you need to make sure that the following ip address 130.159.16.214 is in the Solstice Discovery Service Address tab in Settings on the App.This will unlock the App to be used with any Mersive Solstice Pod on campus.

4: To connect your device to the Mersive Solstice Pod, all you need to do is put the 4 digit code displayed on the Mersive SolsticePod display into the Search Bar on the Solstice App, and press Enter. You will now be connected to the Mersive Solstice Pod in the room. This code changes regularly for security.

5: You share content to the display using the options on the 'Share' Panel. Apple devices may need to open the control centre and select the 'Screen Mirroring' option. Content can be arranged and controled in the 'Layout' tab, you can drag and drop shared screens and content from the centre main display to the panel on the left to change the onscreen display quickly and easily.

4: For more information regarding the Solstice Pod, please scan the QR code.

To report a fault,
Tel: ext. 5999 (or 0141 548 5999)
Email: LS-roomsupport@strath.ac.uk