



INSTRUCTION MANUAL






- 1.Power/Reset password
- 2.Reset
- 3.TF card slot
- 4.Power Port
- 5.Rear Camera interface(optional)

Note: 4K UHD video requires high configuration and player of mobilephone or computer. If the player is stuck, please change the hardware device and player that support 4K,decoding to play.

Accessories:
User manual, car charger(built-in 12V to 5V adapter).
1.Power/Reset password Short press to turn on/off the camera. Press 5 consecutive times,the machine forcibly restores the initial WIFI password 12345678
2.Reset Short press to the machine Reset
3.Tf card slot Insert a Class 10 microSD card (8GB--128GB)
4.Power Port Connect the dash cam with the car charg while driving.
5.Rear Camera interface(optional) This machine is a single camera and this interface cannot be used

APP connection and operation guidance

This product connects tachograph WIFI by APP in Android and iPhone platform.
Step 1: APP Download and Installation




GoLook

Both Android and iPhone phones can scan the QR code above to directly download and install "GoLook"APP, or download "GoLook"from different application market. The APP are available for both android and iphone.


Step 2: Open the app when the phone is connected to the machine's WIFI

Power on the machine firstly, after the machine gets ready, turn on the mobile phone WIFI settings, look for the WIFI named HiDvr_ and connect.WIFI password is 12345678.





WIFI Name: HiDvr_
WIFI Password:12345678

Note:
When an Android phone is connected to recorder WIFI, it prompts "This Wi-Fi network has no Internet access. Connect anyway." Be sure to choose similar tips such as "Connect anyway," Otherwise, the phone won't access the APP or black screen or flash back after accessing.



Step 3: Open "GoLook" when connected with tachograph WIFI Application

After opening "GoLook" APP, you can access camera view with one tapping of the CONNECT icon in the middle.
Step 4: Video Playback and Settings




1. Video playback button, play back recorded video with one click
- 2.Camera Button
3. Settings Button, set each parameter of tachograph with one tape.(The machine parameters have been adjusted to the best state before leaving the factory. If there is no special need, users are not recommended to change the parameters by themselves.)


How to save videos to mobile phone :

According to Consumer Privacy Protection Agreement, videos stored in mobile APP can not be directly saved to phone album, which however can be realized by following steps regarding IOS & Android mobile phone.

For IOS phone user, please do as below:



- 1.Check files in the Replay; choose the video you need then click Download;
- 2.After video downloads successfully, go to Downloaded folder on the lower right corner; choose the Video you need then save to phone Album.





For Amdroid phone user, please do as below:

Check files in the Replay; click the video you need to download and play it; then click Downloaded on the right upper corner to download it. After video downloads successfully, you can view this video in your phone's photo album.



Parameters

Recording Angle: Wide-angle 170°
Video Mode: Loop recording, auto overwriting
Microphone: Support (enable by default)
Memory Card: 8~128G, above CLASS 10
Battery: No Battery, safer, no explosion
Language: Multiple Languages (English by default)
G-Sensor: Triaxial 3D acceleration sensor (enable by default)
Seamless Record: Every footage could be seamless linkage.
Time Overprint: Time accurately superimposed on the video
Video Playback: The desired footage can be selected to play back
Temperature Range: -35℃~75℃

Frequently asked questions:

1. After connecting to the recorder's WIFI, black screen or flash back happens after accessing the APP, or can not access the APP?
Solution:
(1) When an Android phone connects to the recorder's WIFI, the phone alerts "This WLAN network has no Internet access. Connect anyway," you haven't chosen "Connect anyway" but ignore it directly, or choose not to use. In this case, please enter your phone settings and choose "forget your WIFI password" and re-enter it. Restart the phone and choose "Connect anyway" and you'll be able to fix it.
(2) If the problem is still existing after (1), it is possible that APP's permission is limited by the phone. In this situation uninstall the APP and re-download it, turn on all the permissions the APP needs. Problems above can basically be resolved by forgetting the WIFI password and re-enter, uninstall APP and re-download. It's important to make sure connecting to the recorder's WIFI in your phone's settings before accessing the APP. Iphone users please check if the permissions required by APP are turned down, if it is not working, please uninstall APP and redownload, make sure the permissions the APP needs are turned on and the problem can be resolved. Problems above can basically be resolved by forgetting the WIFI password and re-enter, uninstall APP and re-download. It's important to make sure connecting to the recorder's WIFI in your phone's settings before accessing the APP.
2. The recorder does not read the memory card, or the video sometimes records sometimes not?
Solution:
Check that the memory card used is a regular brand of high-speed card,ultra HD recorder requires an extremely high level in speed and stability of the memory card. In this case, replacing the memory card and problem can be resolved. Buy genuine high-speed cards from well-known brands such as SanDisk, Toshiba, Kingston through regular channels.

3.Recorder flash screen or abnormal switch machine

Solution:
Please check if the power connector is plugged in properly. Also detecting whether the voltage and current of the power supply are sufficient. This can occur when the voltage is unstable or the current is too small. Ultra HD recorders require 5V 1.5A power.