

DYLINK

EX1010A

EX1020A

EX1030A

VGA Video & Audio Extender
User Manual

Introduction

Thank you for purchasing our VGA Video & Audio extender. The extender transmits VGA video and audio up to *300* meters away from a computer using CAT5/5e/6 cable. Each extender consists of a local unit that connects to a computer and also supplies VGA video and audio to the local and a remote unit. Split the video signal and audio signal into 2 monitors and speakers.

Package includes

- Local unit
- Remote unit
- 2 Power adapters
- 1x1.5m VGA cable
- 1x3.5mm Stereo audio cable
- 1 User manual
- 1 crossed screwdriver

Features

- Split one VGA video signal and one audio signal from one source into 2 monitors and speakers and extend it up to *100* meters (EX1010A) or *200* meters (EX1020A) or *300* meters (EX1030A)
- Supports local monitor and speaker
- Uses standard Category 5/5e/6 straight-wired, twisted-pair, network patch cable for economical and reliable data transmission
- No software required

- Provides crystal clear picture quality
- Supports maximum video resolution - *1280x1024* at *300* meters away.
- Supports VGA, SVGA, and Multisync monitors
- Built-in surge protection

Specifications

Maximum Resolution	1280 X 1024
Max. Distance	EX1010A : 100 meters EX1020A : 200 meters EX1030A : 300 meters
Audio Frequency Response	20 Hz to 20 kHz, +/- 1 dB
Audio Input Impedance	10k Ohms
Line Level Output	Supports multimedia speakers
Video Quality Adjustment	Auto or Manual
Connect with PC	One High Density DB75 Male; One 3.5mm female stereo audio jack
Local Video and Audio	One High Density DB75 Female; One 3.5mm female stereo audio jack
Connect with User	Two High Density DB75 Female; Two 3.5mm female stereo audio jack
Subunit Connector	RJ45(connect local unit and remote unit)
Cable Type	Category 5/5e/6 UTP
Power Adapter	2 X DC 9V/1A
LEDs	Local unit : One for power, one for Video, one for Audio Remote unit : One for power, one for Video, one for Audio
Dimensions	108 X 94 X 26 mm

INSTALLATION

Installing the Local unit

- (1) Connect a female-to-male HD-15 VGA cable to the VGA Out port on the local computer. Connect the opposite end to the male 15HD port on the Local unit.
- (2) Connect a male-to-male headphone audio cable to the Speaker Out port on the local computer. Connect the opposite end to the audio in port on the Local unit.
- (3) If you wish to use local displays and speakers, connect them to the female 15HD port and the Speaker port on the Local unit.
- (4) Connect the Ethernet cable connection for Remote Unit to the RJ-45 connector labeled with REMOTE I/O on the Local unit. The cable such as CAT5 , CAT5E , CAT6 can be used, both terminal of the cable should be made according to EIA/TIA568B standard.
- (5) Connect the power adapter into an appropriate power source and plug the opposite end into the power connector on the Local unit. The POWER LED will light.

Installing the Remote unit

- (1) Connect the data cable from the display(s) to the opposite side of the Remote Unit, marked with monitor. You may choose to have either one or two displays at the remote location connected to the Remote Unit.
- (2) Connect one or two sets of speakers to the speaker ports marked with speaker on the Remote unit.
- (3) Connect the Remote Unit to the Ethernet cable connection from the Local unit, marked with REMOTE I/O. The cable such as CAT5 , CAT5E , CAT6 can be used, both terminal of the cable should be made according to EIA/TIA568B standard.
- (4) Connect the power adapter into an appropriate power source and plug the opposite end into the power connector on the Remote unit. The POWER LED will light.

Display & Adjustment

You should adjust corresponding parameters in order to get the best image effect according to the difference of usage distance.

Under the condition of image being shown on display, you can adjust four adjustable turn knob on Remote unit by the screwdriver attached, and adjust signal compensation (marked with GAIN) and the red one (labeled with R), green one (labeled with G) and blue one (labeled with B) respectively, which makes the effect to the best status.

Troubleshooting

Each and every piece of every product produced by us is 100% tested to exacting specifications. We make every effort to insure trouble-free installation and operation of our products. If problems are experienced while installing this product, please look over the troubleshooting chart below to see if perhaps we can answer any questions that arise. If the answer is not found in the chart, please contact us for help.

Problem	Solution
No video on monitor	<p>(1) Check the power adapters. Make sure they are connected to the Remote unit and the Local unit.</p> <p>(2) Check all video cable connections</p> <p>(3) Check UTP cable, make sure it is EIA/TIA568B type.</p>
Video signal is foggy or un-clear on the screen	<p>(1) Check all connections. Make sure all cables are fully seated.</p> <p>(2) Check cable connections. Make sure they are snapped-in properly and completely.</p> <p>(3) You should adjust corresponding parameters according to the difference of usage distance in order to get the best image effect</p>
Monitor sometimes loses sync, causing it to go blank for a second or two	<p>(1) Electrical power system is very noisy, particularly the ground.</p> <p>(2) Make sure the interconnection cable is not near any power lines.</p>