
















ASSEMBLY INSTRUCTIONS



A.  5PCS	F.  1PC	K.  4PCS
B.  1PC	G.  1PC	L.  4PCS
C.  1PC	H.  1PC	M.  1PC
D.  1PC	I.  4PCS	N.  4PCS
E.  1PC	J.  4PCS	

Model: ALE-TS4159W

Manufactured for/ Hecho para/ Fabriqué pour Alera®/ Essendant Co.

1 Parkway North, Suite 100, Deerfield, IL 60015 ©2015 Essendant Co.

Made in/ Hecho en/ Fabriqué en China

Product support and parts: 1-800-733-4000


Ayuda del producto y partes / Support technique et pieces

OPERATING INSTRUCTIONS

ALE-TS4159W


A. Seat height adjustment

To raise the seat height, stand up from the chair while lifting the lever (A) under the right side of the seat. To lower the seat height, lift the lever (A) while sitting in the chair.



B. Tilt tension

Knob underneath seat adjusts angle and ease with which chair reclines to the different weights and strengths for different users. To increase tension, turn knob to the right. To release tension (loosen), turn knob to the left.



C. Tilt Lock

Pull lever, "A" on the right side of the seat away from the chair and lean back to recline. To lock chair in upright position, push lever back towards the chair.

