



Bravo Zulu Sensor Solutions MSH-RPTR-ESTP User's Manual

Rev 1.00

- READ BEFORE OPERATING -

This product manual must be read by all operators of the MSH-RPTR. The operation and maintenance of this product must be performed in accordance to the manufacturers guidelines. Failure to do so may cause damage to the MSH-RPTR-ESTP and may increase the risk of injury or death to the operator. This product is not intended for use in any other way than stated in the user's manual.

This apparatus is suitable for use in Class I, Division 2, group D, T4, or unclassified locations.



WARNING: EXPLOSION HAZARD. BATTERIES MUST ONLY BE CHANGED OR CHARGED IN AN AREA KNOWN TO BE NON HAZARDOUS.



WARNING: EXPLOSION HAZARD. DO NOT MOVE OR REPLACE COMPONENTS OR CONNECTORS WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.



WARNING: SUBSTITUTION OF THE COMPONENTS MAY IMPAIR SUITABILITY FOR DIVISION II



WARNING: USE ULTRALIFE RECHARGABLE LITHIUM-ION CELL 3.6 V MODEL: UBBL19-FL, UBBL23-FL OR BZ Sensor Solutions APPROVED EQUIVALENT.

Table of Contents

- 1 General Information 4
 - 1.1 Specifications 4
 - 1.1.1 Dimensions..... 4
 - 1.1.2 Weight..... 4
 - 1.1.3 Operational Time 4
 - 1.1.4 Operational Environment 4
 - 1.1.5 Package Content: 5
- 2 MSH-RPTR-ESTP Operation 6
 - 2.1 Physical Description 7
 - 2.2 Visual Indicators..... 7
 - 2.3 Rechargeable Battery..... 7
 - 2.4 BZSS Mesh Backbone 8
- 3 Preventative Maintenance and Inspection Information..... 8
 - 3.1 Mechanical Inspection 8
 - 3.1.1 Guidelines 8
 - 3.2 Electrical Inspection 8
 - 3.2.1 Guidelines 8
- 4 Support..... 8
 - 4.1 Contact Us..... 8
- 5 Appendix 8
 - 5.1 Compliancy..... 8

1 General Information

The BZ Sensor Solutions MSH-RPTR device is designed to extend the signal and coverage area of the Mesh Network. The design of this device enhanced the functionality of the network.

1.1 Specifications

1.1.1 Dimensions

- Height: 2.25 in.
- Width: 8.0 in.
- Depth: 3.25 in.

1.1.2 Weight

- 18 oz.

1.1.3 Operational Time


- 12 - 24 hrs.

1.1.4 Operational Environment

- Altitude: 2000m
- Temperature: -25 – 40°C
- Humidity: 80% RH max.
- POLLUTION DEGREE 2


1.1.5 Package Content:

- MSH-RPTR-ESTP
- Battery Charger
- Antennae
- Quick Start Guide





2 MSH-RPTR-ESTP Operation

The MSH-RPTR-ESTP is part of the MSH-RPTR family of products. The MSH-RPTR-ESTP is a wireless control device for interfacing and controlling industrial equipment. This product works in conjunction with other MSH-RPTR products and BZ Sensor Solutions devices.



2.1 Physical Description

The MSH-RPTR-ESTP is designed to comply with standards for ANSI/ISA-12.12.01-2007 and ANSI/UL 61010-1-2008, 2nd.



2.2 Visual Indicators

The MSH-RPTR-ESTP contains two visual indicators. A green power LED and a RED charging status LED. The green LED will illuminate when the power to the device is on. The RED LED will illuminate when MSH-RPTR-ESTP is charging. The RED LED will turn off once the charging cycle is complete.

2.3 Rechargeable Battery

The MSH-RPTR-ESTP uses a rechargeable Lithium Ion Polymer battery. ONLY USE ULTRALIFE RECHARGABLE LITHIUM-ION CELL 3.6 V MODEL: UBBL19-FL, UBBL23-FL OR BZ Sensors APPROVED EQUIVALENT.



WARNING: EXPLOSION HAZARD. BATTERIES MUST ONLY BE CHANGED OR CHARGED IN AN AREA KNOWN TO BE NON HAZARDOUS.



WARNING: EXPLOSION HAZARD. DO NOT REMOVE OR REPLACE COMPONENTS OR CONNECTORS WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITIBLE CONCENTRATIONS.



WARNING: SUBSTITUTION OF THE COMPONENTS MAY IMPAIR SUITABILITY FOR DIVISION 2.

2.4 BZSS Mesh Backbone

The BZSS mesh backbone uses the 2.4 Ghz RF signal and follows the ZigBee protocol for mesh networks. The MSH-RPTR-ESTP works with the BZSS Control Card is required. BZSS also offers a mesh repeater to extend the range of the RF signal.

3 Preventative Maintenance and Inspection Information

Maintenance of the MSH-RPTR-ESTP is very minimal. Visually inspect the device for any apparent damage, replace the components as necessary.

3.1 Mechanical Inspection

3.1.1 Guidelines

- Inspect the housing for any wear, exposure, or damage. Replace damaged parts.
- Inspect the E-Stop button and contactor for wear. Replace damaged parts.
- Inspect mounting system for damage. Replace damaged parts.

3.2 Electrical Inspection

3.2.1 Guidelines

- Battery run cycle is dependent on network traffic, if there is a noticeable decline in battery performance, replace the battery with an approved replacement.

4 Support

4.1 Contact Us

Bravo Zulu Sensor Solutions, LLC.
1035 Putman Drive, Huntsville, AL 35816
Tel: (256) 489-0209
Fax: (256) 489-2149
www.bzsensors.com

5 Appendix

5.1 Compliancy

- Nonincendive Electrical Equipment for use in Class I Division II, Division II and Class II, Divisions I and II Hazardous (Classified) Locations. (ANSI/ISA-12.12.01-2007)
- Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1: General Requirements. (ANSI/UL 61010-1-2008, 2nd)