0

DATE

1 of 1

7400-0633

05/24

Notes:

- 1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
- 2. Do not scale drawing.
- 3. Dimensions are in inches (mm).
- 4. LHR door shown. Preparation is typical for both door hands.
- 5. For door reinforcement see template 7400-0000.
- 6. Provide adequate internal support to prevent door deformation from bolting trim to the device.
- 7. Dimensions given about a centerline are symmetrical
- 8. Unspecified radii 1/8 (3.2) maximum.

