

**Don't
Panic!**



W3(WT2 Edge)

Manual



Timekettle APP Download

[Accessory List]



charging case*1



1 pair of earbuds



2 pairs of earplugs



1 pair of ear hooks



1 type-C charging cable



1 product manual

[Product Introduction]

earbuds



Indicator light status:

- Off: The earbuds are in sleep mode
- Green light flashing: Ready for pairing
- Green light on: Pairing succeeded
- White light on: Charging
- Red light on/flashing: The battery running lower than 20%

Charging case

Indicator lights status:

- White lights off: Charging case is in sleep mode
- White lights on (1-4 lights): Battery power (25%, 50%, 75%, 100%)
- White lights flashing: Charging



[Quick Start]



1. Please download the Timekettle app from the mobile app store. (Android 7 and above, iOS 12 and above required)
2. Start the Timekettle app and select "W3 (WT2 Edge)" for the product.
3. Tap on " + ".
4. Take out the left and right earbuds, tear off the insulation sheet, and put them back into the charging case for activation.
5. Take out the earbuds again and put it close to the phone.
6. After the earbuds are taken out, the green indicator light flash.
7. Tap on " **Connect** " on the app (both left and right ears need to be connected).
8. After the connection is successful (the green indicator light of earbuds is on, and the app interface shows " **Connected** "), click " **OK** " to return to the homepage.
9. Seeing the earbuds' status on the screen means they are paired successfully and ready for use.



*Note:

1. The Bluetooth of the mobile phone needs to be turned on and the location service and microphone access of the app are on to ensure normal use.
2. Please do not connect the device in the mobile phone Bluetooth settings, but directly use the app for connection.
3. After the first successful connection, there is no need to manually pair the earbuds for subsequent use. The earbuds can be automatically connected after being taken out.

[Mode Introduction]

Mode 1: Simul Mode

It is suitable for long-term and multi-turn communication between the two parties so that both users can hear the real-time translation.

1. Each user should wear an earbud and select the "Simul Mode" on the app.
2. Select the language used for each earbud.
3. The two sides can start the communication by clicking "  ", and there is no need to manually switch speakers during the process.
4. Tap on "  " to pause the conversation.

tips:

1. Swipe left or right on the app to switch between "Side-by-side mode" and "Face-to-face mode".
2. Try to keep a distance of one meter between the two speakers to reduce mutual interference.
3. Enter "  " to adjust the volume of speech in earbuds, font size, translate audio, pause duration, and personalized glossary to improve the user experience.

Mode 2: Listening Mode


No need to share earbuds with others when listening to translation. This function only translates audio on mobile phones and plays the translation through earbuds.

1. Users can wear one or both earbuds and tap on "Listening Mode" on the app.

2. Select the language for your earbuds and mobile phone.
3. Click "🎤", and then place the mobile phone microphone near the sound source to ensure the audio quality.
4. Users can listen to the translation through one or both earbuds.
5. Tap on "⏸" to pause.

Tip:

You can adjust pause duration, ambient noise, and font size in the app to improve translation accuracy.



Mode 3: Speaker Mode

It is ideal for short, quick conversations without the need to share earbuds.

1. Users can wear one or both earbuds and tap on "Speaker Mode" on the app.
2. Select the language for your earbuds and mobile phone.
3. Earbud users can touch the earbud touch zone, or tap on the corresponding "🎤" icon in the app to speak.
4. Touch the earbud touch zone again, or click "⏸" in the app to end your speech.
5. After the speech, the mobile phone will automatically play back the translation via the speaker and display the text at the same time.
6. Mobile phone users can tap on the corresponding "🎤" icon in the app to speak, and then tap on "⏸" again to end their speech.
7. Earbuds users can listen to the translation through one or both earbuds.

tips:

1. You can enable/disable the "Auto Mic Switch" function in "🔊". When the "Auto Mic Switch" is turned on, mobile phone users can directly tap on "🗣️" to speak when the earbuds users are speaking, and there is no need to wait. Instead, mobile phone users have to wait until the earbuds users end their speeches when the "Auto Mic Switch" is turned off.
2. Swipe left or right on the app to switch between "Side-by-side mode" and "Face-to-face mode".
3. Enter "🔊" to adjust the volume of speech in earbuds, ambient noise, font size, translate audio voice, pause duration, and personalized glossary to improve the user experience.

Mode 4: Touch Mode

Designed for multiple rounds of communication between two parties and the manual mic switch is needed.

1. Each user should wear an earbud and select the "Touch Mode" on the app.
2. Select the language used for each earbud.
3. The speaker taps on the touch zone of his/her earbuds or the corresponding "🗣️" icon on the app to start speaking.
4. Touch the earbuds touch zone again or tap on "🔊" to end the speech, and then the other party can hear the translation via earbuds.

tips:

1. You can enable/disable the "Auto Mic Switch" function in "🔊". When the "Auto Mic Switch" is turned on, the second speaker can touch the earbuds touch zone to speak in the middle of another speaker's speech. When the

function is turned off, the second speaker can speak only after the other speaker finishes speaking.

2. Swipe left or right on the app to switch between "Side-by-side mode" and "Face-to-face mode".

3. Try to keep a distance of one meter between the two speakers to reduce mutual interference.

4. Enter "🔊" to adjust the volume of speech in earbuds, ambient noise, font size, translate audio, pause duration, and personalized glossary to improve the user experience.5. The Touch Mode also supports the multi-person translation scenario of two to six people. Please scan the QR code for detailed steps and the video demonstration.



Online manuals

[Tips for Use]

1. Try to speak clearly and loudly with standard pronunciation. A proper pause after each sentence/clause can improve the accuracy of translation.
2. When using "Listening Mode" and "Speaker Mode," placing the mobile phone microphone nearer and directing it towards the speaker may also increase the translation accuracy.
3. For all modes, you can enter "⌂" to adjust the volume of speech in earbuds, font size, ambient noise, translation audio speed, pause duration, and personalized glossary to improve the user experience.
4. The speed of translation depends on the Internet speed. In case of no network or poor network, it is suggested to purchase and download the Offline Translation package in advance. The number of languages for Offline Translation is limited, and the accuracy is slightly lower than that of Online Translation. (You can find the Offline Translation entry on the homepage of the mobile phone app)
5. This product is not applicable for computer or mobile audio translation, and the accuracy will be lower than that of human voice translation.
6. Select "Side-by-side mode" or "Face-to-face mode" based on how the two speakers are positioned.

[FAQs]

1. Why isn't the translation accurate?

- Please check that you have selected the right language and accent.
- Please check whether the earbuds are worn correctly and their microphone point to your mouth. If you speak with a mobile phone, make sure that it is close to the sound source and avoid ambient noise interference.
- To improve translation accuracy, you can adjust the pause duration and ambient noise to a proper level and add items to the personalized glossary in the settings of each mode.

2. Why is the translation function not working at all (or working very badly)?

- Please check your Internet connection. Poor or no network will lead to translation failure. You can change the network connection or turn on Offline Translation.
- Please check whether the earbuds are successfully connected (the green indicator light is on). If the connection fails, please put them back into the charging case and take them out again to reconnect them.
- It may be caused by the low battery or charging failure of earbuds. Please put them back into the charging case for charging, and take them out after a while.

3. Why can't I connect my earbuds?

- Please ensure that the earbuds are not connected to another device.
- Please put the earbuds back into the charging case, take them out again, and see whether the green light flashes. Tap on " " in the mobile phone app to connect manually.

4. Why is the earbud volume too high or too low?

- Tap on "🔊" on each mode's page to adjust the volume of left and right earbuds.

5. Why can't I turn on my earbuds or charge them?

- Please first check whether the batteries of the earbuds and charging case are running low. If the red indicator light of the earbuds is on or flashes or the indicator lights of the charging case are off, please connect a charger for charging. Please check if the charging works normally: the white indicator light of the earbuds should be on and the white indicator lights on the charging case should flash in sequence.
- If the earbuds charging fails, please first check if the charging cable is damaged and try replacing it; inspect the charging contacts of the charging case for any rust or damage, and if so, please contact our customer service for assistance. Please also check whether there is any dirt on the charging contacts of the charging case and the earbuds, and if so, clean them with a cleaning cloth. After removing the dirt, put the earbuds back into the charging case for charging and see if the white lights stay on.

In case of other problems, you can inquire through the "Customer Service" section on the homepage of the app.



[Safety Information]

Please read the following safety information before using this product.

- Please avoid methods that have not been officially recommended for charging in order to prevent risks like fire, explosion, or other hazards;
- Be careful not to drop, burn, subject the product to excessive force, or immerse it in liquid to avoid damaging the device;
- Avoid exposing the product to high temperatures or keeping it around heating devices such as ovens, microwaves, etc.;
- Be sure to use the product within the temperature range of 0-35° C and store it within the range of -20-45° C. Temperatures that are too high or too low could result in device malfunctions;
- Timekettle shall not be responsible for quality problems, equipment failures, and safety accidents caused by the use of accessories that have not been officially approved.

[Product Specifications]

Name: AI Simultaneous Interpretation Earbuds

Model: W3(WT2 Edge)

Earbuds size: 37.8*16.5*19mm

Charging case size: 58*58*27mm

Total approximate weight: 52.4g

Charging specification: Type-C 5V 1A

Battery capacity: Single earbud (50mAh); Charging case (500mAh)

Charging time of charging case: 1.5 hours

Earbuds charging time: 1 hour

Battery life of charging case: 12 hours

Battery life of earbuds for a single charge: 3 hours

Bluetooth version: BLE 5.0

[Warranty Regulations]

- 1.Any problems with the quality of the product occurring within one year during normal use of the product or half a year for its accessories, from the date of purchase, are subject to free maintenance service with the official/officially recognized order number on the purchasing platform.
- 2.Normal wear and tear, improper usage not in accordance with the manual, and damages caused by human actions or irresistible forces are not covered under the warranty.
- 3.For repair of malfunctions caused by human actions or irresistible forces, or when the warranty period has expired, we will charge an appropriate repair fee.

[Contact Us]

Official website: www.timekettle.co

Customer service email: support@timekettle.co

Contact: (+86) 0755-86725036 (Chinese)

+1 (833) 491 - 1328 (English/ Español)

Manufacturer: Shenzhen Timekettle Technologies Co., Ltd.

Address: Building A#612, Minqi Science Park, No. 65 Lishan Road, Pingshan Community, Taoyuan Street, Nanshan District, Shenzhen

[Online Manual]

See the Online Manual for more tutorials in text, image, and video.



Online manuals