

MAST

Activate Your Artistic Inspiration



MAST

English

A: Screen

- ①. Voltage display
- ②. Battery level display

B: Battery

- ③. Long press button to power on/off, single click when powered on, start/pause
- ④. Voltage adjustment button

C: Stroke

Adjust the stroke by rotating 360°, stroke range: 2.2—3.2

D: Grip

Rotate the grip to adjust the needle length

E: Cartridge interface

Insert the cartridge into the interface, twist clockwise to tighten

F: Type-C charging connector

PARAMETER

Output voltage	4-10V
Battery capacity	900mAh
Stroke	2.2-3.2mm
Speed	11000 ± 10%rpm

Polski (język)

A. Ekran

- ①. Wyświetlacz napięcia
- ②. Wskaźnik poziomu naładowania baterii

B: Bateria

- ③. Długie naciśnięcie przycisku do włączania/wyłączania, pojedyncze kliknięcie po włączeniu, start/pauza
- ④. Przycisk regulacji napięcia

C: Udar

Regulacja skoku poprzez obrót o 360°, zakres skoku: 2,2-3,2

D: Uchwyt

Obróć uchwyt, aby wyregulować długość igły

E: Interfejs kartridża

Włóż wkład do interfejsu, przekręć zgodnie z ruchem wskazówek zegara, aby go dokręcić.

F: Złącze ładowania typu C

