

单折宽9cm高15cm
整纸宽36cm高15cm

折线: — — — — —
切线: —————

正面

fit4med® Wall Mounted Parking Rack Manual



Product accessories



1. Horizontal hanging bracket x 1
2. Vertical hanging bracket x 1
3. Frame cushion x 1
4. M8x80 Expansion screw x 4
5. 13+14 double sided wrench x 1

Installation steps



1. First, mark the four hole positions of the expansion screw on the wall with a marker pen



2. Use the drilling machine with a diameter equal to or greater than expansion screw(specification M8x80) to drill holes in the marked areas (drilling bit needs to be prepared by oneself) and insert the bolts.



3. Align the top two holes of bracket (1) and bracket (2) and thread them into the bolts inside the wall holes.



5. Attached the (3) cushion to the (1) load-bearing area. (To prevent the frame paint from being scrapped off)



4. Screw on the four nuts and tighten them with a wrench.



6. Installation completed

Attention:

Please confirm the wall material and do not use it on hollow walls/gypsum board walls
Please do not install in pedestrian walkways to avoid collisions
Pls keep the wheels clean to avoid contaminating the walls

fit4med®

Importer: Mona
Leszczynowa 8
62-070 Dąbrówka; Poland
Made in PRC

反面

fit4med® Wieszak ścienny na rower



W zestawie:



1. Uchwyt poziomy x 1
2. Uchwyt pionowy x 1
3. Podkładka do ramy x 1
4. Śruba rozprężna M8x80 x 4
5. Klucz dwustronny 13 + 14 x 1

Montaż:



1. Najpierw oznacz cztery miejsca na otwory śrub rozprężnych na ścianie za pomocą markera.



2. Użyj wiertarki o średnicy równej lub większej niż śruba rozprężna (specyfikacja M8x80), aby wywiercić otwory w zaznaczonych miejscach (wiertło należy przygotować samodzielnie) i włożyć śruby



3. Wyrównaj górne dwa otwory uchwytu (1) i uchwytu (2) i wkręć je na śruby w otworach w ścianie.



5. Przymocuj podkładkę (3) do strefy nośnej (1). (Aby zapobiec zarysowaniom farby na ramie)



4. Nałóż cztery nakrętki i dokręć je kluczem



6. Montaż zakończony

Uwaga:

Proszę upewnić się, jaki jest materiał ściany i nie montować uchwytu na ścianach pustych lub gipsowo-kartonowych.
Proszę nie instalować go w przejściach dla pieszych, aby uniknąć kolizji.
Proszę dbać o czystość kół, aby uniknąć zabrudzenia ścian.

fit4med®

Importer: Mona
Leszczynowa 8
62-070 Dąbrówka; Poland
Made in PRC