



# Nanostine

The scalable way to do nanocoatings

---

Commercial Dossier

# Executive summary

**Nanostine** industrializes nanostructured coatings, combining lab-grade purity with industrial throughput and low cost. The company has validated its technology **with 11 industrial and institutional customers**, including **ESA, SENER, Graphenea, Acciona, Nano4Energy and B5Tec**, delivering **more than 25 projects**.



## Higher reactivity

thanks to a much larger surface area.



**New properties** (optical, electrical, catalytic) driven by size effects and quantum effects.




**Application-tailored performance**, making materials lighter, harder, more durable and non-stick.

**Nanostine** has worked with **28 materials** to provide a **unique combination**:

## Cost + Quality + Scale + Sustainability


- ✓ **28+ materials** processed (metals, oxides, polymers, ...).
- ✓ Designed for **high-throughput, low-cost production**.
- ✓ Processes compatible with **industrial scale** and **sustainability targets**.



Surface treated with nanoparticles, increasing interaction area without impurities.

# Technology: Industrial precision and scalability

Our **proprietary** MICS (Multiple Ion Cluster Source) technology enables the manufacturing of **complex nanoparticles** with **atomic-level precision** and **industrial stability**.



## Full control

Generation of alloys and complex nanostructures in a single step using **three independent magnetrons**.

## Industrial scalability (the “race track” issue solved)

We have solved the typical instability of conventional sputtering by using our proprietary **Full-Face Erosion (FFE) magnetrons**.

## Stability data

Validated continuous operation for more than 12 hours without replacing the feedstock, achieving 20 % target utilization (vs. 5-10 % standard), significantly reducing OPEX and maintenance downtime.

# Nanostine: High-performance coatings at scalable cost



## Precision and purity

**Ultra-thin conformal layers** (from single-particle-thick coatings to films of several  $\mu\text{m}$ ) with thickness control of  $\pm 2\text{--}10\text{ nm}$ .

**Very low impurities**, resulting in higher performance and reliability.



## Cost and scalability

Lower cost per  $\text{m}^2$  than traditional methods: **up to 33% lower than CVD and 50% lower than laser**, with better quality.

High productivity compatible with volume manufacturing. Cycle times per part can be **just a few seconds**.




## Sustainability

**Dry process, with no solvents or hazardous reagents** (vs. chemical alternatives).

**Reusable raw material**, reducing cost.


Nanostine is a CSIC spin-off with patented technology\*



# Patents: Strong intellectual property protection

## 1 EP3605583B1 DEVICE FOR THE STABLE MANUFACTURE OF NANOCLUSTERS

- Stable nanoparticle production using FFE magnetrons.
- Enables continuous industrial operation.
- European patent granted and validated in ES, DE, UK, FR, IT, SWZ.
- Co-developed with CSIC. Exclusivity for Nanostine.



## 2 EP25382706.7 ANTI-MULTIPACTOR COATING, METHOD OF PRODUCTION AND USES THEREOF

- Protects the family of anti-multipactor coatings for RF components in space applications.
- European patent in the validation process.
- Filed on 8 July 2025.
- Developed jointly with CSIC. Exclusivity for Nanostine.



# Proprietary know-how

## 1 Equipment design and tuning




Maintaining UHV and plasma stability during continuous nanoparticle growth.

## 2 Synthesis route optimization

Empirical calibration protocols for each substrate and coating family, ensuring reproducibility and performance.

## 3 Process software and control logic

Unique deposition algorithms to scale from lab to industrial platforms.



Homogeneous nanoparticle distribution.


No agglomerate formation.

Deposits <1 monolayer.


Controlling the number of nanoparticles per  $\mu\text{m}^2$ .




# Examples of broad product portfolio




*Single element*




*Alloys*




*Nanocolumns*



*Oxidized nanoparticles*



*Core-shell*



*Nanocolumns + nanoparticles*



# Wide range of options

1A

1

H

1.00794

2A

2

He

4.002602

3

Li

6.941

4

Be

9.012182

11

Na

22.989769

12

Mg

24.3050

3B

4B

5B

6B

7B

8B

1B

2B

3A

4A

5A

6A

7A

8A

5

B

10.811

6

C

12.0107

7

N

14.0067

8

O

15.9994

9

F

18.9984032

10

Ne

20.1797

13

Al

26.9815386

14

Si

28.0855

15

P

30.973762

16

S

32.065

17

Cl

35.453

18

Ar

39.948

19

K

39.0983

20

Ca

40.078

21

Sc

44.955912

22

Ti

47.867

23

V

50.9415

24

Cr

51.9961

25

Mn

54.938045

26

Fe

55.845

27

Co

58.933195

28

Ni

58.6934

29

Cu

63.546

30

Zn

65.38

31

Ga

69.723

32

Ge

72.64

33

As

74.92160

34

Se

78.96

35

Br

79.904

36

Kr

83.798

37

Rb

85.4678

38

Sr

87.62

39

Y

88.90585

40

Zr

91.224

41

Nb

92.90638

42

Mo

95.96

43

Tc

[98]

44

Ru

101.07

45

Rh

102.90550

46

Pd

106.42

47

Ag

107.8682

48

Cd

112.411

49

In

114.818

50

Sn

118.710

51

Sb

121.760

52

Te

127.60

53

I

126.90447

54

Xe

131.293

55

Cs

132.9054519

56

Ba

137.327

57-71

Lanthanides

72

Hf

178.49

73

Ta

180.94788

74

W

183.84

75

Re

186.207

76

Os

190.23

77

Ir

192.217

78

Pt

195.084

79

Au

196.966569

80

Hg

200.59

81

Tl

204.3833

82

Pb

207.2

83

Bi

208.98040

84

Po

[209]

85

At

[210]

86

Rn

[222]

1A

1

H

1.00794

2A

2

He

4.002602

3

Li

6.941

4

Be

9.012182

11

Na

22.989769

12

Mg

24.3050

3B

4B

5B

6B

7B

8B

1B

2B

3A

4A

5A

6A

7A

8A

5

B

10.811

6

C

12.0107

7

N

14.0067

8

O

15.9994

9

F

18.9984032

10

Ne

20.1797

13

Al

26.9815386

14

Si

28.0855

15

P

30.973762

16

S

32.065

17

Cl

35.453

18

Ar

39.948

19

K

39.0983

20

Ca

40.078

21

Sc

44.955912

22

Ti

47.867

23

V

50.9415

24

Cr

51.9961

25

Mn

54.938045

26

Fe

55.845

27

Co

58.933195

28

Ni

58.6934

29

Cu

63.546

30

Zn

65.38

31

Ga

69.723

32

Ge

72.64

33

As

74.92160

34

Se

78.96

35

Br

79.904

36

Kr

83.798

37

Rb

85.4678

38

Sr

87.62

39

Y

88.90585

40

Zr

91.224

41

Nb

92.90638

42

Mo

95.96

43

Tc

[98]

44

Ru

101.07

45

Rh

102.90550

46

Pd

106.42

47

Ag

107.8682

48

Cd

112.411

49

In

114.818

50

Sn

118.710

51

Sb

121.760

52

Te

127.60

53

I

126.90447

54

Xe

131.293

55

Cs

132.9054519

56

Ba

137.327

57-71

Lanthanides

72

Hf

178.49

73

Ta

180.94788

74

W

183.84

75

Re

186.207

76

Os

190.23

77

Ir

192.217

78

Pt

195.084

79

Au

196.966569

80

Hg

200.59

81

Tl

204.3833

82

Pb

207.2

83

Bi

208.98040

84

Po

[209]

85

At

[210]

86

Rn

[222]

1A

1

H

1.00794

2A

2

He

4.002602

3

Li

6.941

4

Be

9.012182

11

Na

22.989769

12

Mg

24.3050

3B

4B

5B

6B

7B

8B

1B

2B

3A

4A

5A

6A

7A

8A

5

B

10.811

6

C

12.0107

7

N

14.0067

8

O

15.9994

9

F

18.9984032

10

Ne

20.1797

13

Al

26.9815386

14

Si

28.0855

15

P

30.973762

16

S

32.065

17

Cl

35.453

18

Ar

39.948

19

K

39.0983

20

Ca

40.078

21

Sc

44.955912

22

Ti

47.867

23

V

50.9415

24

Cr

51.9961

25

Mn

54.938045

26

Fe

55.845

27

Co

58.933195

28

Ni

58.6934

29

Cu

63.546

30

Zn

65.38

31

Ga

69.723

32

Ge

72.64

33

As

74.92160

34

Se

78.96

35

Br

79.904

36

Kr

83.798

37

Rb

85.4678

38

Sr

87.62

39

Y

88.90585

40

Zr

91.224

41

Nb

92.90638

42

Mo

95.96

43

Tc

[98]

44

Ru

101.07

45

Rh

102.90550

46

Pd

106.42

47

Ag

107.8682

48

Cd

112.411

49

In

114.818

50

Sn

118.710

51

Sb

121.760

52

Te

127.60

53

I

126.90447

54

Xe

131.293

55

Cs

132.9054519

56

Ba

137.327

57-71

Lanthanides

72

Hf

178.49

73

Ta

180.94788

74

W

183.84

75

Re

186.207

76

Os

190.23

77

Ir

192.217

78

Pt

195.084

79

Au

196.966569

80

Hg

200.59

81

Tl

204.3833

82

Pb

207.2

83

Bi

208.98040

84

Po

[209]

85

At

[210]

86

Rn

[222]

1A

1

H

1.00794

2A

2

He

4.002602

3

Li

6.941

4

Be

9.012182

11

Na

22.989769

12

Mg

24.3050

3B

4B

5B

6B

7B

8B

1B

2B

3A

4A

5A

6A

7A

8A

5

B

10.811

6

C

12.0107

7

N

14.0067

8

O

15.9994

9

F

18.9984032

10

Ne

20.1797

13

Al

26.9815386

14

Si

28.0855

15

P

30.973762

16

S

32.065

17

Cl

35.453

18

Ar

39.948

19

K

39.0983

20

Ca

40.078

21

Sc

44.955912

22

Ti

47.867

23

V

50.9415

24

Cr

51.9961

25

Mn

54.938045

26

Fe

55.845

27

Co

58.933195

28

Ni

58.6934

29

Cu

63.546

30

Zn

65.38

31

Ga

69.723

32

Ge

72.64

33

As

74.92160

34

Se

78.96

35

Br

79.904

36

Kr

83.798

37

Rb

85.4678

38

Sr

87.62

39

Y

88.90585

40

Zr

91.224

41

Nb

92.90638

42

Mo

95.96

43

Tc

[98]

44

Ru

101.07

45

Rh

102.90550

46

Pd

106.42

47

Ag

107.8682

48

Cd

112.411

49

In

114.818

50

Sn

118.710

51

Sb

121.760

52

Te

127.60

53

I

126.90447

54

Xe

131.293

55

Cs

132.9054519

56

Ba

137.327

57-71

Lanthanides

72

Hf

178.49

73

Ta

180.94788

74

W

183.84

75

Re

186.207

76

Os

190.23

77

Ir

192.217

78

Pt

195.084

79

Au

196.966569

80

Hg

200.59

81

Tl

204.3833

82

Pb

207.2

83

Bi

208.98040

84

Po

[209]

85

At

[210]

86

Rn

[222]

1A

1

H

1.00794

2A

2

He

4.002602

3

Li

6.941

4

Be

9.012182

11

Na

22.989769

12

Mg

24.3050

3B

4B

5B

6B

7B

8B

1B

2B

3A

4A

5A

6A

7A

8A

5

B

10.811

6

C

12.0107

7

N

14.0067

8

O

15.9994

9

F

18.9984032

10

Ne

20.1797

13

Al

26.9815386

14

Si

28.0855

15

P

30.973762

16

S

32.065

17

Cl

35.453

18

Ar

39.948

19

K

39.0983

20

Ca

40.078

21

Sc

44.955912

22

Ti

47.867

23

V

50.9415

24

Cr

51.9961

25

Mn

54.938045

26

Fe

55.845

27

Co

58.933195

28

Ni

58.6934

29

Cu

63.546

30

Zn

65.38

31

Ga

69.723

32

Ge

72.64

33

As

74.92160

34

Se

78.96

35

Br

79.904

36

Kr

83.798

37

Rb

85.4678

38

Sr

87.62

39

Y

88.90585

40

Zr

91.224

41

Nb

92.90638

42

Mo

95.96



# Validated results across 4 strategic industries

|                     |                                                                                   |                                                                                                                                                                                                                                                |
|---------------------|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Aerospace & Defense |  | <p>Multipactor mitigation <b>x 2–7</b> on satellite RF components</p> <p>Hydrophobic/self-cleaning lenses, <b>x 2</b> faster contamination removal</p> <p>Materials outgassing reduced up to <b>x 100</b> with higher reliability in orbit</p> |
| Energy              |  | <p>Electrodes coating: <b>30 % less catalyst</b> with increased durability &amp; performance</p> <p>Improved lifetime &amp; efficiency for fuel cells and electrolyzers</p>                                                                    |
| Sensors             |  | <p>Sensitivity improved <b>x 2-3</b></p> <p>Enhanced microorganism detection (biosensing)</p>                                                                                                                                                  |
| Healthcare          |  | <p>Antibacterial nanoparticle <b>implant coatings</b></p> <p>Adhesion &amp; biofilm proliferation reduced by up to <b>95 %</b></p>                                                                                                             |



# SpaceTech success story #1: Radiofrequency

## Problem

**Multipactor effect**, a phenomenon in which electrons bounce between metallic surfaces inside RF devices, creating a cascade that overheats or destroys components. Existing coatings (Alodine, SurTec) mitigate it only partially:

1. **Alodine** uses hexavalent chromium (Cr VI), a carcinogen restricted under the European REACH regulation (Registration, Evaluation, Authorization and Restriction of Chemicals).
2. **SurTec** is REACH-compliant but provides weak multipactor suppression, forcing operation at lower RF power levels or requiring device redesign.


## Solución de Nanostine

**REACH-compliant nanostructured coatings that drastically reduce secondary electron emission** while maintaining electrical conductivity and mechanical stability (-150 °C to +150 °C).

## Validation to date

**ESA BIC Madrid and ESA IDEAS-OSIP projects with ESA and SENER.**

**Performance improvement of x 3–7** (first crossover energy ( $E_1$ ) = 130 eV vs. 41 eV (Alodine) and 18 eV (SurTec); discharge threshold ( $\Delta P$ ): 7–9 dB vs. 3.3–7.7 dB for Alodine 1200).



Comparison between a flat surface (left) and a nanoparticle-textured surface (right) to mitigate the multipactor effect. Electrons escape more easily from less rough surfaces (without nanoparticles).

# SpaceTech success story #2: Self-cleaning lenses

## Problem

Fingerprints, organic stains and fogging on external glass surfaces **degrade image quality**.

## Nanostine solution

**Self-cleaning photocatalytic coatings** based on titanium dioxide nanocolumns ( $\text{TiO}_2$  NC).


## Validation to date

Pilot project with **Lidax Ingeniería**.


Samples intentionally contaminated with hydrocarbons and esters following ECSS-Q-ST-70-05C.

Two cleaning protocols: conventional bake-out (72 h, 80 °C,  $10^{-6}$  mbar) and UV-assisted cleaning.

**UV cleaning removed up to twice as much organic residue as bake-out**, confirming photocatalytic self-cleaning capability.



Nanostructured coatings deposited on metal substrates (bottom) and optical glass (BK7) (top).



Superhydrophobic coatings.

# Sensor success story: High-sensitivity sensors for IoT

## Problem

**Increase signal-to-noise ratio and sensitivity** in miniaturized IoT sensors without damaging the base material of the devices.

## Nanostine solution

**Ultra-pure metal nanoparticles** (Ag, Au) deposited directly onto active graphene or silicon substrates.

## Commercial product in collaboration with Graphenea

Nanostine's MICS process deposits precision nanoparticles on Graphenea's graphene sensors.


This functionalization **improves sensor sensitivity** to specific biological or chemical analytes without the contamination risks of wet chemistry.

## Technology advantage (tailored functionalization)

**Independent control:** We can tune particle density (NPs/ $\mu\text{m}^2$ ) and particle size independently.

**Benefit:** This lets us maximize active surface area (increasing signal) without increasing individual particle size (maintaining resolution).

[Press release link](#)



Ultra-sensitive sensors.



# Energy success story: Electrode optimisation

## Problem

Electrodes in fuel cells, electrolyzers and batteries suffer from **low catalyst utilization, limited durability and high catalyst cost**.

## Nanostine solution

Nanoparticle coatings engineered at the nanoscale to maximize catalytic surface area, improve charge transfer and **reduce precious-metal loading by ~ 30 %**.

Solvent-free process, uniform coverage even on porous electrodes.

## Validation to date


Products commercialized on **ElectroSeek**.

**B5Tec** project: same performance with ~ 30 % less platinum (a very expensive material). Strong adhesion under methanol flow (high robustness).

**Nano4Energy** project: electrolyser electrodes for green hydrogen.

**Natron and UAM**: solid-state battery interfaces and nanoparticles for H<sub>2</sub> storage.

### Custom Nanoparticle Coatings for Electrolysis Electrodes



#### Description

Ultrapure nanoparticle coatings (Mo, Co, Ni, MoO<sub>3</sub>, CoO, NiO) adaptable to various substrates and geometries. Designed to enhance catalytic activity and stability of electrodes used in alkaline, PEM, and AEM electrolyzers.

#### Applications:

Catalytic electrodes for water electrolysis (HER/OER)

Price: On request

[Contact Vendor](#)

[Add to List](#)

### Custom Nanoparticle-Coated Substrates for Electrochemical Devices



#### Description

Tailor-made substrates coated with ultrapure metallic or metal oxide nanoparticles (Mo, Co, Ni, MoO<sub>3</sub>, CoO, NiO, Pt, Au, Ir, Pd, TiO<sub>2</sub> etc.) using a physical vapor aggregation process. Designed to boost electrochemical activity, durability, and efficiency in advanced energy and sensing devices.

#### Applications:

- Fuel cells: enhanced catalytic layers and electrodes
- Electrolyzers: efficient HER/OER electrodes
- Batteries: modified current collectors
- Supercapacitors: improved surface area and conductivity

Price: On request

[Contact Vendor](#)

[Add to List](#)

Products on ElectroSeek (marketplace).



# New developments: Healthcare and prosthetics

## Problem

Existing coatings (TiN, antibiotic films) to **prevent post-implant infections** lack **antibacterial activity** or promote resistance.

## Nanostine solution



**Antibacterial** and **biocompatible** nanostructured **coatings** that inhibit bacterial adhesion and biofilm formation without antibiotics, while maintaining mechanical stability for years.

## Development status

**95% in-vitro bacterial reduction** on real implants tested with academic partners.

Excellent adhesion and surface finish.

Selected for HealthStart 2025 (Community of Madrid) to define the industrial pathway (TRL 4 → 5 during the project).



Top image: Implant example.

Bottom image: Coating real implants and prostheses to prevent bacterial and biofilm growth. Comparison of bacterial growth without nanoparticles (top) vs. with nanoparticles (bottom).

# Nanostine is a platform with multiple applications

Beyond the showcased use cases, we **develop nanoparticles and coatings** to solve specific industrial requirements.



**Tailored**

Designs **adapted** to specific requirements and materials.



**Scalable**

From lab to industrial production with **repeatability**.



**High-ROI**

**Measurable improvements** in total cost and performance.





# Nanostine

**The scalable way to do nanocoatings**

C/Faraday, 7, Madrid, Spain

[daniel.gonzalez@nanostine.com](mailto:daniel.gonzalez@nanostine.com)

[www.nanostine.com](http://www.nanostine.com)

