

SURFACE TREATMENT / UV CURE

USHIO SHANGHAI, INC.
02,03 Unit, 30F, New Bund Center, NO.555 West Haiyang Road/
NO.588 Dongyu Road, Pudong, Shanghai, 200126, P.R.C.
TEL: +86 21-6841-1135 FAX: +86 21-6841-1150

USHIO SHENZHEN, INC.
Unit 08, 52/F, A Block, Kingkey 100 Building,
No.5016 Shennan East Road, Luohu District, Shenzhen, P.R.C.
TEL: +86 755-8207-0162 FAX: +86 755-8207-0161

USHIO ASIA PACIFIC PTE. LTD.
28 Genting Lane, #05-05, Platinum 28, Singapore 349585
TEL: +65 6274-5311 FAX: +65 6274-5300

USHIO TAIWAN, INC.
8F, No.4, Sec.1, Zhongxiao W.Rd., Taipei 10041, Taiwan, R.O.C.
TEL: +886-2-2312-3358 FAX: +886-2-2312-3858

USHIO KOREA, INC.
(Yeoksam-dong, Gangnam Center Building), 17F, 388,
Gangnam-daero, Gangnam-gu, Seoul 06232 Rep.of Korea
TEL: +82 2-587-1115 FAX: +82 2-587-1118

USHIO AMERICA, INC.
5440 Cerritos Avenue, Cypress, CA 90630, U.S.A.
TEL: +1 714-236-8600 FAX: +1 714-229-3180

USHIO EUROPE B.V.
Breguetlaan 38, 1438 BC Oude Meer, The Netherlands
TEL: +31 20-446-9333

USHIO GERMANY GmbH
Münchener Straße 10, 85643 Steinhöring, Germany
TEL: +49 80-94-906-0

USHIO U.K., LTD.
Argyll House, Quarrywood Court, Livingston,
West Lothian, EH54 6AX United Kingdom
TEL: +44 129-625-6067

2209K①-1000Ei①


USHIO

USHIO INC.

**Sales Department, Photon Process Global Business Unit,
System Solution Division**

TOKYO 1-6-5 Marunouchi, Chiyoda-ku, Tokyo 100-8150, Japan
TEL: +81 3-5657-1033 FAX: +81 3-5657-1030
OSAKA Shin Osaka Prime Tower 12F 6-1-1 Nishinakajima, Yodogawa-ku,
Osaka 532-0011, Japan
TEL: +81 6-6306-5711 FAX: +81 6-6306-5718
www.ushio.co.jp Mail: stc@ushio.co.jp





Cleaning, Surface Treatment, Curing, Bonding

Ushio's Cleansing, Surface Treatment, Curing and Bonding	03
Sample Applications	05
Example of manufacturing process	07
Cleaning, Surface Treatment	
Excimer Irradiation Units	09
Atmospheric Pressure Plasma Irradiation Device	15
Curing, Bonding	
Spot UV Irradiation Units	17
UV-LED	25
Customer Service	33

Ushio's Cleaning, Surface Treatment

Optimize surface conditions with light and plasma

Cleaning and surface treatment technologies offer all sorts of possibilities. Not only can they improve the overall stability of production processes and increase yields, but they can also add new functionality to materials, allowing combinations of materials that were formerly not possible. In addition, a wide variety of cleaning and surface treatment processes are available, such as "wet/dry," "physical action/chemical action," and "atmospheric pressure treatment/decompression treatment," and it is necessary to select the most appropriate method for the purpose and application. Ushio provides solutions to create optimal surface conditions based on light and plasma technologies.

Features of Dry Cleaning/Surface Treatment Technology

Compared with ordinary heatbased curing and drying, UV curing offers the advantages listed below.

**Simplified process
Space saving**

Only UV irradiation is needed, so no rinsing or drying process is required

Low environmental impact

Chemical treatment by photochemistry/free radicals, so no need for chemical management or waste liquid disposal

Easy to incorporate into inline processes

No need for vacuum pulling or release, making it easy to incorporate into inline processes

Can accommodate larger workpieces

Capable of processing even large workpieces of up to three meters

Ushio's Curing, Bonding

Anything, anywhere — curing and bonding with UV

"Ultraviolet (UV)-curable resins" are photosensitive agents that instantly harden (cure) or bond upon irradiation by ultraviolet light. Materials coated with such resins can be cured or bonded by irradiation with ultraviolet light in wavelengths short enough to induce a chemical reaction. When used in UV curing and bonding technology, this technique is referred to using terms such as "light hardening" and "UV curing." This UV curing technology was first used practically around 35 years ago in the printing industry for stickers and labels. Since then, applications for UV curing have expanded into a range of manufacturing sectors, including the curing of paints and surface coatings, the attachment of precision components such as semiconductors and electronic components, and the bonding of LCD panels, as well as in nanotechnology, biotechnology, fuel cells and photovoltaic cells.

Features of UV Curing Technology

Compared with ordinary heat-based curing and bonding, UV curing offers the advantages listed below.

Quick effect and adhesion

Processes that would take hours with heat curing and bonding can be completed in just a few seconds

Low-temperature processing with little or no heat damage

No high heat is generated, so the temperature of the irradiated object does not increase

Space saving


Does not require furnaces or other large equipment, so conserves space

Non-polluting

Uses no organic solvents, so this technology is pollution-free and environmentally friendly

Example of dry cleaning/surface treatment


■ VUV/O₃ Cleaning with Dielectric Barrier Discharge Excimer Lamp



Click here to see a video about "Excimer Light Irradiation System for Surface Treatment."




■ Difference between UV curing and thermal curing




Cleaning, Surface Treatment, Curing, Bonding

Ushio's light technologies are used in a wide variety of applications to meet all sorts of needs.


For the mobile equipment




For Automobiles




For computers




For cameras



For CD, DVD and Blu-ray




For optical communications




For printing



For medical equipment



Manufacturing Process of Touch Panels and Ushio's UV Technology



Ushio products used in manufacturing processes

01 Excimer
Irradiation Units → P9




02 04 Spot UV
Irradiation Units → P17



03 05 UV-LED → P25



Example of touch panel structure




Excimer Irradiation Units


EXCIMER

Cleaning and surface modification by excimer light

This unit emits ultraviolet rays of high photonic energy with the very short wavelength of 172nm.
This equipment can decompose resins and excite gases, and is used for dry cleaning of organic materials, hydrophilization, and adhesive strength improvement.



Result of Evaluation by Thermal Desorption GC/MS Analysis




Change of Water Contact Angle

Before Radiation




After Radiation



Process Conditions	
Radiation time	10 seconds
Sample	Non-alkali glass
Atmosphere	In atmospheric air
Radiation distance	2mm


Contact angle 50°→ 5° or less (less than measurement limit)

Change in Contact Angle for Various Organic and Inorganic Substrates




Evaluation Example


Wettability improvement of film substrate



SiO₂ conversion of silicone resin surface



Example of adhesion improvement



※Degree of adhesion improvement varies greatly according to substrate.

Excimer Irradiation Units

EXCIMER

Features

World's first successful commercialization of this type of product

In 1993, excimer lamps were the first products launched by Ushio.

Cumulative shipment of 6,000 units

Focusing on the FPD industry, as of 2018 we have shipped a total of more than 5,000 units.

High market share

As a leading manufacturer of excimer lamps, we constantly work to advance research & development and to expand out lineup to meet the needs of our customers.

Collaboration / Open Innovation

For customers who are considering the purchase of our products, demonstration units may be loaned out, with a Application Laboratory Facilities available. Witnessed experiments or experiments using an customer provided sample can be conducted. Upon completing an experiment, we conduct analysis and assessment (XPS,FT-IR,FE/SEM etc), and then send an experiment report to each customer. Any customer interested in the above should submit an application from our Homepage or contact the Business Division.

For a witnessed experiment:
Inform us of the contents of the desired experiment or send/deliver a workpiece to us in advance. We will be able to start an experiment soon after you visit us.

For an experiment with an customer provided sample:
Inform us of the contents of the desired experiment in advance and send us a workpiece.



※Note that it may be difficult for us to satisfy certain customer requests depending on the contents of an experiment or analysis. For details, please contact us for further information in advance.

A rich light source lineup

We make a broad lineup of equipment, ranging from laboratory verification equipment to mass production facilities. We can propose customizations to meet individual customer requirements. With its outstanding productivity, the HP-V series enjoys a particularly high reputation.


- High cumulative exposure by wide, flat tube structure
- High radiation emittance by proprietary reflective film technology
- Covers widths of up to 3,400 mm with a single lamp

Achieves processing with minimal number of lamps. Contributes to CoO reduction.



Support Organization

Ushio Group provide support program such as spare parts sales, tool maintenance, relocation, modification or calibration. Customer service center in Japan collaborate with worldwide service office to provide quick and convenient support. We support preventing your tool from any troubles by proposing preventive maintenance program. Please use our support program for comfortable operation and optimization for market and technical needs change.



Excimer Irradiation Units

EXCIMER

Product Lineup

Surface light source for □100mm window size



Specifications		
Model	Atmosphere	放射発散度
SSP04A-***	Normal atmosphere	20mW/cm ² 以上
SSP04V-***	Vacuum	18mW/cm ² 以上
Utilities		
Electricity	Nitrogen	
AC100 or 200V 0.1kVA	4.5~5.5NL/min (purity of 99.99% or more)	

HPV-ST Series

Compact in size while maintaining the performance of the HPV series



STN Series



STA Series

Specifications			
Model	Process gas	Emission wavelength	Radiation divergence
STN3-***	Required	300mm	170W/cm ² or greater
STN5-***	Required	550mm	

※100V/200V specification for 300 mm width, 200V specification for 550mm width

Utilities			
Model	Process gas	Emission wavelength	Radiation divergence
STA3-***	Not required (air intake)	300mm	170W/cm ² or greater
STA5-***	Not required (air intake)	550mm	

※100V/200V specification for 300 mm width, 200V specification for 550mm width

Small experimental unit (for □100mm window)



Reference specifications	
Irradiation area	□100(mm)
Irradiation emittance	Over 20mW/cm ²
Irradiation distance (window to stage top)	4~25mm (When equipped with elevating mechanism)
Rough size (excluding protrusions and lighting power supply)	W250 × D500 × H325 (mm)
Utilities	
Electrical capacity	AC100V 0.3KVA
Cooling water (municipal supply)	—
Exhaust	0.1~0.2m ³ /min
Gas for lamp housing	N ₂ : 5~6NL/min
Gas for processing chamber	N ₂ : 0~50NL/min CDA : 0~1NL/min

SVM Series (Stage conveyor with material handling mechanism for large substrates)



Reference specifications	
Irradiation area	~730×920 (mm)
Irradiation emittance	Over 170mW/cm ²
Irradiation distance (window to stage top)	3~40mm
Rough size (excluding protrusions and lighting power supply)	—
Conveyor speed	0.5~5.0m/min

※ Approximate size and utilities vary according to unit size.
Please contact our sales representative for details.
※ Available with or without process gas (intake type)

Film Excimer Series (Horizontal conveyor type)

Provides 50% reduction in N2 flow rate. Allows control over oxygen concentration even during high-speed substrate handling.



Reference specifications	
Irradiation area	~width 1,500 (mm)
Irradiation emittance	Over 170mW/cm ²
Irradiation distance (window to stage top)	4mm (Adjustable)
Rough size (excluding protrusions and lighting power supply)	—

※ Approximate size and utilities vary according to unit size.
Please contact our sales representative for details.


Atmospheric Pressure Plasma Irradiation Device

Features


Atmospheric pressure plasma irradiator that combines high frequency power supply technology developed for excimer lamps with Ushio's unique reactor structure.



Example of COP (cyclic olefin polymer) hydrogenation




Change in contact angle of organic/inorganic materials



Low-temperature processing / low damage

Enabling low-temperature processing, effective for irradiating resins and film substrates that have low heat resistance
High cooling efficiency enables reactor cooling with process gas only



Long life and high reliability

- Reactor with a unique structure that is less affected by thermal expansion and more resistant to cracking
- Highly reliable high-frequency power supply with a total of more than 5,000 units shipped

	Direct discharge method	Ordinary DBD method	Ushio's original DBD method
Structure			
Efficiency	◎ Overwhelming advantage over DBD	△	○
Life	× Discharge continues as electrode is consumed	△ Dielectric cracks due to expansion coefficients of metal and dielectric	○ Structure less affected by expansion coefficient

※DBD : Dielectric Barrier Discharge



Spot UV Irradiation Units

Spot-Curing

Features

3 times more irradiance than before. Curing requires only 1/3 of the time!
High-power spot UV irradiation apparatus.

SP-11


Shorter curing time

Fewer devices


Improves adhesion




■ Broad spectrum of wavelengths increases irradiance to 3 times more than before
Curing time down to 1/3



■ High-level irradiance, requiring only half the number of apparatuses



■ Broad-spectrum light achieves deeper and more intense curing



Specifications

Model	SP11_275A
Light Source	Preset 275W UV lamp
UV irradiation	6500 mW/cm ² (previous: 4080mW/cm ²) [Conditions] Ushio fiber SF-101AQ, irradiation distance 15mm, Ushio intensity meter: UVD-S365 (photoreceptor ø1mm) [Remarks] SP11 UV wavelength measurement is limited with Ushio irradiator; use values as a guide. Curing speed is therefore faster with broad-spectrum curing provided with this apparatus depending on the work material.
Lamp life	2000 hours / 50% of initial UV irradiance
Shutter	Motor shutter timer/manual controllable Timer settings: 0.5 – 999s (0.1-s steps), 1000 – 9999s (1-s steps)
Weight	Approx 8.3kg

Lamp replacement One-touch system


No special tools/No optical axis adjustment

0-to-100% Light Control (Mechanica I Diaphragm)

Light can be controlled in increments of 1% from 0% to 100% by a light control system using a simple Mechanical diaphragm. The irradiance corresponds almost linearly to the scale value.




Appearance



External interface


D-sub 25PIN




Spot UV Irradiation Units

Spot-Curing

High illumination type



Radiation (irradiance) distribution



Intensity comparison by number of branches (referential value)

Fiber type: SF (φ5mm) No lens	Number of branches			
	1	2	3	4
Relative intensity	100%	85%	65%	50%

※For UIT250/UVD-S365 when the number of branches is 1, the length is 1m, and the power is 250W

Fiber Line-up


Optical fiber units can be selected based on number of branches, length, and radiation diameter to meet the features of a newly developed light source.

Standard Quartz Fiber Specifications

	Type SF
Fiber diameter	φ5mm
Number of branches	1~4
Fiber length	1m

※More than 4 branches are available.
※Other fiber diameters and lengths are also available by ordering.

Type SF



Options



Line fiber type UV irradiation unit

By combining with Ushio's unique optical design technologies, we can customize our products to suit your needs and all forms of lines.



Special optical fiber with uniform radiation lens


Special lens and special optical fiber enable an irradiation surface of from □ 30mm to □ 84mm.




Spot UV Irradiation Units

Spot-Curing

Standard type



Radiation (irradiance) distribution



Intensity comparison by number of branches (referential value)

Fiber type: AF No lens	Number of branches			
	1	2	3	4
Relative intensity	100%	90%	80%	60%

※With the UIT-250 when using 1 branch with a length of 1m and a 200/250W switchable main unit

Fiber Line-up


Optical fiber units can be selected based on number of branches, length, and radiation diameter to meet the features of a newly developed light source.

Standard Quartz Fiber Specifications

	Type AF
Fiber diameter	φ3.5mm
Number of branches	1~4
Fiber length	1m

※More than 4 branches are available.
※Other fiber diameters and lengths are also available by ordering.

Type AF



Standard-type AF fiber with “A”, “B”, or “P” tip lenses, each having a different radiation distance and radiation diameter, or with a fine lens that can easily access a narrow place.

Spot UV Irradiation Units

Spot-Curing



An eco-friendly Spot UV Curing System (LED-type) that maximizes energy conservation and hardening performance

Light head type UV curing system (SP-LED-3)


SP-LED-3

Compact, Light-weight Design

Industry No.1 for High-level Irradiance

Highly-affordable Pricing

■ Appearance



Specifications

■ General Body

Dimensions	W80mm×D148mm×H132mm
Weight	Approx. 1.2kg
Rated Voltage	100-240VAC±10% single-phase,50/60Hz
Power consumption	100% setting 37VA(0.37A at AC100V)
Air exhausts	0.2m3/min max
Operating environment	Temperature 0 to 40°C, Humidity 80% max
Strage environment	There should be no corrosive gas or dust, Water,oil,etc. shall not be spiashed directly Temperature 0 to 50°C, humidity 80% max (non condensing)
AC cable length	1.5m


■ Optical System

LED unit	1 unit (4 elements/4 branches)
LED unit expected life	20,000 hours
Initial peak illuminance	12,000mw/cm ² or more
Light head length	2m
Light intensity adjustment	0% to 100%: 1% step
Irradiation time setting	Timer setting 1 to 999 seconds (0.1 second step)
Head types	φ3, φ6, φ8, φ10


Signal terminal no.	Signal type	Signal content
Left no. 5	24V signal	Channel 1 output signal
Left no. 6	24V signal	Channel 2 output signal
Left no. 7	24V signal	Channel 3 output signal
Left no. 8	24V signal	Channel 4 output signal
Right no. 5	Power supply ground	Left side 5-8 common ground
Right no. 6	Relay common contact	Normally, Right 6 is shorted to Right 7; when error occurs, Right 6 is shorted to Right 8
Right no. 7	Relay normally close contact	
Right no. 8	Relay normally open contact	

Optical simulation


■ φ3mm lens




■ φ6mm lens



■ φ8mm lens



■ φ10mm lens



UV-LED

UV-LED

Product Lineup

Compared to lamps with a broad wavelength range, UV-LED lamps can irradiate at specific wavelengths, enabling low-temperature processing.

Can be turned off and on instantaneously, conserving electricity (approx. 75% reduction) and enabling pulsed lighting operation.

Enables long lamp life.

Makes it possible to propose products that include a lighting power supply and control unit.

Model Series										
Peak intensity		Air-cooling	Air-cooling	Air-cooling	Air-cooling	Air-cooling	Air-cooling	Air-cooling	Water-cooling	Water-cooling
Cooling method		~4.5W/cm²	~5.5W/cm²	~10.0W/cm²	~10.0W/cm²	~14.0W/cm²	~13.0W/cm²	~2.0W/cm²	~14.0W/cm²	~4.5W/cm²
Performance characteristic	WD-free		●				●			
	Connection optics		●	●	●					●
	High efficiency cooling					●			—	—
	Split lighting			●				●	●	
	LED board exchange			●	●	●	●	●	●	●
	Higher dosag			●		●	●		●	
	Wavelength Selectione		●	●	●	●	●			●
	Silent Design					●	●		—	—
	Compact and light weight		●	●		●			—	—
	LED driver integrated		●	●	●	●	●	●		●
	Exclusive power supply		※1	※1	●	●	●	●	●	※1

**WD-Free**
Equal Illuminance can be obtained at irradiation distances of 0 to 15 mm.

**Connecyion Optics**
When lamps are connected, there is no decrease in illuminance at the points of connection.

**High Efficiency Cooling**
High integrated light output is achieved with low power consumption through the use of high-efficiency cooling.

**Split Lighting Control**
Lighting can be split within a module.

**LED Board Exchange**
No need to return modules in case of trouble. Customers can replace LED boards on their own.

**High Dose Capability**
Model that provides industry's highest integrated light output in terms of size and power consumption.


**Wavelength Selection**
Selectable wavelengths from 365 to 405 nm.

**Silent Design**
High power, yet quiet due to optimal fan control.


**Compact and Light Weight**
Easy-to-use size and weight.

※1 Possible to propose with a single power supply.

UniJet lineup Irradiation and Dosage



UV-LED spectral distribution (reference values)



UV-LED

UV-LED

E Series



Air-cooling

Features

Significantly improved light distribution uniformity when modules are connected, with powerful specification despite palm-sized configuration. An entry-level UV-LED model that can be used in any situation.



Both HD and HC types are available

10%~100% dimmable


Scalable by edgeless design

Built-in LED driver


Specifications

E series (GEN2) Standard type		HD		HC	
		E075Sd HD	E110Sd HD	E075Sd HC	E110Sd HC
Window Size (mm)		75×17	108×17	76×φ10	109×φ10
Width (mm)		78	111	78	111
Length (mm)		33			
Height (mm)		134.5		143.2	
Peak Irradiance (W/cm²)	365nm	6.5 (WD=0mm) / 2.7 (WD=5mm) ※1		4.6 (WD=10mm) ※1	
	385nm	10 (WD=0mm) / 4.2 (WD=5mm) ※1		6.5 (WD=10mm) ※1	
	395nm				

※1 Reference value based on measurement by USHIO. ※ A single power supply is also available as an option.




HD Type (High Dose)



High dose energy is suitable for inkjet printing as well as applications that requires quick UV curing demand.




HC Type (High Condensing)



High condensing UV by optical rod lens is suitable for long distance / narrow curing area.



Modules can be connected



Specifications

E series (GEN2) High power type		HD		HC	
		E075Hi HD	E110Hi HD	E075Hi HC	E110Hi HC
Window Size (mm)		75×17	108×17	76×φ10	109×φ10
Width (mm)		78	111	78	111
Length (mm)		33			
Height (mm)		134.5		143.2	
Peak Irradiance (W/cm²)	365nm	5.4 (WD=0mm) / 3.8 (WD=5mm) ※1		4.2 (WD=5mm) ※1	
	385nm	7.5 (WD=0mm) / 5.4 (WD=5mm) ※1		6.1 (WD=5mm) ※1	
	395nm				

※1 Reference value based on measurement by USHIO. ※ A single power supply is also available as an option.

UV-LED

UV-LED

iC Series

Features

Sufficient illuminance and integrated light output to meet basic productivity requirements for various photosensitive resins. In addition, this basic model is easy to use, particularly in terms of size and air intake/exhaust requirements.



High irradiance:
Up to 13.5W/cm²

Smallest widely
used 10W/cm²
model
in the world


10%~100%
dimmable

Scalable by
edgeless design

Built-in
LED driver

Replaceable
UV-LED board

■ i225C



Specifications

iC series		i075C	i150C	i225C	i130C	i375C
Window Size (mm)		73×29	148×29	223×29	289×29	373×29
Width (mm)		78	152	227	302	377
Length (mm)		60				
Height (mm)		230				
Peak Irradiance (W/cm ²)	365nm	9.0 (WD=0mm) / 7.0 (WD=5mm) ※1				
	385nm	12.5 (WD=0mm) / 10.0 (WD=5mm) ※1				
	395nm	13.5 (WD=0mm) / 11.0 (WD=5mm) ※1				

※1 Reference value based on measurement by USHIO.

iIV Series

Features

Air-cooled model with integrated light output that “far exceeds that of water-cooled models.” This is our flagship model, which we recommend for use in environments where curing cannot be achieved by conventional UV-LEDs.



Achieves high
irradiation of
up to 15W/cm²

Achieved approx.
240% increase
of dosage than
iII series

25%
more compact
than iIII

25% lighter
than iIII


Quiet design

15%~100%
dimmable

Built-in
LED driver

Replaceable
UV-LED board

■ i075iV



Specifications

iIV series		i075iV	i150iV	i225iV	i130iV	i375iV	i450iV	i525iV
Window Size (mm)		75×52	150×52	225×52	300×52	375×52	450×52	525×52
Width (mm)		77	152	227	302	377	452	527
Length (mm)		136						
Height (mm)		256.4						
Peak Irradiance (W/cm ²)	365nm	10.5 (WD=0mm) / 10.0 (WD=5mm) ※2						
	385nm	13.0 (WD=0mm) / 12.5 (WD=5mm) ※2						
	395nm	15.0 (WD=0mm) / 14.0 (WD=5mm) ※2						

※1 Available for 395nm ※2 Reference value based on Ushio measurement.

UV-LED

UV-LED

i III Series



Features


This model is designed for customer ease of use, providing quiet operation along with high power and working distance flexibility.



Specifications

iIII series		i075III	i150III	i225III	i300III	i375III	i450III	i525III	i600III	i675III	i750III
Window Size (mm)		75×40	150×40	225×40	300×40	375×40	450×40	525×40	600×40	675×40	750×40
Width (mm)		77	152	227	302	377	452	527	602	677	752
Length (mm)		136									
Height (mm)		270									
Peak Irradiance (W/cm ²)	365nm	9.0 (WD=0mm) / 7.0 (WD=5mm) ※2									
	385nm	12.5 (WD=0mm) / 10.0 (WD=5mm) ※3									
	395nm	13.5 (WD=0mm) / 11.0 (WD=5mm) ※3									

※1 Available for 385nm and 395nm. ※2 Reference value based on measurement by Ushio. ※3 Reference value based on measurement by Ushio at 395nm.



i II R Series



Features


This model is equipped with a mirror unit that enables uniform UV irradiation over a wide area.



Specifications

iIIR series		i185IIR	i245IIR	i310IIR	i185IIR-2	i185IIR-2	i185IIR-2
Window Size (mm)		184.8×69	246.6×69	307.4×69	372.2×69	395.8×69	619.4×69
Width (mm)		228.6	290.4	252.2	420.8	544.4	668
Length (mm)		305.6					
Height (mm)		103.5			113.5		
Peak Irradiance (W/cm ²)	385nm	1.5 (WD=10mm) ※1					

※1 Reference value based on measurement by Ushio.



A Series



Features


This water-cooled, high-illumination model is ideal for environments that are not suitable for air-cooled systems.



Specifications

A series		A180	A270	A360	A450	A540
Window Size (mm)		180×26	270×26	360×26	450×26	540×26
Width (mm)		230	320	410	500	590
Length (mm)		80				
Height (mm)		111.5				
Peak Irradiance (W/cm ²)	385nm	Full : 16.0 (WD=0mm) / 14.0 (WD=5mm) ※1 Half : 8.0 (WD=0mm) / 7.0 (WD=5mm) ※1				

※1 Reference value based on measurement by Ushio.



Power supply for UV-LED air cooling

Features

- Fine irradiation control with 200 dimming levels: Digital display enables reproduction of dimming values
- All-in-one structure with power supply and enables single-unit control. (Separate type is also available.)
- Error signals are output from the irradiation device's built-in IF board
- Compact design requires little space for installation
- For retrofits, three levels of control signals can be input for remote dimming control.



i/II/IIR/C/III/IIV Series-specific power supply

Specifications

External dimensions	Width (mm)	400
	Length (mm)	616
	Height (mm)	150
Power supply capacity※1		180–240 V AC single phase + 1G, 50/60Hz, 2.9 kVA
Remote operation		Irradiation on/off, 3-step dimming control (H, M, L) 0–10 V dimming control
Local operation		Operation from touch panel On/Off, dimming Total irradiation time display, Error display
External Interface		On/off command, Dimming control (0–10V, dimming rate 10–100%), RS485 serial communication
Displa		Remote local error Cumulative irradiation time Language selection (Japanese/English)

※1 Power supply specifications vary depending on the length of the irradiation width. Please contact our sales representative for details.
※2 H, M, L dimming control voltages can be set independently from each other through the touch panel in the range of 0 to 10 V.

Continually Striving for Optimum Light


Striving for the satisfaction of each individual customer,
Ushio provides "light support" services according to needs and objectives.

“Ushio Light” has long been used both for illumination and as energy.

As light professionals, we provide support services for light that best suits your needs and objectives as we strive to satisfy each and every one of our customers.

Please take advantage of Ushio’s support services to ensure that you continue to use your “Ushio Light” with peace of mind after your purchase, and to ensure that your “Ushio Light” is optimally suited to your sometimes changing circumstances.

Support Flow



Support Program

Calibration of Optical Measuring Instruments
USHIO calibrates light measuring instrument sent to designated facilities under an ISO9001-based quality control system.

Repairs
We perform repairs of products sent to our designated repair facilities. We can also provide overhauls and substitutes as needed.

On-site Repair
Our service personnel visit customer sites to make repairs or restore devices.

Shipment of Maintenance Parts
We select and ship needed replacement parts. In some cases, we can visit customer sites to install such parts.

Periodic Inspection and Maintenance
Periodic inspection is recommended to ensure safe operation of equipment. During periodic inspection, we evaluate equipment performance and the condition of consumable items and component wear.

Others
We provide services according to customer needs, such as relocation and modification of equipment. Please feel free to contact us.

Customer Support Center

6409 Moto-Ishikawa-cho, Aoba-ku, Yokohama-shi Kanagawa 225-0004

Reception Hours 9:00-17:00
(excluding weekends and holidays)

Mail
techsup@ushio.co.jp

TEL
+81 45-901-2509

FAX
+81 45-901-2607

※A charge is assessed for this service. Means of account settlement, and return shipping location and method must be arranged in advance.
※Applies only to products of Ushio INC. or companies who are members of the Ushio group.

Supported Products

Please feel free to contact us regarding products or services not listed. We look forward to serving you.

1. Lithography tools
2. TAB exposure system
3. ODF;UV Irradiation Equipment for One Drop Fill
4. UV curing system
5. Spot UV curing equipment
6. UV photoresist curing systems
9. Excimer irradiation unit
10. Light measurement instruments