## **TC Wall Port Installation Guide**

The TC Wall Port is designed to be used with an external thermocouple temperature probe with mini-plug.

To install, firstly attach the probe sensor to the object you wish to monitor using a TAPS adhesive pad or similar tape. Run the probe wire to a convenient position (probes are available from 1-20 metres in length). Fix the Wall Port back panel to the wall using the slotted screw holes provided, or suitable adhesive tape.



Next, plug the probe wire into the socket in the BACK of the face plate as shown below ensuring the neck of the plug sits in the aperture in the face plate (see below)



Now fix the face plate to the back plate using the screws provided. Connect your thermocouple thermometer to the port using a plug-to-pug cable and read the temperature.



Parts List		
Allied Part Number	RS Part Number	Description
KA01	409-4908	K Type Thermocouple Fine Wire Probe (1m)
KA01-3	479-1788	K type Thermocouple Fine Wire Probe (3m)
KM07	788-7144	K Type Thermocouple Immersion Probe
KMPC1MP	788-7122	Coiled Connection Cable 1m Length
MM2008	204-8413	Thermocouple Legionella Thermometer
MM7010	204-8412	Thermocouple Logging Thermometer
MM7000-2D	204-8411	Thermocouple Barcode Scanning Logging Thermometer