

Tools Needed: 2.5mm, 4mm, and 5mm Hex Key

..kuat..
(koo-at)

NOTE: 2-Bike Transfer with driver side disassembly shown below, disassembly is equivalent for passenger side and all Transfer series racks.

1. Rotate the rack into the trailer position as shown below.

NOTE: Ensure the pivot latch bar has fully engaged the pivot bracket before proceeding.

2. Remove the m4 bolt and m6 bolts retaining the end cap and tire cradle with puck; now slide off the components.

TIP: Make a note of the tire cradle position to maintain bike position after reinstalling.

3. Remove the m6 bolts retaining the hinge and hinge arm; then remove the arm and slide the hinge off the rack.

4. Install the new hinge with the provided hardware, being careful not to overtighten any bolts.

5. Reinstall the remaining components in the reverse order of removal, making sure not to overtighten the remaining hardware.

