

# Using and Calibrating Thermometers

## Purpose

To prevent foodborne illness by ensuring that the appropriate type of thermometer is used to measure internal product temperatures and that thermometers used are correctly calibrated for accuracy.

## Scope

This procedure applies to foodservice employees who prepare, cook, and cool food.

## Key Words

Thermometers, Calibration

## Instructions

1. Train foodservice employees on using the procedures in this SOP.
2. Follow State or local health department requirements.
3. Follow the food thermometer manufacturer's instructions for use. Use a food thermometer that measures temperatures from 0°F (-18 °C) to 220°F (104 °C) and is appropriate for the temperature being taken.
  - a. For example:
    - i. Temperatures of thin products, such as hamburgers, pizza, and sausage patties, must be taken with a thin probe. Always take the temperature in the thickest part of the food.
    - ii. Bimetallic, dial-faced stem thermometers are accurate only when measuring temperatures of thick foods. They may not be used to measure temperatures of thin foods. A dimple mark located on the stem of the thermometer indicates the maximum food thickness that can be accurately measured.

- iii. Use only oven-safe, bimetallic thermometers when measuring temperatures of food while cooking in an oven.
4. Have food thermometers easily-accessible to foodservice employees during all hours of operation.
5. Clean and sanitize food thermometers before each use. Refer to the Cleaning and Sanitizing Food Contact Surfaces SOP for the proper procedure to follow.
6. Store food thermometers in an area that is clean and where they are not subject to contamination.

## Monitoring

1. Foodservice employees will use either the ice-point method or boiling-point method to verify the accuracy of food thermometers. This is known as calibration of the thermometer.
2. To use ice-point method:
  - a. Insert the thermometer probe into a cup of crushed ice.
  - b. Add enough cold water to remove any air pockets that might remain.
  - c. Allow the temperature reading to stabilize before reading temperature.
  - d. Temperature measurement should be 32°F (+2°F) [or 0°C (+1°C)].
  - e. If not, adjust according to the manufacturer's instructions.
3. To use boiling-point method:
  - a. Immerse at least the first two inches of the probe into boiling water.
  - b. Allow the temperature reading to stabilize before reading temperature.
  - c. Reading should be 212°F (+2°F) [or 100°C (+1°C)]. This reading may vary at higher altitudes.
  - d. If adjustment is required, follow the manufacturer's instructions.
4. Foodservice employees will check the accuracy of the food thermometers:
  - a. At regular intervals (at least once per week)
  - b. If dropped
  - c. If used to measure extreme temperatures, such as in an oven

- d. Whenever accuracy is in question

### Corrective Action

1. Retrain any foodservice employee found not following the procedures in this SOP.
2. For an inaccurate, bimetallic, dial-faced thermometer, adjust the temperature by turning the dial while securing the calibration nut (located just under or below the dial) with pliers or a wrench.
3. For an inaccurate, digital thermometer with a reset button, adjust the thermometer according to the manufacturer's instructions.
4. If an inaccurate thermometer cannot be adjusted on-site, discontinue using it, and follow manufacturer's instructions for having the thermometer calibrated.
5. Retrain employees who are using or calibrating food thermometers improperly.

### Verification and Record Keeping

- Foodservice employees will record the calibration temperature and any corrective action taken, if applicable, on the Thermometer Calibration Log each time a thermometer is calibrated.
- The foodservice manager will verify that foodservice employees are using and calibrating thermometers properly by making visual observations of the employees during the calibration process and all operating hours.
- The foodservice manager will review and initial the Calibration Log daily. The Calibration Log will be kept on file for a minimum of 3 years.
- The foodservice manager will complete the Food Safety Checklist daily. The Food Safety Checklist is to be kept on file for a minimum of 3 years.

Date Implemented \_\_\_\_\_ By \_\_\_\_\_

Date Reviewed \_\_\_\_\_ By \_\_\_\_\_

Date Revised \_\_\_\_\_ By \_\_\_\_\_