

USER'S MANUAL



Respirator Fit Tester and Software

For Windows[™] 2000 and XP and Vista

For help visit our web site or call: http://www.ohdusa.com 1-205-980-0180 1-888-464-3872

Quantifit and Fitrack[™] are registered trademarks of Occupational Health Dynamics. Windows[™] is a registered trademark of the Microsoft Corporation.

Contents

1. General Information

Safety Considerations	7
The Quantifit and Its Features	8
Introduction	8
Quantifit Features	9
Accessories	
Standard Accessories	
Optional Accessories	
-	

2. Set Up

Front Panel Controls	11
Optical Sensor Knob.	
Front Panel Push Buttons	
Front Connections	13
Rear Connections	13

3. Operating Instructions

Preparing the Quantifit for testing	15
Daily Calibration	17
Interfacing with the Respirator	17
Performing a Fit Test	
Quantitative Fit Test Overview	19
Procedure	19
Protocol	19
Fit Factor	
Getting Started	21
Power-On and Menu Navigation	
Using the Optical Sensor Knob and Keyboard	
Preparing the Respirator for Fit-Testing	
Instructing the Test Subject	

4. Test Menu

Pre-Test	23
Introduction	23
Challenge Pressure	24
Respirator Mask Pressure	
Pre-Test Parameters	
Explanation of parameters:	25
Running the Pre-Test	
Pre-Test Results	
Repeat the Pre-Test	28
Fit Factor	
Leak Rate	
Test Time	29
Test-Q	
Additional Parameters	
Challenge Pressure	
Modeled Breathing Rate	

15

23

11

	Test Results	
5. Ec	dit Protocol Menu	39
	Introduction	
	Edit Protocol Menu	
	Test Parameters	41
6. Sy	ystem Menu	43
	Introduction	
	Set Clock	
	System Reset	
	Dual Tube Calibration	
	Zero Pressure	
	Edit Name	
	System Setup Datalog	
7 +	tility Menu	53
/. Ul		
	Introduction	
	Speaker Test	
	Keyboard Test	
	Display Test Printer Test	
	View Cycle Count	
	Factory Protocol	
	Print Help File	
8. Fit	tTrack Software	55
	Introduction	
	WARNINGS!	
	Getting Help	
	While you Work	
	Technical Support	
9. Ins	stalling and Removing FitTrack	57
	Requirements	
	Installing FitTrack	
	Removing FitTrack	
	Installing the Quantifit Driver	
10. R	Running FitTrack	61
	Starting FitTrack for the First Time	
	Starting FitTrack for Normal Operation	64
11. S	System Database Functions	67
	Database Utilities	67
	Synchronizing the FitTrack Database	
	Backing Up the FitTrack Database	

...39 ...41

43

53

Quantifit User's Guide

Contents • iii

Setting-up the Quantifit	
Connecting the Quantifit TM	
Communications Settings	
Updating Instrument Information	
Selecting a Quantifit	
Adding a New Quantifit to the Instrument Menu	
Deleting a Quantifit from the Instrument Menu	

13. Wo

Modifying an Existing Protocol	79
Deleting a Protocol	
Editing Protocol Steps	
Updating Respirator Data	
Creating a New Respirator Type	
Modifying an Existing Respirator Type	
Deleting a Respirator Type	
Sorting Respirator Type	
Printing a Respirator Summary	80
Changing User Options	
Quick Test Mode	
Safe Mode	81
Show Tips	81
Working with Company/Locations	
Creating a New Company/Location	
Opening an Existing Company/Location	
Closing a Company/Location	
Deleting Company/Location Information	
Updating Company/Location Information	
Updating Personnel Information	
Creating a New Record	
Modifying an Existing Record	
Deleting a Record	
Using Query to Filter Records	
Using Find and Find Next to Locate a Record	
Sorting Personnel Records	
orking with the Quantifit	87
Setting-up the Quantifit	

Importing from Excel Spreadsheet (Incremental)71 Importing Quantifit Data Into FitTrack71

Change Password75

Explanation of Calculation Method......77

12. Modifying System Data

Quantifit User's Guide	

16. Troubleshooting

Modifying a Quantifit	
Retrieving Calibration Data	
Reset Pump	

14. Performing a Fit Test

Selecting Test Information	91
Selecting Personnel Information	91
Selecting a Respirator	
Selecting a Protocol	
Selecting a Quantifit	
Running a Protocol Test	
Using Run Step	
Using Auto Step	
Using Auto Save (preferred method)	
Viewing Intermediate Test Results	
Adding Notes Regarding a Test	
Saving Protocol Test Results	
Saving & Printing Protocol Test Results	94
Performing a Pre-Test	
Viewing Test Results	
Viewing Test Results	
Viewing Test Result Details	
Manually Entering Test Results	
Adding Test Results	
Deleting Test Results	96

15. Report Generation

Printing the Company/Location Summary97Printing the Protocol Summary98Printing the Respirator Summary98Printing the Instrument Summary98Printing the Calibration Summary98Printing the Calibration Summary99Printing the Personnel Summary99Printing the FitTest Summary99Printing the FitTest Log.99Printing the FitTest Log.99Printing the FitTest Log.99Printing the Contract Certification Card100Printing the FitTest Certification Card101Printing the Company/Location Detail101Printing the Respirator Detail101Printing the Respirator Detail101Printing the Calibration Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the Respirator Detail101Printing the FitTest Detail102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104Custom Designed Reports104	Printing Summary Reports	
Printing the Respirator Summary98Printing the Instrument Summary98Printing the Calibration Summary98Printing the Personnel Summary99Printing the FitTest Summary99Printing the FitTest Log99Printing the Outstanding Test Summary100Printing the Fit Test Certification Card100Printing the Company/Location Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Personnel Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing the Seports102Filtering Reports102Filtering Reports103Printing the FitTest Report Text104Printing Options104Printing Options104Print to Window104	Printing the Company/Location Summary	97
Printing the Instrument Summary.98Printing the Calibration Summary.98Printing the Calibration Summary.99Printing the Personnel Summary.99Printing the FitTest Summary.99Printing the FitTest Log.99Printing the Outstanding Test Summary.100Printing the Fit Test Certification Card100Printing Detail Reports101Printing the Company/Location Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Personnel Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing the Respirator Detail101Printing the FitTest Detail101Printing the FitTest Detail102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Protocol Summary	
Printing the Calibration Summary98Printing the Personnel Summary99Printing the FitTest Summary99Printing the FitTest Log99Printing the FitTest Log99Printing the Outstanding Test Summary100Printing the Fit Test Certification Card100Printing the Company/Location Detail101Printing the Respirator Detail101Printing the Respirator Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Respirator Summary	
Printing the Personnel Summary99Printing the FitTest Summary99Printing the FitTest Log99Printing the Outstanding Test Summary100Printing the Fit Test Certification Card100Printing the Fit Test Certification Card101Printing the Company/Location Detail101Printing the Protocol Detail101Printing the Respirator Detail101Printing the Calibration Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Instrument Summary	
Printing the FitTest Summary.99Printing the FitTest Log.99Printing the Outstanding Test Summary.100Printing the Fit Test Certification Card100Printing Detail Reports101Printing the Company/Location Detail101Printing the Protocol Detail101Printing the Respirator Detail101Printing the Calibration Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Printing the FitTest Detail102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text.104Print to Window104	Printing the Calibration Summary	
Printing the FitTest Log99Printing the Outstanding Test Summary100Printing the Fit Test Certification Card.100Printing Detail Reports.101Printing the Company/Location Detail.101Printing the Protocol Detail.101Printing the Respirator Detail.101Printing the Quantifit Detail.101Printing the Calibration Detail.101Printing the Personnel Detail.101Printing the FitTest Detail.101Printing the FitTest Detail.101Printing the FitTest Detail.102Filtering Reports.102Sorting Reports.103Printing Options.104Customize FitTest Report Text104Print to Window.104	Printing the Personnel Summary	
Printing the Outstanding Test Summary.100Printing the Fit Test Certification Card100Printing Detail Reports101Printing the Company/Location Detail101Printing the Protocol Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Calibration Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing Reports102Filtering Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the FitTest Summary	
Printing the Fit Test Certification Card100Printing Detail Reports101Printing the Company/Location Detail101Printing the Protocol Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing the FitTest Detail101Printing Reports102Filtering Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the FitTest Log	
Printing Detail Reports101Printing the Company/Location Detail101Printing the Protocol Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Outstanding Test Summary	
Printing the Company/Location Detail101Printing the Protocol Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Fit Test Certification Card	
Printing the Protocol Detail101Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing Detail Reports	
Printing the Respirator Detail101Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Company/Location Detail	
Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Protocol Detail	
Printing the Quantifit Detail101Printing the Calibration Detail101Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Respirator Detail	
Printing the Personnel Detail101Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104		
Printing the FitTest Detail101Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Calibration Detail	
Filtering and Sorting Reports102Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the Personnel Detail	
Filtering Reports102Sorting Reports103Printing Options104Customize FitTest Report Text104Print to Window104	Printing the FitTest Detail	
Sorting Reports 103 Printing Options 104 Customize FitTest Report Text 104 Print to Window 104	Filtering and Sorting Reports	
Printing Options	Filtering Reports	
Customize FitTest Report Text	Sorting Reports	
Print to Window104	Printing Options	
	Customize FitTest Report Text	
Custom Designed Reports	Print to Window	
	Custom Designed Reports	

105

Test Measurements	105

Contents • iv

91

Large Leak	
Erratic Mask Pressure	
Consistently Low Fit Factors	
Rapid or Erratic Graph Movement	
OTHER PROBLEMS	
DAILY CALIBRATION	
What do I do when people are not passing a fit test?	
Claims	
Standard Terms and Conditions	
Warranty	
·	

Index

114

Last Revision to this manual: October 6, 2008

CHAPTER

1. General Information

In this chapter you will learn how to use this manual, where to get help, and about the Quantifit features and specifications.

Safety Considerations

The instrument and related documentation must be reviewed for familiarization with safety markings and instructions before you operate the instrument.

Warning

The WARNING! Sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a WARNING! Sign until the indicated conditions are fully understood and met.

Caution

The CAUTION Sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the instrument or data. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.

Manual Addenda

Information concerning improvements or changes to the instrument that occur after the printing of this manual will be on an addendum sheet included with the manual. Be sure to review these changes before attempting to operate or service the instrument.

The Quantifit and Its Features

Introduction

The Quantifit measures...

Face-to-facepiece fit of a respirator. With a perfect respirator and fit, all inhaled air is forced through the filter system, thereby providing maximum respiratory protection for the individual. If the face-to-facepiece seal leaks, unfiltered air bypasses the filter system and enters the individual's lungs during inhalation, thus reducing respiratory protection.

By design, a respirator should prevent contaminated air from entering the lungs of the individual wearing it. If the respirator is in good working order, the only way contaminated air can enter the individual's lungs is through a leak in the face-to-facepiece seal. The Quantifit measures face-to-facepiece seal leakage and then calculates the fit factor (FF) of the respirator being tested.

The Quantifit uses...

The patented Controlled Negative Pressure (CNP) technology. A fit test adapter replaces the filter cartridge and inhalation valve on the respirator.* The individual under test dons the respirator (in accordance with Association National Standards Institute [ANSI] guidelines or manufacturer's instructions), takes a breath, holds the breath, presses the trigger button, and begins the test.

* The inhalation valve must be removed or propped open for the fit test.

The Quantifit functions by...

Creating and maintaining a negative pressure in the respirator mask. This process lasts 8 seconds. Once the adapter valve is closed by pressing the trigger button, sealing the respirator mask, the Quantifit removes air from the respirator mask until the challenge pressure is reached.

At this point, if there isn't a leak, the Quantifit doesn't remove any more air from the respirator mask. If there is a leak, air enters the respirator mask, and the pressure rises. The Quantifit then removes air from the respirator mask until the challenge pressure returns. This process continues for 8 seconds, and then the test ends. The individual under test releases the trigger button and breathes normally.

During the fit test, the Quantifit measures exactly how much air it removed from the respirator mask after reaching the challenge pressure. This measurement is used by the Quantifit to calculate the leak rate.

The Quantifit has two types of protocols: Standard protocols with fixed challenge pressures and modeled breathing rates; and Custom protocols with challenge pressures and modeled breathing rates determined by user defined parameters, including work rate, mask cartridge type, mask size, and subject gender.

Challenge pressure, expressed in hundredths of inches of H_20 , is the maximum partial vacuum created in a correctly fitting mask when the user is working at a typical rate. The modeled breathing rate is the calculated total inspiration for 1 minute.

The modeled breathing rate (in liters per minute [LPM]) is multiplied by 1000 to provide cubic centimeter and then divided by the leak rate (in cubic centimeters per minute [cc/min]) is the fit factor ratio. This is a ratio of the total air inhaled to the contaminated air inhaled.

The Quantifit follows...

A set procedure, or a protocol. Each protocol consists of 1 to 12 steps (a step is either a fit test or an exercise).

Quantifit Features

If you don't have a quantitative fit-testing program, the Quantifit helps you start one. Or, if you do have a quantitative fit-testing program, the Quantifit integrates easily into your present program.

These features make the Quantifit simple to use:

- Doesn't require a personal computer and may be used with keyboard and optional printer.
- On-board data storage
- USB Thumb drive data transfer
- Interfaces with personal computer USB ports
- Updates are done by the end-user with an easy internet download
- User prompts that make the instrument easier to use than ever, including self testing.
- Doesn't require an invasive probe.
- Doesn't use messy challenge agents or alcohol.
- Reduces test time compared to other quantitative fit-test systems.
- Directly measures leakage flow-the primary measure of respirator fit.
- Tests workers in the actual respirator masks they wear in the workplace.
- Displays individual test measurement results including Fit Factor, Leak Rate, Test Time, Test-Q (Test Quality), Challenge Pressure, Modeled Breathing Rate, and Minimum Passing Fit Factor.
- Displays and prints overall fit-test protocol results including Average Percent Leak, Equivalent Fit Factor, Test Date, Test Time, Test Parameter Values, and a step-by-step summary of the protocol.

- Meets OSHA and CSA fit-testing protocol requirements.
- Offers two custom protocols that can be created and stored in nonvolatile memory.
- Displays menu-selectable commands.
- Provides a comprehensive "Help" program that is available at the touch of a button.
- Outputs test results to the display (LCD display), an external printer, or a database.
- Minimizes cross-contamination (air extracted from the mask exits through the "EXHAUST" port, located on the back of the instrument).

Accessories

Standard Accessories

Description	Part Number
USB Keyboard	9530-4003
USB Computer Cable	3010-4002
Universal Power Cord	3010-4001
Triple Tube Assembly	9503-4003
Trigger Button	3010-4000
User Manual	3010-0208
FitTrack Software	3010-2019
Rigid Carrying Case	9530-4001

Optional Accessories

Description	Part Number
Adapters	9513-XXXX
Printer	9503-4002
Laminator Kit	FTK PL4A PKG

CHAPTER

2. Set Up

In this chapter you will find information about setup and external connections for the Quantifit.

Front Panel Controls

Front View of Quantifit





Optical Sensor Knob

The Optical Sensor Knob is used for navigation within the Quantifit menu structure. The knob can be turned clockwise or counter-clockwise to move forward or backward through the menu selections. When the appropriate selection is highlighted, push on the Optical Sensor Knob to accept the menu selection.

To use the Optical Sensor button to go back to the previous screen, the user would need to turn the button counter-clockwise until "Exit" is highlighted. Then the user would press on the knob to exit out to the previous menu.

Front Panel Push Buttons



Seal Check

The Seal Check button can be pressed to perform a user-seal check. When the subject has properly donned the respirator and wishes to do a user-seal check, he or she may press the Seal Check button to close off air flow while inhaling to determine if the subject can identify a leak in the respirator. The subject can press the Seal Check button while inhaling, and hold his or her breath for 10 seconds. When the Seal Check button is released, the subject should feel the mask move away from the face as the pressure is released. If this does not occur, this would indicate that the mask leak was so significant that the pressure could not be held for the 10 seconds.

Back

The Back button may be used to back up one step in the menu structure. This button works in the same manner as the back button in an internet web browser. If the user is several levels deep within the menu structure, the back button will bring the user to the previous screen.

Home

The Home button may be used to bring the user back to the start-up screen of the Quantifit. Regardless of where the user is, he or she can press the Home button to return to the start-up screen. If this button is pressed during a test or after data input, the user will be asked to confirm that they want to escape the current position and not save the current data.

Help

The help menu may be used to view further details or instructions when the user needs further assistance. Navigate through the help menu by using Optical Sensor Knob. Scroll to the appropriate subject and press on the knob to enter the subject information.

Front Connections



The connectors located on the front of the instrument will be used during calibration and testing.

Flow, Pressure and Valve

These connectors are used for the Triple Tube. The flow will accept the only male connector. The Pressure connector will take the clear female connector, and the Valve port will take the connection on the blue tube.

Trigger

The Trigger connection will be used for the hand-held trigger button that sets each test in motion.

Rear Connections



On-Off Switch

The On-Off Switch functions like a standard power switch. Toggle to the left (-) and the power is turned off. Toggle to the right (o) and the power is turned on.

9 VDC, 5A (Power) Connection

The power connection is to supply power to the unit, and the universal power supply that was shipped with the Quantifit must be used. Take care to be sure that the flat end of the cable is facing up when connecting the power cord. Do not force the cord into place as this may result in damage to the unit.

Dual Tube Cal Ports

During the instrument's daily calibration, the clear tubing sides of the Triple Tube will be connected to these ports. These ports are interchangeable, therefore, it does not matter which tube gets connected to which port. Do not connect the blue tube to this port, this will result in a failure of the daily calibration.

Exhaust Port

This port exhausts air out of the unit during normal operation. This port is also used during factory calibration and should not be tampered with by the user.

USB PC Port



The USB PC Port is used to connect the Quantifit to a PC. The Quantifit is shipped with a supplied cable for this purpose. The USB symbol (see image at left) on the cable must face up to properly insert this cable. This cable allows for the Quantifit to be operated from the supplied software. This cable may also be used to upgrade the firmware of the Quantifit.

USB Devices (2)

The two standard USB ports may be used to connect the USB Keyboard and the optional printer. These ports are interchangeable and may be used for either of these devices. The top port (only) may be used to connect a flash drive or memory stick to download testing data. Please note that this will only work on the top USB port.

Printer Compatibility Information

To use a printer directly connected to the Quantifit, only approved printers may be used. Those printers include all Hewlett Packard (HP) Deskjet printers with a USB connection. If the tests are being performed via a personal computer and FitTrack software, any Windows-compatible printer may be used.

3. Operating Instructions

In this chapter you will find information about menu options and preparing the Quantifit for testing.

Preparing the Quantifit for testing

1. Location

- Use a room that permits spoken communication between the operator of the Quantifit and the test subject.
- Place the Quantifit on a table large enough to also accommodate a printer, keyboard and accessories, while allowing room for two seated persons.

2. Printer and Keyboard Connections

- Turn the power off to both the printer and the Quantifit.
- Connect the printer and keyboard to the Quantifit through the USB Ports on the back of the unit. Plug the square end of the printer cable into the printer.
- Turn on the power to the Quantifit.
- Turn printer power on.

NOTE: Refer to Connecting the Printer for printer compatibility and connector specifications.

- If you wish to use FitTrack software to operate the Quantifit, use the supplied USB cable.
- The square end of the cable goes into the USB PC port.
- The flat end of the cable goes to a USB port on your PC.

4. Test Adapters

- Replace the respirator's filter cartridge (or cartridges) with the appropriate test adapter (or adapters).
- Be sure to prop open or remove the inhalation valve from the mask.

5. Triple Tube & Trigger Button Connections

- First, attach the triple tube assembly (Part # 9503-4003) to the front of the Quantifit. Use the end of the dual tube assembly that has one male quick-disconnect adapter to connect to Flow, use the clear female connector to connect to Pressure, and the blue female tube to connect to Valve.
- Connect the Trigger Button by inserting the quarter-inch connector into the Trigger port.

Daily Calibration

At the beginning of each day, if the Daily Calibration has not been performed, the instrument will prompt the user to do the calibration. It is recommended that the daily calibration be performed before each day of testing. This calibration assures the user not only that the Quantifit is working properly, but that it is also measuring leak within the specified tolerance.

Zero the Sensor

The Quantifit will first prompt the user to zero the sensor of the instrument. In order to do this step, the user must disconnect the Triple Tube from the front of the instrument and press on the Optical Sensor Knob to zero the sensor.

Daily Calibration

For the next step, the instrument will prompt you to connect the Triple tube to the front of the instrument, and then to connect the two ends of the clear tubing to the back of the instruments on the Dual Tube Cal ports. When connecting to these Cal ports, it does not matter which side each tube is connect to, as they are interchangeable.

When the tubes are properly connected, push in the Optical Sensor Knob to "Proceed." The Quantifit will send various flow rates through the instrument to make sure that the measurement of each flow rate is within the accepted tolerance. When the calibration is completed, the Quantifit will confirm that the instrument has passed the calibration requirements. If for some reason the Quantifit should fail this calibration, the user will see an error message to describe the reason for failure. The user should check all connections to make sure they are secure. If the Quantifit does fail calibration, it will be necessary to contact OHD.



Interfacing with the Respirator

The OHD test adapters provide mechanical connections between respirator masks and the Quantifit. Two types of test adapter kits are used:

Single Piece Adapter

On the single piece adapter, the two clear tubes are connected to the side of the adapter, and the blue tube is connected to the single adapter located at the front of the adapter.

Two Piece Adapters

When using the two-piece adapters, the clear tubes are connected to the adapter piece that contains the two connector ports, and the blue tube is connected to the piece with the single port.

Performing a Fit Test

(See "Running a Protocol," page 34, for complete instructions.) To perform each of the five steps of a fit test protocol, the test subject takes a comfortable breath and holds it, and then presses the trigger button to begin the test. The trigger button simultaneously closes off the breathing airway, and starts the test. At the end of the 8-second test, the instrument automatically releases the airway which allows the test subject to breathe.

If at any time the test subject wishes to do a user-seal check, the Seal Check button on the front panel of the instrument can be used. The subject can press the Seal Check button while inhaling, and hold his or her breath for 10 seconds. When the Seal Check button is released, the subject should feel the mask move away from the face as the pressure is released. If this does not occur, this would indicate that the mask leak was so significant that the pressure could not be held for the 10 seconds.

Quantitative Fit Test Overview

Procedure

The Quantifit does not require an invasive probe in the respirator mask. In most cases, the test subject can be tested using the actual respirator mask that is worn in the workplace.

The respirator mask inlets are capped with one or two of the test adapters described in the previous section, and inhalation valves are removed or propped open. The test subject dons the respirator mask to perform the fit test. When the mask is properly positioned, the test subject takes a breath, holds the breath, and presses the trigger button to close the adapter valve and start the test. This starts the piston moving within the cylinder inside the Quantifit. The piston movement within the cylinder removes air from the facepiece until a predetermined challenge pressure is reached (see Challenge Pressure in Test Menu Chapter, page 24). Each step of the fit test is completed in 8 seconds or less.

The Quantifit controls the piston movement to maintain the challenge pressure inside the facepiece. The piston speed required to maintain a constant pressure is directly related to the airflow. Since leakage is directly related to the fit of the respirator mask, the lower the leakage, the better the fit. The leak rate is reported in cubic centimeters per minute.

Protocol

A protocol is a series of quantitative fit tests in various positions or a combination of fit tests and exercises. One quantitative fit test consists of the 8-second-or-less procedure explained above.

In September, 2004, OSHA approved the Redon protocol to be used only with CNP instruments. This five-step protocol performs tests with three different donnings to assure that the test subject is proficient at donning a respirator to achieve adequate fit. The test steps measured with this protocol are as follows:

- 1. Face Forward
- 2. Bend Over
- 3. Shake Head
- 4. Redon Respirator (1)
- 5. Redon Respirator (2)

It is recommended that the user follow the Redon protocol when testing any airpurifying respirators. When Self-Contained Breathing Apparatus (SCBA) Respirators are used, it is recommended that the SCBA protocol is used. This protocol is identical to the Redon protocol with the one exception that the challenge pressure is increased. The assumption is that while wearing an SCBA, the user will be under more stress, therefore creating a higher breathing rate. The Redon protocol uses a breathing rate of 0.58 H₂0, while the SCBA protocol uses a breathing rate of $1.50 H_20$. The MIL protocol uses a challenge pressure of 1.0 H_20 . The CSA protocol contains the steps currently required by Canadian Standards Association as of this writing. It is expected that the CSA will soon adopt the Redon protocol recommended by OSHA.

The user may also tailor the protocol to meet his company's needs or may alternatively use the factory preset protocols and test values. But please know that in order to comply with current standards for respirator fit testing, the user must use one of the factory-set five-step protocols.

Fit Factor

The ratio of the modeled breathing rate to the measured leak rate is the calculated fit factor and is expressed by the following equation.

Fit Factor = Modeled Breathing Rate (cc/min) Measured Leak Rate (cc/min)

The modeled breathing rate (MBR)* is the rate at which an individual breathes, predetermined for the standard protocols. The MBR is calculated from the parameters specified by the operator for custom protocols: The operator-specified parameters are inspiratory work rate, respirator mask type, cartridge type, and test subject's gender.

The measured leak rate (MLR) is directly related to facepiece fit. It is from the leak rate measurement that all fit factor calculations are made. The leak rate is specified in cubic centimeters per minute (cc/min).

Simply stated, the fit factor is the inverse of the percentage of air inhaled as a result of the leak.

* A feature unique to the Quantifit is its ability to change the modeled breathing rate in order to challenge the mask at different negative pressures. This allows the user to replicate different or extreme circumstances in the real work environment. By varying the negative pressure, the user can "challenge" or test the mask under varying stress load conditions, and discover how fit will be affected under those loads. The setting of these parameter options is discussed in the PARAMETERS section of Protocol Chapter.

NOTE: The conservative fit factor of the Quantifit is equivalent by definition to fit factors obtained by other quantitative fit test methods (ambient aerosol). The direct leakage measurement of the Quantifit is superior to ambient aerosol approximation methods, because the leakage measurement isn't dependent on aerosol in-mask particle accuracy problems, including collection and counting. The Quantifit leak measurement system uses air, not aerosols; there fore, it eliminates mixing and all other related problems associated with quantitative aerosol measurement methods.

Getting Started

Power-On and Menu Navigation

The power-on/off switch is located adjacent to the power cord plug on the rear panel of the Quantifit.

Use the Optical Sensor Knob to select the menu you wish to enter. The menu options are Test, Edit Protocol, System and Utility. The following four chapters are devoted to describing the functions and options contained under each menu heading.

Using the Optical Sensor Knob and Keyboard

For navigation through the Quantifit menu structure, you may use the Optical Sensor Knob, the supplied keyboard, or any combination of those two.

The Optical Sensor Knob can be turned clockwise or counter-clockwise to scroll through menus. When you arrive at the selection you wish to choose, simply press on the knob.

The keyboard can be used in the same way by using the cursor arrow keys to navigate through the menus, and by pressing <ENTER> to make a selection.

For the purposes of this manual, all instructions for navigation will use the Optical Sensor Knob. Please know that the keyboard may be used in the same manner for every function performed by the Optical Sensor Knob.

To enter into one of the four menus, press on the Optical Sensor Knob. You may now turn the knob clockwise to move forward to one of the menu items and press on the knob to make your selection. At any time you may press the "Back" button to get back to the previous menu, or use the "Home" button to return to the start-up screen.



Preparing the Respirator for Fit-Testing

- 1. **SELECT** the size, brand, and style of respirator that best fits the test subject and is most suitable for the application.
- 2. **REMOVE OR PROP OPEN** respirator inhalation valve(s) carefully. Upon completion of the fit test, reinstall the respirator inhalation valve(s).
- 3. **REPLACE** filter cartridge(s) or regulator with test adapter(s).
- 4. **CONNECT** the blue tube of the Triple Tube (Part # 9503-4003) to single connector on the adapter kit.
- 5. **CONNECT** two clear tubes of the Triple Tube (Part # 9503-4003) the two connector portion of the fit test adapter kit.

Instructing the Test Subject

Use the instructions below to teach the test subject the procedure for holding one's breath and the guidelines to follow during the fit test.

Have the test subject practice the following steps a few times until comfortable with the procedure.

- Take a breath and hold it, keeping mouth closed.
- Continue holding breath for 8 seconds.
- After holding breath for 8 seconds, and after the relax and breathe normally.

Have the test subject follow these guidelines during a fit test.

- Keep mouth closed (do not swallow or move mouth or tongue).
- Do not exhale any air through the nose.
- Do not make any head or facial movements. Sit or stand as still as possible in the position as instructed. Maintain this position for 8 seconds; then resume normal breathing.

CHAPTER

4. Test Menu

In this chapter you will find information about the Test Menu and Protocols.

Pre-Test

Introduction

The pre-test is not a requirement, but rather a tool that can be used to familiarize the test subject with the fit test, to conduct donning exercises, and to let the test subject quickly see how donning affects fit factor. The pretest can also be used to "qualify" a mask before beginning a protocol. The Quantifit can quickly check fit factors on different sizes and models of masks to determine the best-fitting respirator.

This introductory section contains the following:

- Information shown on the display when running a pre-test. (See instructions on running the pre-test, page 26.)
- Challenge pressure and respirator mask pressure definitions.
- Explanations of the pre-test parameters: inspiratory work rate, respirator mask type, cartridge type, and test subject's gender. (*NOTE: The minimum passing fit factor is a parameter for protocols only; therefore, see the Parameters section for instructions on how to change the minimum passing fit factor, page 41.*)
- When the minimum passing fit factor is changed for protocols, it affects the pretest results. (See the Pre-test Results section, page 28.)

• From the MAIN MENU, select the TEST MENU. Turn the Optical Sensor Knob or use the cursor arrow keys on the keyboard highlight "Pre-Test" on the TEST MENU. The following display appears:

TEST	EDIT PROT	OCOL	SYS	TEM	UTILTY
Exit Pre-Test Redon P MIL Prot	rotocol			Custom Mask Ir	· - I

Run a Single Test Exercise.

Next, press the key, and the display shows:

IMPORTANT:

Inhalation valves must be PROPPED OPEN or REMOVED from the respirator mask prior to the Fit Test! Press Enter to continue.

Press any key to continue, and the display looks like this:



The two numbers in the upper left corner of the above-illustrated display indicate the challenge pressure and respirator mask pressure.

The challenge pressure (58, above) is located immediately above the respirator mask pressure (0, above). See next page for details about these pressures and parameters.

Challenge Pressure

- For PRE-TEST, and CUSTOM 1 AND CUSTOM 2 PROTOCOLS the Quantifit calculates the negative pressure that would be produced in the respirator mask during inhalation, according to operator-selected parameters.
- For the REDON, MIL, and SCBA protocols, the challenge pressure is fixed and is not a factor of operator selected parameters.

- The challenge pressure is equal to the pressure produced in the respirator mask during inhalation, and it appears (in hundredths of an inch of water) in the upper left portion of the display during the pre-test.
- The challenge pressure is the pressure at which the leak rate measurement is made.

Respirator Mask Pressure

The Quantifit monitors the respirator mask pressure via the PRESSURE port (located on the front panel).

The respirator mask pressure appears (in hundredths of an inch of water) below the challenge pressure in the upper left portion of the display.

Pre-Test Parameters

The operator specifies values for four parameters: inspiratory work rate, respirator mask type, cartridge type, and test subject's gender.

These parameter values are used directly in two Quantifit calculations: modeled breathing rate (which is then used to calculate the fit factor) and challenge pressure.

Before you begin the pre-test, use the options listed below to set the parameter values. (An explanation of each parameter follows this list.)

WR: Select the inspiratory work rate.

Msk: Select the respirator mask type.

C: Select the cartridge type.

Male: Select the test subject's gender.

Explanation of parameters:

WR:

The inspiratory work rate has the largest influence on internal respirator mask pressure. It is measured in units of kcal/hr (energy consumed).

When a person expends more energy (works harder), he breathes harder, causing greater airflow through the cartridge. This increased airflow results in a higher-pressure drop.

Make an estimate of the work rate that the test subject experiences under normal working conditions. Turn the Optical Sensor Knob to highlight WR, and then push on the knob to make a selection. Scroll through the various options.

- 100 kcal/hr Light standing still or sitting at ease.
- 200 kcal/hr Moderate walking (casual) without a load.
- 300 kcal/hr Heavy walking with or moving a light load.
- 350 kcal/hr Extreme walking with or moving a heavy load, climbing stairs, digging, etc.

Msk:

The Quantifit tests two types of respirator masks.

- FF Full Face or Full Mask
- HM Half Mask

Because the full-face respirator mask has a C_02 accumulation in the dead space, the test subject must take harder, deeper breaths to compensate for the lower oxygen content. Deeper breaths mean a higher instantaneous airflow rate through the filter cartridge. Challenge pressure, the pressure differential across the filter cartridge, is directly proportional to the airflow rate through the cartridge.

C:

The cartridges are classified into four categories:

- Low Dust/mist filter
- Medium Chemical or HEPA
- High Combination of chemical and HEPA
- NA Respirator masks that do not use cartridges; for example, SCBA and PAPR

The pressure drop across the cartridge is a function of cartridge resistance and airflow rate; therefore, the higher-density (more resistive) cartridge causes a greater pressure drop across the face-to-facepiece seal.

Male/Female

Men and women both breathe the same volume of air (for a given work rate). They do, however, have different inhalation rates. A male inhales faster, which causes a higher instantaneous flow rate to occur and results in a higher challenge pressure.

Running the Pre-Test

- Set parameter values as explained in the previous section PRE-TEST, Pre-Test Parameters.
- Review the breath-holding procedure with the test subject.
- Complete steps 1–4 in PREPARING THE QUANTIFIT FOR TESTING.

- Complete steps 1–5 in GETTING STARTED, *Preparing the Respirator for Fit-Testing*.
- Have the test subject don the mask and adjust the straps to achieve a good fit.
- Make sure the test subject is seated or standing comfortably with shoulders facing the Quantifit.
- When the test subject is ready, have him take a breath, then press the trigger button.
- There are two beeps. On the second beep, instruct the subject to release the trigger button and to breathe normally and relax.

During the pre-test, a pressure trace appears as shown below:



The Quantifit measures respirator mask leakage after the pressure in the mask stabilizes at the challenge pressure.

The two beeps signify the following:

- The first beep (visually indicated by the first vertical line) signifies that the challenge pressure has been reached.
- The second beep (visually indicated by the second vertical line) signifies the end of the test.

Pre-Test Results

The pre-test results are illustrated below and on facing page. The results are explained on page 29.

If the leak rate of the respirator mask yields a measurable fit factor, the display will look similar to this:

-	Test Results	;	Pre-Test
-	Fit Factor	=	1353 PASS
-	Leak Rate	=	4.0 (cc/min)
	Test Time	=	8.0 (seconds)
-	Test Q	=	GOOD
Cont	tinue E	xit	Graph More Help

If the leak rate is so great that a fit factor cannot be measured the display will read "NO FIT (fit factor $\langle x \rangle$," where x is the lowest fit factor that can be measured for the particular set of parameters. Repeat the pre-test (see instructions below.)

• Select (MORE) for additional information as shown below:



* To change the minimum passing fit factor, refer to PARAMETERS, Editing Parameters beginning on page 25.

• Press (MORE) again, and the pressure trace is shown again:

Repeat the Pre-Test

It is recommended that the user keep repeating the pre-test until successful test results are achieved, that is, a "GOOD Test-Q" and a passing fit factor.

• Press (CONTINUE) to repeat the pre-test.

Fit Factor

The first test result is the calculated fit factor (FF), the ratio of the modeled breathing rate to the measured leak rate.

Fit Factor = Modeled Breathing Rate (cc/min) Measured Leak Rate (cc/min)

The direct leakage measurement of the Quantifit is superior to the aerosol approximation methods because the leakage measurement isn't dependent on aerosol particle-size distribution.

Notice the word "PASS" or "FAIL" next to the fit factor:

- "FAIL" indicates that the calculated fit factor is less than the *Minimum Passing Fit Factor* (explained on next page).
- "PASS" indicates that the calculated fit factor is equal to or greater than the *Minimum Passing Fit Factor* (explained on next page).

Leak Rate

The next test result is the leak rate. This is directly related to facepiece fit. It is from this leak rate measurement that all fit-factor calculations are made. Leak rate is specified in cc/min.

Test Time

This number represents the time from start to finish during which the subject holds his or her breath. The test time does not exceed 8 seconds. The total test time in seconds appears on the display beneath the "Leak Rate."

Test-Q

The Test-Q, or test quality, is an indication of acceptability of the fit-test results. Accurate results depend on a constant pressure being sustained during the test measurement interval.

To achieve a "GOOD" test quality, there must be enough consistency in the measurement from which the Quantifit will measure a consistent leak rate. Large pressure variations during the test will result in a "BAD" test quality. When this should happen, the user is instructed to try the step once again.

Additional Parameters

Additional parameters relating to the test can be viewed by using the optical sensor knob to scroll over to the "More" selection. The additional test information includes the following items:

Challenge Pressure

Shown in hundredths of an inch of water, the challenge pressure is the pressure at which the leak rate measurement is made. Challenge pressure is explained in the PRE-TEST, Challenge Pressure section.

Modeled Breathing Rate

The modeled breathing rate is the rate, in liters per minute, at which an individual breathes under the conditions specified in the protocol.

For Custom 1 and Custom 2 Protocols, the modeled breathing rate is set by the same parameters as discussed in the pre-test: work rate, respirator mask type, cartridge type, and test subject's gender. The modeled breathing rate is used to calculate the fit factor.

For the REDON, MIL, AND SCBA Protocols, challenge pressure and modeled breathing rate are pre-set and hence are unaffected by changes in the parameters.

Minimum Passing Fit Factor

The minimum passing fit factor is the minimum fit factor required for a passing result. This parameter is operator-specified as explained in the PARAMETERS, Editing Parameters section and displayed here. The PASS/FAIL indication that appears next to the fit factor, is calculated based on this parameter number.

Protocols

Now that you have completed several successful pre-tests, you are ready to begin running a protocol. The protocol is a comprehensive test that accurately measures the fit of a given respirator. Consistent fit-test results are achieved by using a protocol.

The protocol is a sequence of up to 18 fit tests or exercises. The Quantifit stores four standard and two custom protocols in nonvolatile memory. After all steps in a protocol have been completed, the fit-test results are combined to calculate an overall fit factor for the protocol. The protocol results can be printed.

Preprogrammed Protocols (5)

In September 2004, OSHA approved the Redon protocol for use only with CNP instruments. This 5-step protocol uses the strengths of Controlled Negative Pressure to assure that employees are achieving a proper fit. This protocol also reinforces proper donning techniques as the test measures the fit from three separate donnings. The following four protocols all use the same 5 steps during the protocol. The difference in each comes from the modeled breathing rate. The Redon protocol, as approved by OSHA (1910.134 App. A), requires that the fit is measured against a Challenge Pressure of .58 H₂O. The MIL (Military) protocol increases the pressure to 1.0 H₂O and the SCBA protocol increases all the way to 1.5 H₂O. With the two latter protocols, it is expected that the respirator wearer will be under more duress on a consistent basis. Because of this, the modeled breathing rate has been increased to match the estimated breathing rate of those respirator wearers.

Redon Protocol

Challenge Pressure (0.58 in. H2O) Modeled Breathing Rate (53.8 l/min.)

STEP 1:Face Forward

For this first step, after the test subject has selected a respirator and donned it properly, he or she will face forward for this measurement. The employee should be instructed with the proper method for holding breath and remaining still during the test measurement.

STEP 2: Bend Over

The test subject will bend over at the waist and face the floor during this measurement. This step determines if gravity pulling on the mask will create more leak than is permissible. The test subject holds breath and remains still during the test measurement.

STEP 3: Shake Head

The test subject will shake his or her head vigorously from side to side for approximately 5 seconds. The test subject is also required to blow out vigorously or yell while shaking head. The purpose of this exercise is to determine if the mask is unseated, if it will reseat itself properly on the test subject's face. For the test, the subject will stop shaking his or her head, hold breath and remain still during the test measurement.

STEP 4: Redon 1

The test subject will release all straps, remove the respirator (doff it), and then redon the respirator. The redon steps are very effective in determining how well a mask fits according to proper or improper donning techniques. Once the respirator is properly donned, the subject holds breath and remains still during the test measurement.

STEP 5: Redon 2

This step is identical to Redon 1. This gives the test subject one more donning with which to assure proper fit.

MIL Protocol

The MIL protocol procedure is identical to the REDON above but has a higher stress level than the REDON. The MIL protocol is designed to be used in military applications, where mask stress is high and fit requirements are more critical. This extra measure of protection is expressed in the increased values of:

Challenge Pressure (1.00 in. H2O) Modeled Breathing Rate (55.8 l/min.)

SCBA Protocol

The SCBA protocol procedure, like the MIL, is identical to the REDON above. It is designed to place the mask under extraordinary stress to be sure the mask can provide protection in life threatening situations where the SCBA is used. This increased exposure protection is better evaluated by values of:

Challenge Pressure (1.50 in. H2O) Modeled Breathing Rate (93.1 l/min.)

CBRN Protocol

The CBRN protocol procedure, like the MIL and SCBA, is identical to the REDON above. It is designed to place the mask under extraordinary stress to be sure the mask can provide protection in life threatening situations where the SCBA is used. This increased exposure protection is better evaluated by values of:

Challenge Pressure (1.50 in. H2O) Modeled Breathing Rate (93.1 l/min.)

CSA Protocol

The CSA Protocol was developed to meet the current standards of the Canadian Standards Association, Z94.4-02. The latest version of this standard was written in 2002. The next standard written may include the Redon Protocol. This protocol contains several exercises that are followed by tests where the subject will be tested face-forward.

Challenge Pressure (0.58 in. H2O) Modeled Breathing Rate (53.8 l/min.)

1. EXERCISE: NORMAL BREATHING The test subject will properly don the respirator and breathe normally for 30 seconds. When "Start" is selected, the Quantifit will being the 30 second countdown.

2. TEST: FACE FORWARD

The employee should be instructed with the proper method for holding breath and remaining still during the test measurement while facing forward.

3. EXERCISE: DEEP BREATHING The test subject will perform deep breathing for 30 seconds. Select "Start" and the instrument will count down 30 seconds leading up to the next exercise.

4. TEST: FACE FORWARD The employee should be instructed with the proper method for holding breath and remaining still during the test measurement while facing forward.

5. EXERCISE: HEAD SIDE TO SIDE The test subject will turn head from side to side during the 30-second countdown.

6. TEST: FACE LEFT The employee should be instructed with the proper method for holding breath and remaining still during the test measurement while facing left.

7. TEST: FACE RIGHT The employee will turn head to the extreme right, hold breath remain still during the test measurement.

8. EXERCISE: HEAD UP AND DOWN The test subject will raise and lower head up and down during the 30-second countdown.

9. TEST: FACE UP The employee will look up, hold breath remain still during the test measurement.

10. TEST: FACE DOWN The employee will look down, hold breath remain still during the test measurement.

11. EXERCISE: TALKING The test subject will talk during the 30-second countdown. The subject may talk randomly, read a passage, count, or recite alphabet.

12. TEST: FACE FORWARD The employee will face forward, hold breath remain still during the test measurement.

13. EXERCISE: BEND AT WAIST The test subject will bend over and touch his or her toes to the best extent possible. This will continue during the 30-second countdown.

14. TEST: FACE FORWARD The employee will face forward, hold breath remain still during the test measurement.

15. EXERCISE: REDON

The test subject will remove the respirator and redon it during a 30-second countdown.

- 16. EXERCISE: NORMAL BREATHING After the respirator has been redonned, the subject will resume normal breathing for a period of 60 seconds.
- 17. TEST: FACE FORWARD The employee will face forward, hold breath remain still during the test measurement.

User Definable Protocols

CUSTOM 1 AND 2

The Custom 1 and 2 protocols are designed to be defined by the user. They consist of up to 18 programmable steps of exercises or test measurements. The parameter values for the tests are determined by the selection of four parameter variables (see PARAMETERS). These protocols provide the user with the option to customize a protocol to meet his specific needs. The following chapter will explain in great detail the procedure to set up the custom protocols.

Challenge Pressure (VARIABLE in. H₂O)

Modeled Breathing Rate (VARIABLE l/min.)

Running a Protocol

Use the optical sensor knob to select the desired protocol from the TEST menu. When your selection is made, press on the knob to select.

If a keyboard is detected, the Quantifit will prompt the user to enter test information including:

- Test Subject ID
- First Name
- Middle Initial
- Last Name
- Mask Manufacturer
- Mask Model
- Mask Size
- Mask Type
- Test Operator
The Quantifit will display the message: IMPORTANT: Inhalation valves must be PROPPED OPEN OR REMOVED from the respirator mask prior to the fit test! Press Enter to continue.

It is very important that this step is put into practice. Examine the interface where the fit test adapters will be mounted onto the respirator. If there is an inhalation valve visible when looking into the respirator, this valve will interfere with the fit test and must be propped open or removed.

If the inhalation valve is easily removed and replaced, this is the recommendation. If it is difficult to remove and replace the valve, it should be held open with some small apparatus. You may use whatever is available for you or whatever will successfully keep the valve open during the test. Some suggestions include cut up drinking straws or coffee stirs, rubber tubing, or paper clips. These items MUST be removed at the conclusion of the test.

If the inhalation valves are not opened or removed, the Quantifit cannot exhaust air from the respirator to create a negative pressure. This could potentially create an invalid test by only measuring the distance between the dual tube and the inhalation valve.

If a keyboard is not being used, the user will have to select the mask type. HM = half mask, FF = Full Face. This selection will set the minimum passing fit factors to 100 and 500 respectively.

Follow these steps to run a protocol:

- 1. Review the breath-holding procedure with the test subject (see page 22.)
- 2. Complete steps 1-4 in PREPARING THE Quantifit FOR TESTING).
- 3. Complete steps 1–5 in GETTING STARTED, Preparing the Respirator for Fit-Testing.
- 4. Follow the on-screen prompts that instruct the test subject on activity to perform for each test step.
- 5. From the Main Menu, select the Test Menu; then select the protocol you wish to use.

Test and Protocol Results

There are two types of protocol results: test results and protocol results. The test results appear on the display only after each test-step is completed.

The protocol results appear on the display after all test-steps and exercise-steps are completed. The protocol results are a combination of each test-step's test results. From this combination of test results, the Quantifit calculates the "average equivalent fit factor" for the test protocol.

Test Results

Each test result is explained under PRE-TEST, Pre-Test Results.

If the leak rate of the respirator mask yields a measurable fit factor, the display will look similar to this:



This screen displays the protocol name at the top, the over all fit factor, pass or fail, and then the following options to finish out the test:

Scroll

Scroll will allow you to scroll through the results of the test you just performed. Click on scroll and rotate the knob one click clockwise, and it reveals the date and time of the test as in the following graphic.



The following screen displays Mask Type, Subject Gender, Challenge Pressure and Modeled Breathing Rate:

Mas	k Type		= Half Mask	
Subj	ject Gender		= Male	
Cha	llenge Pressure		= 0.58 ("H2O)	
Mod	eled Breathing Rate		= 53.8 (LPM)	
Scroll	Print & Save	Print	Save	Exit

You can then scroll through each step of the protocol as seen in step 1 below:

r			— Redon Pr	otocol		
	Step		Туре		Descriptio	n
	1		Fit Test		Face Forw	/ard
	Leak R	ate	Duration	Fi	t Factor	Quality
	42.2		8.0 Seconds		2206	GOOD
	Scroll	Print &	Save	Print	Save	Exit

Print & Save

Print & Save will save the test to the Datalog and print a copy.

Print

Print will print a copy of the results without saving to the Datalog.

Save

Save will save the test to the Datalog without printing a copy.

Exit

Exit will take you out of the results screen. If you have not selected Save or Print & Save, you will be prompted with a warning: Exit Test – Are you sure? Test data not saved yet! You can choose Yes or No.

If you choose Save or Print and Save, you will have the option to perform another fit test. This will begin a new test with the same protocol selected as the previous test.

5. Edit Protocol Menu

Introduction

This section contains instructions on how to use the EDIT PROTOCOL MENU to make adjustments to the protocol and parameters. Explanations are included on how to:

- View, Build, Edit, and Print a Protocol.
- View, Edit, and Print Parameters.

Edit Protocol Menu

On the main menu of the Quantifit, you can use the Optical Sensor Knob or keyboard to select EDIT PROTOCOL. You will be presented with a screen that shows the 5 standard protocols along with 2 custom protocols and a Parameters selection.

TEST	EDIT P	ROTOCOL	:	SYSTEM	UTILITY
MIL Prot	tocol	CBRN Pro CSA Proto Custom 1 Custom 2		Par	ameters

Edit, print, or view Redon Protocol

To edit any of the existing protocols, you may choose that protocol and press the Optical Sensor Knob. In this example we will enter the Redon Protocol. When selecting Redon Protocol, you will see the below options:

Redon Protocol				
EDIT	PRINT	VIEW		
RENAME	HELP	EXIT		

Select desired function

You can choose to edit, print, view, rename, help, or exit this menu. Each of these options are explained in detail.

Edit Protocol

Select the EDIT function to edit an existing protocol, or to create or define the custom protocols. When you enter the option to edit a protocol, a screen will be displayed to show the current setting, and the changes you are making to that setting. See diagram below for step 1.

		— Redon	Protocol ———	
	Step	Туре	Action	Dur
Current:	1	Test	Face Forward	N/A
New:	1	Test	Face Forward	N/A
Save and	d Exit		Cancel a	nd Exit

Select Step to Edit

The cursor is highlighted on New Step 1. To change a different step, press on the Optical Sensor Knob, and scroll to the step desired. Press on the knob again, and you can toggle the next field between Test and Exer (Exercise) and Clr (Clear) if you choose to delete that particular step. Finally, move over to the Action to select the desired action. The available actions are all of the standard selections that have been used throughout the history of fit testing. The duration is listed as N/A because this is not a changeable feature. By the definition of the way in which Controlled Negative Pressure works, all tests are preset to measure at 8 seconds.

When you have one step completed, scroll to another step if desired. When the protocol is set, you can select Save and Exit to save that protocol. If you decide to delete the changes you've made, you can select Cancel and Exit to exit this menu and lose the settings you've made.

If Custom 1 or Custom 2 had been selected, you can create up to 18 steps in a protocol if you have specific needs or desire to create a protocol for mask integrity testing or any other function of the Quantifit.

Print Protocol

By selecting Print from the Edit Protocol menu, this will simply print the current settings of the protocol if a printer is connected to the Quantifit.

View Protocol

By selecting View Protocol, you can view the current steps that are assigned to the selected protocol.

You will see listed the first 4 steps to the selected protocol. Steps beyond step 4 can be viewed by scrolling the Optical Sensor Knob.

View Redon Protocol					
Step	Туре	Action	Dur		
1	Test	Face forward	N/A		
2	Test	Bend over	N/A		
3	Test	Shake head	N/A		
4	Test	Re-don 1	N/A		
1					

Rename Protocol

This function allows you to rename the protocol so that your newly assigned name will now appear on the test menu. This is especially helpful if you want to change Custom 1 or Custom 2.

Help and Exit

These choices will lead you to the obvious place. If you choose Help, this will bring you to our on-board help menu. Exit will bring you out to the Edit Protocol Menu.

Test Parameters

The test parameters allow you to specify default options for your protocols. These options include mask type, gender, and minimum passing fit factors.

Mask Type

You may choose the default mask type as half mask or full face for your protocols.

Male/Female

This option applies only to the custom protocols where the gender would make a difference in the modeled breathing rate. The Male/Female option allows you to set a default gender that would be pre-set at the beginning of each test.

HM Passing

This setting pertains to the minimum passing fit factor for a half mask. It is recommended that this not be changed, as the default of 100 is the minimum passing fit factor for half masks. You must remember that CNP produces very conservative fit factors, and 100 on the Quantifit may equal up to 1,000 using Ambient Aerosol or Nuclei Counting technologies.

FF Passing

This setting pertains to the minimum passing fit factor for a full face mask. It is recommended that this not be changed, as the default of 500 is the minimum passing fit factor for half masks. You must remember that CNP produces very conservative fit factors, and 500 on the Quantifit may equal up to 5,000 using Ambient Aerosol or Nuclei Counting technologies.

CHAPTER

6. System Menu

Introduction

This section contains instructions on how to use the SYSTEM MENU to make adjustments to the system-level parameters. Explanations are included on how to:

- Set the clock.
- Reset protocols and parameters to the factory default values.
- Calibrate the dual tube assembly.
- Zero the pressure transducer.
- Add or edit operator name.
- Setup Quantifit parameters such as view the annual calibration date, change auto advance values, adjust the speaker volume, adjust the screen contrast, and view the version of firmware.

When you scroll to the System menu, you will see the choices displayed on the following diagram. This section will explain operation in each of these selections.

т	FST	
	LOI	

EDIT PROTOCOL

ExitZero PressureSet ClockEdit NameSystem ResetSystem setupDual tube calDatalog

Exit this menu

Set Clock

Set Clock allows you to adjust the time and date of the battery-backed clock. All printed reports made by the Quantifit include a time and date stamp; therefore, it is important to adjust the battery-operated clock to the current time and date to report accuracy on all tests.

D	——— Date and Time setup ———				
Current:	07/15/08	10:18 AM			
New:	07/19/08	10:24 AM			
Format:	MM/DD/YY	12 HR			
Save	•	Cancel			

When you open this menu, you'll notice that the month is highlighted. To change this value, press on the Optical Sensor Knob, and then scroll left or right to the appropriate value. Press on the knob again to accept that value. Then scroll to the right to change day, year, time and AM or PM.

On the Format row, you can choose the way in which you would like this data displayed. For the date, you can choose between MM/DD/YY or DD/MM/YY. For the time, you can choose 12 HR or 24HR.

When you have correctly set the time, choose Save at the bottom of the screen.

System Reset

The System Reset option will force all settings back to the way they were when the unit was first manufactured. Any alterations you might have made in any of the settings, these will be set back to the default settings. If you created a new protocol, this protocol will be lost by pressing System Reset.

You will receive one warning, "WARNING: System reset will re-load factory default settings. All custom Protocols will be lost! Are you sure?" You can select System Reset or Cancel.

Dual Tube Calibration

The Dual Tube calibration is the same function as the Daily Calibration. The Quantifit prompts you each day to perform a daily calibration. If you chose to proceed without the daily calibration, but want to do it at a different time, this is where you would go to perform that calibration. There may be other times where you might need to perform the calibration to ensure the accuracy of the instrument.

To accurately measure respirator-mask-fit, the leakage attributed to the triple tube assembly leak orifice must be removed from the total measured fit-test leakage value. Calibrating the dual tube assembly accomplishes this.

The triple tube assembly is terminated with an airtight section of tubing. The Quantifit removes air at eight different flow rates. The pressure developed across the leak orifice is measured at each flow rate and stored in an array of calibration data.

To cancel the effect of orifice leakage during a fit test, an interpolating algorithm uses the array of calibration data to determine orifice leakage at the fit test's particular challenge pressure. This calculated-leakage value is subtracted from the measured-leakage value.

Performing the Calibration:

Select Dual Tube Cal from the SYSTEM MENU. You will see the screen as displayed below.



This screen will show the user the last time the unit was calibrated. This screen also shows when the annual NIST Calibration is due. You may Perform Calibration, Print Data, or Exit. If you Print Data, it will print out the last calibration performed on the unit.

Select Perform Calibration to continue with the calibration.

Daily Calibration The sensor must be zeroed before running the dual tube cal. Disconnect the Dual Tube. 0.00 in H2O

Proceed

Cancel

The first part of the calibration performs a Zero Pressure. In order to do this part, you are instructed to remove the tube assembly from the instrument. Press the Optical Sensor Knob to proceed. You will then be instructed to "Connect dual tube assembly to 'Flow' and 'Pressure' on the front and to 'Dual Tube Check' ports on the back of the unit." This procedure measures only the two clear tube portion of the triple tube. When connecting to Pressure and Flow on the front of the unit, the male and female connectors must be matched properly. On the back of the unit, the other two ends are interchangeable and it does not matter which port each tube is connected to.

When both ends of the clear tube have been secured, press the knob on Proceed to continue. This calibration check will take approximately one minute to complete. The Quantifit will force different pressures through the instrument and tubing assembly and measure the leakage of the leak orifice. After the calibration has been completed, you will see a screen that confirms the calibration, and reminds you to remove the tubing from the back of the unit.



At this time you may Exit from the Dual Tube Calibration, or Print the report. Or you may return to the calibration at any time to re-print the calibration data.

Calibration Errors

If an error should occur and the Quantifit cannot successfully perform the calibration, the unit may not be operating properly. Check all connections, and try the calibration a second time. If it should fail a second time, you must contact OHD for further instructions. The following errors may occur:

ERROR–Bypass orifice not within spec. The message appears when there is a problem with the tubing. The leak orifice may be out of the tolerance range, or there may be a leak within the integrity of the tubing. If you have another tubing set, replace the tubing and try an additional calibration.

ERROR–Check connections and repeat. Reconnect quick-disconnect adapters and repeat this procedure.

ERROR–Check transducer calibration. Go to the next diagnostic routine, "Zero Pressure," and remove the offset from the pressure transducer.

ERROR-Replace orifice if necessary. Replace the dual tube assembly.

When the Quantifit successfully performs a calibration, this ensures that the unit is working properly and the leak measurements are within tolerance. If an error occurs, this would mean that there is a problem in the system and it must be corrected before successful fit testing can be accomplished.

Zero Pressure

"Zero Pressure" removes the offset from the pressure transducer. This step is identical to the first step of the Daily Calibration and Dual Tube Calibration. The Zero Pressure option may be used when the user would like to eliminate any offset without going through the Dual Tube Calibration.

When selecting Zero Pressure you will be instructed to remove the Dual Tube from the instrument. Press the Optical Sensor Knob to proceed. After one second, a message will be displayed, "Zero Adjust Successful." Any offset has been removed from the transducer.

There is an acceptable range of zero-offset values. Exceeding that range of values indicates that the dual tube assembly is connected, or that there is a problem in the pressure transducer or the conversion circuit. Fit-testing is inhibited at these times.

If the dual tube assembly is disconnected an error message occurs, contact OHD to determine if the Quantifit needs service.

Edit Name

If a keyboard is in use during fit testing, the operator will input his or her name at the beginning of the test. (See 21 for more information.) If a keyboard is not being used, the user can enter his or her name into the Quantifit so that it will print out on the report.

Select Edit Name, and you will see the following screen:



If a name is already present in this screen, you can easily "type over" the existing name, or go to "Clear" to delete the name. To enter a name one letter at a time, you must press on the Optical Sensor Knob to "enter," and then scroll through the alphabet either clockwise or counterclockwise until you reach the desired letter. When the desired letter has been selected, you may press the knob to confirm that letter, and then move one space to the right to continue with the next letter. When the name has been fully entered, select Done. See below.



System Setup

System Setup contains options and selections pertaining to the way your Quantifit performs. These functions in no way affect performing fit tests. Options include Auto Advance Fit Factors, Screen Contrast and Speaker Volume.

NIST Calibration Date

The NIST calibration date displays the last time the instrument was calibrated to NIST (National Institute of Scientific Testing) standards. This calibration is recommended annually. The Quantifit will display the calibration due date upon startup when the instrument is within 60 days of calibration expiration.

HM Auto Advance Fit Factor

When performing a fit test, the Quantifit recognizes when the test subject has passed a protocol step, and automatically advances to the next step. For the half mask, OSHA determines that the fit factor must be a minimum of 100. If the fit factor is greater than 100, the Quantifit will move to the next step. If it is below 100, the Quantifit will require that the user retry the step. If you chose to change the minimum requirement to higher or lower than what OSHA has determined, you can change it here. This value does not change the minimum passing criteria, it only changes the value in which the Quantifit will automatically move the user to the next step of the protocol.

If you wish to bypass the auto-advance feature, you may set the value to "0." This will require the user to individually save each step and the Quantifit will not auto-advance.

FF Auto Advance Fit Factor

When performing a fit test, the Quantifit recognizes when the test subject has passed a protocol step, and automatically advances to the next step. For the full-face mask, OSHA determines that the fit factor must be a minimum of 500. If the fit factor is greater than 500, the Quantifit will move to the next step. If it is below 500, the Quantifit will require that the user retry the step. If you chose to change the minimum requirement to higher or lower than what OSHA has determined, you can change it here. This value does not change the minimum passing criteria, it only changes the value in which the Quantifit will automatically move the user to the next step of the protocol.

If you wish to bypass the auto-advance feature, you may set the value to "0." This will require the user to individually save each step and the Quantifit will not auto-advance.

Test Results

Test result determines the way in which the fit factor is calculated. The native technology to the Quantifit is Controlled Negative Pressure (CNP). This measurement is calculated by taking the measured leak rate, dividing it by the modeled breathing rate, and this will give you the fit factor. (See page 20)

If you were to use the "older" approved method of fit testing, Ambient Aerosol (AA), the fit factor is calculated much differently. The AA instrument counts particles outside the mask and then compares it to particles inside the mask (with the assumption that the particles in the mask leaked in through an opening and that it's actually able to "see" a proper sampling of those particles.) The fit factor is calculated by dividing the particles outside the mask by the particles inside the mask, and this will calculate the factor.

Studies show that the fit factors calculated by CNP are at least ten times less than those fit factors calculated using AA or Nuclei Counting technology. The "Aerosol Compatibility" selection will recalculate the CNP fit factor to more directly compare it to a fit factor that would have been determined by Ambient Aerosol tests. However, instead of using the proven ten times factor, the Quantifit is much more conservative by using a four-times factor.

The default and recommended selection for Test Results is set to Standard Mode for the CNP calculation.

Test Device

The selections for Test Device are Mask or Test Cylinder. For demonstration purposes, one may use a test cylinder or leak canister to emulate a fit test. When using a leak canister, the Quantifit is not able to do the initial exhaust of air as with a respirator. So for more accurate measurements, it's best to use the test canister selection when using such to demonstrate the Quantifit. This is the only time Test Cylinder should be used. But even if the user selects Test Cylinder and forgets to change it, the setting will default to Mask the next time the Quantifit is powered up.

Contrast Adjust

This selection is for the contrast of the Quantifit display. At times you may need to change this setting according to your lighting situation. The default setting is 10, but this can be changed from 0 (no contrast) to 20 (maximum contrast.)

Speaker Volume

Normal operation of the Quantifit produces many electronic beeps and signals for various features. If you are operating the Quantifit in a noisy room, you may find the need to increase the volume of these signals. Or if you are in a quiet room and the signals are too loud, you may decrease the volume. The default setting is 2, which is moderately quiet. This range is from 0 (no sound) to 20 (loudest).

Firmware Version

The firmware version will display the current version of firmware. If you need technical assistance, the firmware version may be helpful to the technician in determining your specific problem. You may also go to the OHD website, www.ohdusa.com, periodically to make sure that you have the newest version of firmware.

Datalog

The Datalog displays all the tests that have been saved on the Quantifit. You may store more than 1000 tests in the internal memory. The list of tests is displayed with the most recent test at the top of the test.

		Datalog Mer	iu ——		-1/674
07/19/08	2:45 PM	Smith			J
07/19/08	2:40 PM	Johnson			Р
07/19/08 07/19/08	2:38 PM	Williams			R
07/19/08	2:34 PM	Doe			J
Scroll Vi	ew Print	Menu File	Menu	Clear	Exit

In the upper right corner, this number represents the test number (in order of newest to oldest) and the total number of tests. In this diagram, the highlighted test is 1 of 674.

Scroll

Press the Optical Sensor Knob to enter the scroll feature. You may scroll anywhere in the list to highlight any specific test. The Optical Sensor Knob has a variable speed, so that the faster you turn it, the faster it accelerates. With a single quick turn, you will find the cursor at the bottom of the list. Press the knob again to exit scroll mode, which will allow you to make another selection from the bottom menu.

View

The view selection will allow you to view the test in the same manner that you could view the test directly after its completion. You can scroll through the screens to see the overall fit factor, test details, and then results for each step. You may also print the results for that individual test.

Print Menu

The print menu selection will print a report of fit tests. When selecting this option, you have a choice to print a highlighted record, or print a log. If you choose the Print Record selection, you will print an individual test. If you select Print Log, you will be prompted to choose to print tests from a specific date that you will specify, or you could Print All to print your entire database. This feature will print a landscape (horizontal) page with each test contained within one line. Each line contains date, time, last name, first name, pass/fail, mask model, mask size, fit factor and leak rate. The report contains 40 tests per page.

File Menu

The file menu option is for transferring data. This feature may be used for various reasons including transferring data to FitTrack software (see "Importing Quantifit Data Into FitTrack" in the software section of this manual, page 71), to transfer the test data to another Quantifit, or to simply keep a safe backup of the test data on your instrument.

The **Save Datalog** feature will save the database to a memory stick when one has been inserted into the upper USB port on the back of the Quantifit. If you connect your memory stick to the bottom USB port, you will receive a message on the display telling you to use the upper USB port. When you save the data, you will be asked to name the file to differentiate it from other possible backups that you've already performed. If a keyboard is connected, you may type the name of the file on the keyboard. If no keyboard is connected, you must use the Optical Sensor Knob to assign the name.

The **Load Datalog** option will allow you to select a datalog on your memory stick that will be imported into the Quantifit. You will see a list of the exported information contained on your memory stick.

Clear

If you can confirm that your data has been backed up to your memory stick and you wish to clear the data stored on the Quantifit, you can purge the information by selecting Clear. You will be given one warning "Erase Datalog? Data cannot be restored." You must select Yes or No to complete this task.

CHAPTER

7. Utility Menu

Introduction

This section contains instructions on how to use the UTILITY MENU to test various aspects of the Quantifit. In this menu you may also view the cycle count of how many test steps have been performed, reset all changed protocols, and you can print the help file.

Perform a diagnostic check of the Quantifit diagnostic routines listed below:

- Speaker Test
- Keyboard Test
- Display Test
- Printer Test

TEST	EDIT PROTOCOL	SYSTEM	UTILITY
	Exit Speaker Test Keyboard Test Display Test	Printer to View cyc Factory Print hel	le count protocol

Exit this menu

Speaker Test

The speaker test will confirm that the internal speaker is performing properly. When selecting this option, you will hear a series of tones. If you do not hear tones, make sure that your speaker volume is not set to 0 in the System Setup menu.

Keyboard Test

The keyboard test will display a screen in which typed characters should appear. If no characters appear, disconnect and reconnect the keyboard. At that time, you should see a "USB Keyboard Connected" message. If you do not see this sign, the keyboard may be faulty.

Display Test

When selecting this option, the screen will show full dark for 5 seconds, at which time the screen will return to the normal setting. If you cannot see characters on your screen, check the System Setup menu to make sure the Contrast adjustment is not set to the lowest setting.

Printer Test

The printer test will print a test page to your printer. If this does not occur, your printer could be connected improperly. Check to make sure that the printer is turned on, and reconnect the printer. You should see a message on the display, "USB Printer Connected." If this does not occur, there may be a problem with the printer, or the printer may not be approved for use with the Quantifit. Check the OHD web site or call for technical support to determine if this is the problem.

View Cycle Count

The cycle count is a measure of how many fit test exercises have been performed since the unit was last calibrated. Each time an exercise is completed, the cycle count is incremented then stored in memory.

Factory Protocol

The Factory Protocol will restore all protocols that may have been changed in the Edit Protocol menu.

Print Help File

If a printer is connected to the Quantifit, this function will print all the information from the help file to your printer. This may be helpful to keep as a resource rather than going through the on-board help menus.

CHAPTER

8. FitTrack Software

Introduction

FitTrack software is designed to enhance the capabilities of the OHD Quantifit Quantitative Respirator Fit Test instrument. FitTrack gives you control, ease of operation and a comprehensive ability to store fit test results. This portion of the manual is dedicated to informing you of the capabilities of FitTrack and the advantages of automated data storage.

This manual is based on the assumption that the user is familiar with using the OHD Quantifit Quantitative Respirator Fit Test instrument, as well as the Windows 2000, XP, or Vista operating system. If you are unfamiliar with any of these, please read to the appropriate manuals before proceeding.

WARNINGS!

- FitTrack records cannot be altered after a SAVE has been applied. If errors are noted that need changing, a new test must be created. The test with the error may be deleted from the database.
- All Deletions from the database result in information irretrievably removed. TAKE GREAT CARE USING THE DELETE OPTION. Data is NOT sent to the recycle bin and cannot be recalled.
- REPAIR DATABASE is a powerful option. Please check with the OHD technical staff before using this option.
- If you have the need to reinstall FitTrack software or move to another computer, the best method to transfer data is by using the **Backup/Restore** features found under the **Database Utilities** in the **System** menu. Please

Getting Help

While you Work

An integrated help system provides online assistance whenever you need it.

To access help topics:

- 1. Click Help.
- 2. Click Contents or Search for Help On.

NOTE: Pressing "F1" at anytime will activate the FitTrack help system.

Technical Support

For questions relating to this product, please contact Occupational Health Dynamics.

Phone or Fax

Phone:	(205) 980-0180
Toll Free:	(888) 464-3872
Fax:	(205) 980-5764

Mail

Occupational Health Dynamics 197 Cahaba Valley Pkwy Pelham, AL 35124

Email Support

techsupport@OHDUSA.com

Web Site Support

Check the latest Technical Support publications or download the latest FitTrack updates at http://www.ohdusa.com.

9. Installing and Removing FitTrack

Requirements

FitTrack 3.0 is compatible with Windows 2000, XP, and Vista. FitTrack will run on any computer compatible with these operating systems.

Installing FitTrack

To install FitTrack:

- 1. Close all programs.
- 2. Insert CD into your computer's CD drive.
- 3. If CD does not auto load and begin loading the program, go to **Start** and then **Run**, and type in **D:\setup.exe**. (If your CD drive is other than "D," please substitute command with the appropriate drive letter.)
- 4. In most instances, you will accept all the default selections as you load the program.

Removing FitTrack

To remove FitTrack:

- 1. Close all programs.
- 2. Click the Windows **Start** button, point to **Settings**, and then click **Control Panel**.

- 3. Double-click the Add/Remove Programs icon.
- 4. Click **FitTrack** on the **Install/Uninstall** tab, and then click the **Add/Remove**.
- 5. Follow the instructions on the screen.

Installing the Quantifit Driver

When installing FitTrack and communicating with the Quantifit for the first time, you will be required to install the Quantifit Driver. When using Windows XP, you should see a Windows message declaring that new hardware has been found. Click on this message window to bring up the Add Hardware Wizard.

Found New Hardware Wiz	zard
	Welcome to the Found New Hardware Wizard
	Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission). Read our privacy policy
	Can Windows connect to Windows Update to search for software?
	Yes, this time only
	 Yes, now and every time I connect a device No, not this time
	Click Next to continue.
	< Back Next > Cancel

When the Wizard asks, "Can Windows connect to Windows Update?" click "[•] No, not this time," and click on "Next."

On the next screen, choose \odot "Install Automatically." If the FitTrack disc is still in the CD drive, Windows will automatically install the driver. Then you may click, "Finish."



If the automatic install does not work for you, you may need to point the Add Hardware Wizard directly to the driver file. Instead of choosing "Install Automatically," choose, ⊙ Install from a list or specific location (Advanced). Then select "□ Include this location in the search" and click on the browse button. You will then browse to C:/Program Files/OHD/5.0.0/Drivers. By selecting this location, you should be able to resume the Install Hardware Wizard and properly install the driver.

Found New Hardware Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM)
✓ Include this location in the search:
C:\Program Files\OHD\5.0\Drivers Browse
O Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
< <u>Back</u> Next > Cancel

CHAPTER

10. Running FitTrack

Starting FitTrack for the First Time

If you intend to operate the Quantifit and do testing, first perform these operations on the Quantifit (*See Quantifit section of the manual for help on these items*):

- 1. Power on the Quantifit.
- 2. Perform the **Daily Calibration** function.
- 3. Insure that the connections between the Quantifit and the Computer are properly connected.

NOTE: FitTrack will operate in all modes except Testing and Retrieve Calibration Data without being connected to a Quantifit.

To start FitTrack:

- If there is a FitTrack shortcut on your desktop, double-click on the icon. If not, go to the Windows Start menu, point to Programs. Point to OHD > FitTrack, and then click on FitTrack.
- 2. A Password screen appears. Leave this blank and click "OK." (You can set the password once you enter into FitTrack.)

FitTrack 3000 - Enter Pa	assword	
Password ;		-
<u>D</u> K	Cancel	

3. Enter Operator Name and press Enter.



4. FitTrack will automatically look for a Quantifit connected to your computer, and confirm that if found an instrument.

Retriev	e Calibration Data 📃
2	Found a Quantifit on Com 4. Do you want to retrieve calibration data?
	Yes <u>N</u> o

5. You will then be asked if you want to save the calibration data that has been saved on the Quantifit. It is recommended that you save the calibration data every day into FitTrack software.

Retrieve	e Calibration Data	
÷)	Calibration Data Successfully	Saved.

6. If calibration data has already been saved for the current day, you will receive the following message. You can choose to replace the current calibration data with a newer calibration, or click **No** to keep the data that has already been saved.

Retrieve Calibration	Data 📃
Calibration data has alre UnitID: 1041 Calibration Date: 10/03)	
Do you wish to overwrit	e it?
Yes	No

7. You will be asked to set up a Company/Location. Fill in the appropriate fields into the database. This can be change or completed at a later time through the System > Company/Location Properties.

🛯 New Company/Location		
Name :		<u>K</u>
Location :		Cancel
Contact :		
Address :		
		-
City :		-
State :	ZIP :	
State.	20.1	
Phone :		-
Fax:		-
Notes :	100	
NOIGS .	<u></u>	
		2
Custom 1 :		
· · ·		
Custom 2 :		
Custom 4 :		-

- 8. Expand all the Windows in the program.
- 9. Setup the Quantifit. Under the Setup menu, select Instrument. Click on Add and fill in the appropriate information. The serial number can be found on the back of the Quantifit.
- 10. Under the Functions menu, click on Retrieve Calibration Data. This will take the calibration data saved on the Quantifit and import it into your FitTrack database.

Starting FitTrack for Normal Operation

If you intend to operate the Quantifit and do testing, first

- 1. Power on the Quantifit.
- 2. Perform the **Daily Calibration** function.
- 3. Insure that the connections between the Quantifit and the Computer are properly connected.

NOTE: FitTrack will operate in all modes except Testing and Retrieve Calibration Data without being connected to a Quantifit.

To start FitTrack:

- 1. If there is a FitTrack shortcut on your desktop, double-click on the icon. If not, go to the Windows **Start** menu, point to **Programs**. Point to **FitTrack**, and then click on **FitTrack 3000**.
- 2. A Password screen appears. If you are not using a password, click **OK**. If a password is required, please see the Administrator for the password. Once you are in FitTrack, you can always change or add the password by going to the **System** menu and then to **Database Utilities**, and then **Set Password**.

🇞 FitTrack 3000 - Enter P	assword 🛛 🔀	3
Password ;		
<u>Q</u> K	<u>C</u> ancel	

3. Enter Operator Name in the Login screen and press **Enter**. (*NOTE: If the* "*Log in this operator every time the program starts*" box has been checked, you will not see this window when you start FitTrack.) Any entered name becomes a part of the drop-down list at login. You may remove names from the drop-down list by selecting the name and clicking on the **Clear** button.

🔊 FitTrack 3	000 - Operator Lo	gin 🔀
Operator :	John Smith	Ţ
🦵 Login as th	is operator everytime the	e program starts.
<u>o</u> k	<u>C</u> ancel) lear

- 4. When the program has been opened, maximize all Windows.
- 5. FitTrack will automatically look for a Quantifit connected to your computer, and confirm that if found an instrument.



6. You will then be asked if you want to save the calibration data that has been saved on the Quantifit. It is recommended that you save the calibration data every day into FitTrack software.

Retrieve	Calibration Data	
÷)	Calibration Data Successfully	y Saved.

7. If calibration data has already been saved for the current day, you will receive the following message. You can choose to replace the current calibration data with a newer calibration, or click **No** to keep the data that has already been saved.

- FL C I I I I I	
Calibration data has alre UnitID: 1041	eady been saved for
Calibration Date: 10/03	108.
campi acioni piacon ropoo,	1001
Do you wish to overwrit	e it?

CHAPTER

11. System Database Functions

Database Utilities

Synchronizing the FitTrack Database

FitTrack has the capability of synchronizing databases between two FitTrack software installations. To synchronize the databases:

- 1. Click the **System** menu.
- 2. Click Database Utilities.
- 3. Click Synchronize.
- 4. In the *Synchronize Database* dialog, browse to select the database with which to synchronize.
- 5. Click Synchronize to complete the operation, or Cancel to abort.

WARNING: In order for the synchronize function to work, the databases being synchronized must have started as identical copies of a database. You must first create a database, and then use a copy to the computer with which you will be synchronizing. The way to do this is through the Backup/Restore commands. This will produce the identical databases necessary for synchronization.

Backing Up the FitTrack Database

To make a backup of the FitTrack database:

- 1. Click the **System** menu.
- 2. Click Database Utilities.
- 3. Select Backup.
- 4. In the Filename box, type a name for the backup, and then click **Save**.

NOTE: The backup will automatically default to the FitTrack folder with a file called "FitTrack.bak." If you ever have need to reinstall the FitTrack software, be sure to save the backup file to a folder other than the default location.

Restoring the FitTrack Database from a Backup

To restore a previous backup of the FitTrack database:

- 1. Click the **System** menu.
- 2. Click Database Utilities.
- 3. Click Restore.
- 4. In the folder list, browse to find the backup file ending with ".bak."
- 5. Click the filename of the backup, and then click **Open**.

WARNING: This option will irreversibly and completely overwrite the existing FitTrack database with the one you are restoring.

Compacting the FitTrack Database

As you change data in the FitTrack database, the database file can become fragmented and use more disk space than is necessary. Periodically, you can use the Compact function to defragment the database file. The compacted database is usually smaller and often runs faster.

To compact the FitTrack database:

- 1. Click the **System** menu.
- 2. Click Database Utilities.
- 3. Click Compact.

Repairing the FitTrack Database

The Repair function attempts to repair a corrupt FitTrack database file. (*This function should only be used when directed by a technical support staff member.*)

To repair the FitTrack database:

- 1. Click the System menu.
- 2. Click Database Utilities.
- 3. Click Repair.

Importing Data into FitTrack

Importing from Previous Version of FitTrack

This function is to import a database from an older version of FitTrack. Always backup your database before importing new data.

- 1. Open the Company/Location where you want the data to be imported.
- 2. Click the **System** menu.
- 3. Click Import.
- 4. Click From Previous Version FitTrack Database.
- 5. In the *FitTrack Database Import* dialog, click on the box with three dots, and choose the location of the FitTrack database file.
- 6. Click **Import** to start importing the data, or **Cancel** to abort.

Importing from ASCII Files

To import information from a delimited ASCII file:

- 1. Open the **Company/Location** where you want the data to be imported.
- 2. Click the **System** menu.
- 3. Click Import.
- 4. Click From Text File.
- 5. In the *Import* dialog, select the appropriate options, such as type of information and type of delimited text.
- 6. Click on the box next to the default file name to browse to the location of the appropriate file.
- 7. Click **Import** to start importing the information, or **Cancel** to abort.

Note: Text information must be comma or tab delimited and arranged exactly in the order information appears on the corresponding table. Importing from an Excel spreadsheet is a more trouble-free way to import your data.

Importing from Excel Spreadsheet (nonincremental)

To import personnel information from an Excel spreadsheet:

- 1. Open the **Company/Location** where you want the data to be imported.
- 2. Click the **System** menu.
- 3. Click **Import**.
- 4. Click From Excel Spreadsheet.
- 5. Click **Help** to view a list of how the data should be arranged in designated columns. (See figure below.)
- 6. Browse to the appropriate file name and select the correct worksheet.
- 7. Click **Import** to start importing the information, or **Cancel** to abort.

Warning: When using this feature, *all* data will be added to the open database. If a file for John Smith already exists, and there is a John Smith in the imported data, the results will yield two John Smith records.

Incremental Spreadsheet Import Help 🛛 🔀
Matching records in the selected spreadsheet worksheet and in the database will be updated. Records in the selected worksheet that have no matching record in the database will be added to the database. Any records found in the database, but not in the selected worksheet will be DELETED from the database.
The columns of the worksheet to import must be in this order: Personnel ID First Name Last Name Middle Initial Date of Birth Gender Date of Hire Position Job Department Custom Field 1 Custom Field 2 Custom Field 3 Custom Field 4
NOTES: - Column headings are NOT required in the imported worksheet. - If column heading are included, they MUST be placed on row 1 ONLY. - All data must be in sequential columns; there can be no blank colums between columns of data. OK
Importing from Excel Spreadsheet (Incremental)

To import personnel information incrementally from an Excel spreadsheet:

- 1. Open the **Company/Location** where you want the data to be imported.
- 2. Click the **System** menu.
- 3. Click Import.
- 4. Click From Excel Spreadsheet (Incremental).
- 5. Click **Help** to view a list of how the data should be arranged in designated columns. (see graphic above.)
- 6. Browse to the appropriate file name and select the correct worksheet.
- 7. Click **Import** to start importing the information, or **Cancel** to abort.
- 8. You will be asked if you want to delete the persons that do not appear on the list you are about to import.

Warning: If you click "Yes" to delete persons that do not appear on the list you are about to import, you will lose all data on persons that are not in the database you are about to import. This option was created to match the database that exists in FitTrack to the one you are importing, adding and deleting personnel changes.

Note: This function will add only new or changed information in the personnel table. However, the *Personnel ID* field must be used in order for this procedure to work properly.

Importing Quantifit Data Into FitTrack

This option will allow the user to import data stored on the Quantifit into FitTrack software. When test subjects already appear in FitTrack, the software will recognize the first and last name and merge the data with the existing record. In order for this function to work properly, the last name must be spelled accurately in the Quantifit in order to match the last name in the FitTrack database.

See "File Menu" under the Datalog information in the Quantifit section of this manual for more information (page 49). On the Quantifit, the user will go to the Datalog, which can be found under the System Menu. Once in the Datalog, go to the File Menu. This menu will allow the user to "Save Datalog." When a USB memory stick is inserted into the upper USB port, the datalog will be saved to the memory stick. That memory stick can then be inserted into the personal computer, and imported into FitTrack.

1. Save the datalog from the Quantifit to a USB memory stick as described on p. 49.

2. In FitTrack, open the **Company/Location** in which you'd like the data imported.

🖻 Import Quantifit Data File		×
0	Import	1
Quantifit Filename :	Cancel	1

3. In FitTrack, select System > Import Data > From Quantifit.

- 4. Click on the three dots [...] next to the filename field in order to browse to where the file has been saved.
- 5. When files has been selected, choose Import.
- 6. The import will take action in accordance with the following conditions:
 - a. All comparisons will be made by the last name and first letter of the first name.
 - b. If there are no matches to the record, it is automatically imported with no further action.
 - c. If an exact match is found, the record is automatically imported with no further action.
 - d. If a record is found with the last name and first letter of the first name matching, but the rest of the first name is different, the user will be prompted to take action. The user may choose one of the following steps:
 - i. Match the record. The drop-down list will be populated with all people with the same last name and first initial. First select the import record to highlight it, then select the matching name in the drop-down list, and finally click on the Match button. (See figures on next page)
 - ii. Skip the record (by placing an X in the skip column by clicking in that column). This would keep the record from being imported into the FitTrack database.
 - iii. Import the record as a new record. This would be done by clicking on Import and not following i. and ii. listed above.
- 7. When the import is finished, there will be a confirmation that it was successful.



Exporting Data from FitTrack

To export data to a delimited ASCII text file:

Click the System menu.

- 1. Click Export.
- 2. In the *Export* dialog, select the appropriate options, and choose the location for the text file.
- 3. Data Type allows you to specify which data you would like to export from FitTrack. The default selection is "Personnel and Test Data," which is the typical data most users would like to export.
- 4. Date range is if you want a specific range of tests exported. For instance you could put the current day's date for only tests that were performed on that particular day. If you want to export all records, select the "Include All Dates" option.
- 5. Field Delimiter and String Delimiter allows you to choose how you want the data marked. Field Delimiter will allow you to choose a period, semicolon or tab. The String Delimiter will allow you to choose single or double quotation marks.
- 6. Include Column Headings will export a header row presenting the name of each field.
- 7. Filename allows you to name the file as it pertains to the export data. The default location is C:/Program Files/FitTrack/3.0.1. You may press on the square with the three dots to choose another path in which to save the file. FitTrack will then remember this path for your next export.
- 8. Click **Export** to start exporting the information, or **Cancel** to abort.

7	S Export	X
	Data Type : Personnel and Test Data	<u>Export</u>
	Filename :	

Password Protection

Password protection can be set up to allow FitTrack to operate as a secure program, allowing access only when the user knows the appointed password.

Enter Password

- 1. Start FitTrack software.
- 2. On the Password Screen, enter assigned password and click **OK** or hit **enter** on the computer keyboard. If a password cannot be located, contact Technical Support at OHD.

Change Password

- 1. After logging into FitTrack, go to the **System** menu and select **Database Utilities.**
- 2. Under Database Utilities select "Set Password."
- 3. Type in the new password and then type it again in the confirmation box, and click **OK**. The new password has now been set.

Remove Password

Follow these instructions when you have no desire to use password security.

- 1. The password window will always appear when opening the program, but a password is not necessary if it has been left blank, you simply leave it blank and click **OK**.
- 2. To set the password to "blank," follow the instructions above for "Change Password," and make sure the password and confirmation fields are left blank.

Operator Login

After the Password screen, you'll see the Login screen. To login to FitTrack:

- 1. Use the drop-down menu to select a name from the list.
- 2. If the name you desire does not appear, type the name in the field. That name now becomes a part of that drop-down list.
- 3. To remove a name from that drop-down list, select the name and click on **Clear**.
- 4. To login another person, either restart the program, or use the **System** menu.
- 5. Under the System menu, select Operator Logout.
- 6. Then under the **System** menu, select **Operator Login**.
- 7. Follow steps as outlined in 1-4.

CHAPTER

12. Modifying System Data

Operation: Fit Factor Calculation Method

Explanation of Calculation Method

To access the *FitFactor Calculation Method* dialog window, click **Operation** on the **Setup** menu. FitTrack software will then default to the selection made.

You may choose the type of FitFactor Calculation Method you would like to use to report with the Quantifit. **Controlled Negative Pressure (CNP)** represents the value when calculating a fit factor by the controlled negative pressure method. This calculation is native to the Quantifit.



Ambient Aersosol Equivalent Fit Value represents the numbers you would get, in comparison, when using the Ambient Aerosol technology. Studies show that the CNP values are typically ten times lower than the Ambient Aerosol technology. When selecting this option, the value will actually calculate at only four times the CNP value. The Ambient Aerosol Equivalent may be selected to more accurately compare the two types of quantitative fit testing, but using the CNP selection is recommended for a more conservative fit factor.

Auto Save Fit Factor

When running a fit test using the **Auto Save** feature, the operation is dependent on a pre-defined minimum passing fit factor. The **Auto Save Fit Factor** allows you to assign the minimum passing values. The default is to the OSHA standard of 100 for a half-face respirator, and 500 for a full-face respirator.

You may change these values according to your needs. When testing a full-face respirator and keeping the default of 500, this means that if the test step reports a fit factor of 500 or above, FitTrack will automatically save the results and prompt the user for the next step of the protocol. If the fit factor is below 500, the user will have the option to save the step or re-test.

Defining Fit Test Protocols

A Fit Test protocol consists of a series of exercises, donning tests, and Fit Tests. FitTrack allows for an unlimited number of protocols with an unlimited number of steps. The *Protocol Information* dialog window is used to view, modify, create, and delete protocols.

To access the *Protocol Information* dialog window, click **Protocols** on the **Setup** menu.

Creating a New Protocol

To create a new Protocol:

- 1. Click Add.
- 2. In the *Protocol Details* dialog window, you will first be asked to enter the new protocol name.
- 3. Next you will need to click **Add** to bring up the *Protocol Step Detail* dialog window.
- 4. Choose either an exercise or test under the **Step Type**.
- 5. Next you will need to add a description of the step. You may either choose from the pull down list or simply type in your own description.
- 6. If the step is an exercise you will need to indicate how long in seconds the exercise will last. It is not necessary to enter a time for the test steps since all tests run for a maximum of 8 seconds.
- 7. Click **OK** to create the Step, or **Cancel** to abort.
- 8. Additional Steps for the Protocol are created by repeating the steps 3 through 7 above.
- 9. Once all of the steps of the Protocol are completely entered; press **OK** to save the Protocol, or **Cancel** to abort.

Modifying an Existing Protocol

To modify an existing Protocol:

- 1. Select the Protocol you wish to modify.
- 2. Click Modify.
- 3. In the Protocol Details dialog window, change the appropriate information.
- 4. Click **OK** to save the changes, or **Cancel** to abort.

Deleting a Protocol

To delete a Protocol:

- 1. Click the Protocol to delete. (Note Warning for Delete in General Warnings).
- 2. Click Delete.

Editing Protocol Steps

Creating a New Protocol Step

To create a new Protocol Step:

- 1. Click Add.
- 2. In the *Protocol Step Details* dialog window, enter the appropriate information.
- 3. Click **OK** to create the Step, or **Cancel** to abort.

Modifying an Existing Protocol Step

To modify an existing Protocol Step:

- 1. Click Modify.
- 2. In the *Protocol Step Details* dialog window, enter the appropriate information.
- 3. Click **OK** to save the changes, or **Cancel** to abort.

Deleting a Protocol Step

To delete a Protocol Step:

- 1. Click Protocol Step to delete. (Note Warning for Delete in General Warnings).
- 2. Click Delete.

Updating Respirator Data

To access the *Respirator Information* dialog window, click **Respirators** on the **Setup** menu.

Creating a New Respirator Type

To create a new Respirator Type:

- 1. Click Add.
- 2. In the Respirator Details dialog window, enter the appropriate information.
- 3. Click **OK** to create the Respirator Type, or **Cancel** to abort.

Modifying an Existing Respirator Type

To modify an existing Respirator Type:

- 1. Click the Respirator to modify.
- 2. Click Modify.
- 3. In the *Respirator Details* dialog window, change the appropriate information.
- 4. Click **OK** to save the changes, or **Cancel** to abort.

Deleting a Respirator Type

To delete a Respirator Type:

- 1. Click the Respirator Type to delete. (Note Warning for Delete in General Warnings).
- 2. Click Delete.

Sorting Respirator Type

Respirator Types in the *Respirator Summary* dialog window can be sorted based on any of the displayed fields. To sort the respirator types, click the column header of the field by which to sort.

Printing a Respirator Summary

To Print a Respirator Summary:

- 1. Click Print Summary.
- 2. In the Report Query dialog, enter the appropriate filter information, and click Print to print the summary or Cancel to abort.

Changing User Options

Quick Test Mode

Quick test mode is a productivity enhancement that allows an operator to enter new a new personnel record followed automatically with a fit test. To enable or disable the Quick Test Mode:

- 1. Click the **Setup** menu.
- 2. Click Quick Test Mode.
- 3. If the Quick Test Mode has a checkmark, the mode has been turned ON, and if it does not have a checkmark, the mode has been turned OFF.

Safe Mode

Safe Mode prompts the operator for confirmation every time a delete function is selected. To enabled or disable the Safe Mode:

- 1. Click the **Setup** menu.
- 2. Click Safe Mode.
- 3. If the Safe Mode has a checkmark, the mode has been turned ON, and if it does not have a checkmark, the mode has been turned OFF.

Show Tips

Show Tips will show hints when the mouse is positioned over certain controls throughout FitTrack. To enable or disable Show Tips:

- 1. Click the **Setup** menu.
- 2. Click Show Tips.
- 3. If Show Tips has a checkmark, the mode has been turned ON, and if it does not have a checkmark, the mode has been turned OFF.

Working with Company/Locations

FitTrack uses the concept of Company/Location as a logical grouping of personnel and test information. A Company/Location could be an entire company, a specific department, or any other grouping. Personnel and fit test records within one Company/Location cannot be viewed, edited, accessed or included in a report while in another Company/Location. If you wish to see and work with all records simultaneously, you will need to add all personnel under one Company/Location.

Creating a New Company/Location

To create a new Company/Location:

- 1. Click the **System** menu.
- 2. Click New Company/Location.
- 3. In the *New Company/Location* dialog window, enter the appropriate information.

New Company/Location	
Name: Location: Contact:	<u>K</u>
Address :	
City :	
State: ZIP:	
Phone :	
Fax:	
Notes :	
Custom 1 :	
Custom 2 :	
Custom 4 :	

4. Click **OK** to create the new Company/Location, or click **Cancel** to abort.

NOTE: The last four Fields of this screen (Custom 1, 2 & 3) are the Labels for those custom fields within this Company/Location that will appear on each personnel record. These labels may differ from account to account. Field 3 is a secure field and will appear in the database but will not print on the reports.

Opening an Existing Company/Location

To open an existing Company/Location:

- 1. Click the **System** menu.
- 2. Click Open Company/Location.
- 3. In the *Open Company/Location* dialog window, click the Company/Location to open.
- 4. Click **OK** to open the Company/Location, or click **Cancel** to abort.

Closing a Company/Location

To close a currently open Company/Location:

- 1. Click the **System** menu.
- 2. Click Close Company/Location.

Deleting Company/Location Information

To delete an existing Company/Location:

- 1. If a Company/Location is currently open, then close the Company/Location by selecting **Close Company/Location** in the **System** menu.
- 2. Click the **System** menu.
- 3. Click Delete Company/Location.
- 4. In the *Delete Company/Location* dialog window, click the Company/Location to delete.
- 5. NOTE & REMEMBER THE DELETE WARNING IN THE GENERAL WARNINGS SECTION
- 6. Click **OK** to delete the Company/Location, or click **Cancel** to abort.

Updating Company/Location Information

To update Company/Location information for the current Company/Location:

- 1. Click the **System** menu.
- 2. Click Company/Location Properties.
- 3. In the Company/Location Properties dialog, update the appropriate entries.
- 4. Click **OK** to save the settings, or **Cancel** to abort.

Updating Personnel Information

Personnel Information in FitTrack can be Added, Deleted, and Modified using the *Personnel Information* window. The *Personnel Information* dialog window is eh default window when FitTrack is opened. When creating a new company, this window will initially appear blank.

Creating a New Record

To create a new personnel record from the Personnel Information dialog window:

- 1. Click the **Add** button found on the right side of the window.
- 2. In the Personnel Details dialog window, enter the appropriate information.

Personnel Details General Respirators	Notes Test Summary		<u>N</u> ext >
Personnel ID : First Name : Last Name :		Middle Initial : Gender :Male	<u>C</u> ancel <u>S</u> ave <u>P</u> rint
Date of Birth : Date Hired : Position/Title : Medical Evaluation		Department : Job Code :	<u>Find</u> Find <u>N</u> ext
Date :	Custom1 : Custom2 : Custom4 :		

3. Click **Save** to create the new record, or click **Cancel** to abort. If you are ready to perform a fit test, choose **Next**. (Read section pertaining to performing a fit test. (See page 18.)

Modifying an Existing Record

To modify an existing personnel record from the *Personnel Information* dialog window:

- 1. In the main Personnel Information window, click the personnel record you wish to modify.
- 2. Click the **Modify** button found on the right side of the window.
- 3. In the *Personnel Details* dialog window, change the appropriate information.
- 4. Click **Save** to save the changes, or click **Cancel** to abort.

Deleting a Record

To delete a personnel record from the Personnel Information dialog window:

- 1. Click the personnel record you wish to delete.
- 2. Note the Delete Warning in the General Warnings Section.
- 3. Click the **Delete** button found on the right side of the window.

WARNING: This option will delete the currently selected personnel record along with all test data.

Using Query to Filter Records

The Query function allows filtering of personnel records based on a specified criterion.

To perform a Query from the Personnel Information dialog window:

- 1. Click the **Query** button found on the right side of the window.
- 2. In the Query dialog window, enter the appropriate matching criteria.
- 3. Click **OK** to perform the query, or click **Cancel** to abort.

NOTE: Standard wildcards are allowed when entering the query criteria.

Using Find and Find Next to Locate a Record

The Find and Find Next functions allows for searching of personnel records.

To perform a Find from the Personnel Information dialog window:

- 1. Click Find.
- 2. In the *Find* dialog window, enter the appropriate search criteria.
- 3. Click **Find** to perform the search, or click **Cancel** to abort.
- 4. To find the next record with the same search criteria click Find Next.

Sorting Personnel Records

Personnel records in the Personnel Summary dialog window can be sorted based on any of the displayed fields.

To sort the personnel records, click the column header of the field by which to sort.

CHAPTER

13. Working with the Quantifit

Setting-up the Quantifit

Connecting the Quantifit™

FitTrack uses a USB cable (supplied) and an available USB port from your computer to communicate with the Quantifit.

To connect the cable:

- 1. Connect the square end of the supplied cable to the back side of the Quantifit, labeled USB PC.
- 2. Connect the opposite end of the cable to one of the USB ports on the computer.

Communications Settings

To setup communications:

- 1. Click the **Setup** menu.
- 2. Click Communications.
- 3. In the *Communications Setup* dialog window, choose the serial COM port to which the Quantifit is connected.
- 4. Click **OK** to save the settings, or **Cancel** to abort.

Updating Instrument Information

Selecting a Quantifit

To select a Quantifit as the current test unit:

- 5. Click the **Setup** menu.
- 6. Click Quantifits.
- 7. In the Quantifit Information dialog, Select the desired Quantifit.
- 8. Click **OK** to select the Quantifit, or **Cancel** to abort.

Adding a New Quantifit to the Instrument Menu

To add a new Quantifit from the *Quantifit Data* dialog:

- 1. Click the Add button.
- 2. In the *Quantifit Details* dialog, enter the serial number, location and person to whom the Quantifit is currently checked.
- 3. Click **OK** to save the settings, or **Cancel** to abort.

Deleting a Quantifit from the Instrument Menu

To delete an existing Quantifit from the Quantifit Data dialog:

- 1. Select the Quantifit to delete.
- 2. Note the Delete Warning in the General Warnings Section.
- 3. Click the **Delete** button.

Modifying a Quantifit

To modify an existing Quantifit from the Quantifit Data dialog:

- 1. Select the Quantifit to modify.
- 2. Click the **Modify** button.
- 3. In the *Quantifit Details* dialog, modify the appropriate information.
- 4. Click **OK** to save the settings, or **Cancel** to abort.

Retrieving Calibration Data

The Quantifit calibration data is imported upon opening FitTrack. However, you may also select to specifically download this data without restarting the software. To receive calibration data from the Quantifit:

- 1. Click the Functions menu.
- 2. Click Retrieve Calibration Data.
- 3. A screen will let you know which Quantifit is selected (see Selecting a Quantifit, page 88) for use. Click OK to confirm that the correct Quantifit is selected.
- 4. The next window shows the calibration values that will be saved to the database. Click OK.
- 5. The calibration data will be retrieved and saved for the currently selected Quantifit. The date and time of calibration are captured from your computer system, so it is important that you capture the calibration data as close as possible to the actual calibration.

Reset Pump

The **Reset Pump** function resets the pressure transducer in the Quantifit. This function can be performed as a test to confirm communication between the Quantifit and your computer. When selecting **Reset Pump**, the Quantifit will generate a short "burp" sound when communication has been properly established.

To perform a Reset Pump:

- 1. Click the **Functions** menu.
- 2. Click Reset Pump.

Move Personnel

The **Move Personnel** feature allows the user to move a test subject from one Company/Location to another. Simply select the person to be moved, click on **Move Personnel**, and a list of all Company/locations will be displayed. Select the Company/Location to move the test subject, click OK, and the test subject has been moved.

Upgrade Quantifit Firmware

Firmware is the software that is installed on the Quantifit. This is different from FitTrack, which is installed on a computer. The internal software that is used to control an instrument is called firmware. When a new version of the Quantifit firmware is available, it may be downloaded and installed through FitTrack. See section on page 47to see how to check your current version of firmware.

If the computer that contains FitTrack has internet access, the firmware can be downloaded and installed directly from the internet. If the computer does not have an internet connection, you must first get the file (via internet download on another computer) before the upgrade can be applies. If the file must be downloaded on another computer, simply copy that file to the computer with FitTrack software.

Once you know if you will be downloading the file or accessing it directly from the internet, you may proceed.



Select Upgrade Firmware from the Functions menu in FitTrack. There will be prompts and instructions to upgrade the firmware. Follow the online instructions and the software will automatically upgrade the firmware.

If you are upgrading directly from the internet, you will be prompted to choose that selection, "Browse Internet Files. The most recent upgrade will be the only one available in the upgrade window".

If the upgrade file was copied to the FitTrack computer, there is a selection to "Browse Local Files." With this option selected, the user can browse to where the file had been saved to complete the installation upgrade.

14. Performing a Fit Test

Selecting Test Information

Prior to performing a fit test, appropriate protocol, respirator, and Quantifit information must be selected. This information can be selected using the *Test Information* dialog window. This window can be display by clicking **Perform FitTest** on the *Personnel Information* dialog window.

Selecting Personnel Information

To select a personnel record to use during a FitTest:

- 1. Select the desired personnel record on the Personnel Information window.
- 2. Click **Perform FitTest** on the right side of the window, or simply double click on the line of the person you wish to test.

Selecting a Respirator

To select a respirator:

1. Click the **Select Respirator** tab in the *Test Information* dialog window.

ersonnel ID : Bee Clean	First Name : Last Name :	
t Respirator Select Protocol Select	FitTester	
Product Number Manufacturer	Model Size Type Cartridge	Туре

- 2. Select **Add**, **Modify** or **Remove** to edit the list of respirators attached to that person. Appropriate **Size** and **Cartridge Type** options are included when **Add**ing a respirator from the *Respirator Selection* window. The *Respirator Selection* window may also be accessed by using the **Modify** button.
- 3. Verify that the desired respirator to test is highlighted before leaving this window. You will be prompted to confirm.

Selecting a Protocol

To select a protocol:

1. Click the **Select Protocol** tab in the *Test Information* dialog window. The default protocol is always the last protocol run.

Pers	sonnel ID : Bee Clean	First Name : Last Name :		Cance
elect F	Respirator Select Protocol Select FitTester			1
	Protocol Name: REDON			
	Test Parameters Modeled Work Rate : Normal		Fit sk : 100 ce : 500	
1	Step Num Step Description	Step Type	Exercise Duration (sec.)	
	1 Don & Face Forward	Test	0	
1	2 Bend at the Waist & Face Forward	Test	0	
	3 Shake Head & Face Forward	Test	0	
	4 Redon & Face Forward	Test	0	
	5 Redon & Face Forward	Test	0	

2. Use the Protocol Name drop-down list to select the desired protocol.

Selecting a Quantifit

To select a Quantifit:

- 1. Click the **Select Quantifit** tab in the *Test Information* dialog. The default Quantifit is the one last highlighted in the list.
- 2. Select the desired Quantifit.

Running a Protocol Test

The Protocol Test consists of performing a pre-defined protocol on a selected test subject while wearing a selected respirator. To activate the Protocol Test dialog window, click Protocol Test on the Test Information dialog window.

est Information	Respirator Information	< Back
Personnel ID : Bee Clean	Manufacturer : 3 M (7500 Series) Model : 7500	S Dack
First Name :	Size : Medium	
Last Name :	Type : Half Mask	
	Cartridge Type : Medium	Abort
est Parameters		Eave and En
	Min Passing FitFactor: 100	
		Run <u>P</u> reTes
rotocol Results Notes		
Protocol Name : REDON		
Step Num Step Description	Step Type Duration (sec.)	
1 Don & Face Forward 2 Bend at the Waist & Face Forward	Test 0	
3 Shake Head & Face Forward	Test 0	
4 Redon & Face Forward	Test 0	
5 Redon & Face Forward	Test 0	
	Treat of	
Run Step Auto		1
	Step Auto Save	

Using Run Step

To run a test step:

- 1. In the Protocol Test dialog window, select the test step to run.
- 2. Click Run Step.
- 3. Follow the instructions given in the *FitTest* dialog window.
- 4. When finished performing each step of the protocol, click **Save Results** to accept or **Abort** to cancel.

Using Auto Step

To auto run a test:

In the Protocol Test dialog window, select the first step to run.

- 1. Click Auto Step.
- 2. The appropriate dialog for the type of step will be displayed. Follow the instructions for running the step.
- 3. When each exercise step is complete, or you save a test measurement step, the next logical step in the Protocol will automatically come up ready to be run, and this process will continue until the end of the Protocol.

Using Auto Save (preferred method)

To auto save a test:

- 1. In the *Protocol Test* dialog window, select the first step to run.
- 2. Click Auto Save.
- 3. The appropriate dialog for the type of step will be displayed. Follow the instructions for running the step.

When each exercise step is complete, if the fit factor has met the minimum assigned fit factor, (see Auto Save Fit Factor, page 78), the software will automatically bring up the start screen for the next logical to be run, and this process will continue until the end of the Protocol.

NOTE: Any protocol step may be re-run prior to saving the entire protocol test results.

Viewing Intermediate Test Results

To view intermediate test results, Click the **Results** tab in the *Protocol Test* dialog window.

Adding Notes Regarding a Test

To add a note about this specific test, Click the Notes tab in the *Protocol Test* dialog window.

Saving Protocol Test Results

To save protocol test results, after completing an entire Protocol Test, click **Save** or **Save & Print** in the *Protocol Test* dialog window.

Saving & Printing Protocol Test Results

To save and print protocol test results, after completing an entire Protocol Test, click **Save & Print** in the *Protocol Test* dialog window.

Performing a Pre-Test

The Pre-Test can be used to familiarize the test subject with the fit test and to quickly check fit factors on different sizes and models of masks to determine the best fitting respirator.

To perform a Pre-Test:

- 1. Click the Functions menu.
- 2. Click Perform Pre-Test.
- 3. In the *FitTest* dialog window, select the appropriate test parameters.
- 4. Follow the instructions given in the *FitTest* dialog window.
- 5. When finished performing the Pre-Test, close the dialog window.

Viewing Test Results

Viewing Test Results

To view Test Results from the Personnel Information dialog:

- 1. Click the personnel record to view.
- 2. Click View Results.
- 3. A summary of all test results for the selected personnel record will be displayed in the *Test Results* dialog.

Viewing Test Result Details

To view Test Result Details from the Test Results dialog:

Click the test result to view.

- 1. Click Details.
- 2. Once the Details of a particular fittest is shown you may opt to reprint a copy of the test by clicking the Print button

Manually Entering Test Results

Adding Test Results

To manually add test results to the database:

- 1. Logon as a new operator if needed.
- 2. Select (add if necessary) the person you wish to manually add a fittest.
- 3. Click the **View Results** button from the *Main* window.
- 4. Click the Add button from the *Test Results* window.
- 5. In the *Test Information* dialog, select the appropriate Respirator, Protocol, and Quantifit used for the test.
- 6. Click the **Next** button on the *Test Information* dialog window.
- 7. In the Protocol Test dialog, set the correct time & date of the test.
- 8. Enter result data for the appropriate test steps by selecting the desired step and pressing the **Enter Step** button. Alternately, use the **Auto Enter** button to automatically step through the protocol, prompting each time for user entry. Please note that you will be entering the leak rate values rather than the fit factors. FitTrack will automatically calculate the fit factors from the entered leak rates.
- 9. After entering data for the last step in the protocol, click the **Save** to save the results, **Save & Print** to print out a copy of the test entered or **Abort** to cancel.
- 10. If errors are noted after a test has been saved there is no way to edit the information. The erroneous test will have to be deleted and the information reentered.

Deleting Test Results

To delete existing manually entered test results from the Test Results dialog:

- 1. Select the desired test result to delete. Note the Delete Warning in the General Warnings Section.
- 2. Click the **Delete** button.

15. Report Generation

Printing Summary Reports

NOTE: FitTrack prints all reports to the Default System printer.

Summary reports provide all information for Company/Location Information, Protocol Information, Quantifit Information, Calibration Information, and Respirator Information unless narrowed by Report Filter Criterion. Summary reports are also provided for Personnel Information, FitTest Information, A FitTest Log and Outstanding Test Information on an individual Company/Location basis.

With each report, there is an option to **Sort** or **Filter** the criteria you wish to print. If no filtering or sorting is needed, simply bypass this screen by clicking on the **Print** button. Sort and Filter instructions appear at the end of this section.

Printing the Company/Location Summary

This report will print a list of Company/Locations that have been entered into FitTrack. To print the Company/Location Summary report:

- 1. Click the **Reports** menu.
- 2. Click Company/Location Summary.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the **Print** button to print all data.
- 4. Click **Print** to print the report, or **Cancel** to abort.

Printing the Protocol Summary

This report will print a list of Protocols contained within FitTrack. To print the Protocol Summary report:

- 1. Click the **Reports** menu.
- 2. Click Protocol Summary.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the **Print** button to print all data.
- 4. Click **Print** to print the report, or **Cancel** to abort.

Printing the Respirator Summary

This report will print a list of respirators that have been input into FitTrack. To print the Respirator Summary report:

- 1. Click the Reports menu.
- 2. Click Respirator Summary.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the Print button to print all data.
- 4. Click Print to print the report, or Cancel to abort.

Printing the Instrument Summary

This report will print a list of fit testers that have been assigned to FitTrack. To print the Quantifit Summary report:

Click the Reports menu.

- 1. Click Quantifit Summary.
- 2. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the Print button to print all data.
- 3. Click Print to print the report, or Cancel to abort.

Printing the Calibration Summary

This report will print all calibration data that has been retrieved into FitTrack. To print the Calibration Summary report:

- 1. Click the Reports menu.
- 2. Click Calibration Summary.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the Print button to print all data.
- 4. Click Print to print the report, or Cancel to abort.

Printing the Personnel Summary

This report will print one line per person which will include all the data that appears in the personnel screen. To print the Personnel Summary report:

- 1. Click the Reports menu.
- 2. Click Personnel Summary.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the Print button to print all data.
- 4. Click Print to print the report, or Cancel to abort.

Printing the FitTest Summary

This report will print one page per person which will include all fit test results for each person. To print the FitTest Summary report:

- 1. Click the Reports menu.
- 2. Click FitTest Summary.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the Print button to print all data.
- 4. Click Print to print the report, or Cancel to abort.

Printing the FitTest Log

This report will print one line per person which will include all fit test and respirator information. To print the FitTest Log report:

- 1. Click the **Reports** menu.
- 2. Click FitTest Log.
- 3. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the **Print** button to print all data.
- 4. Click **Print** to print the report, or **Cancel** to abort.

Printing the Outstanding Test Summary

This report is useful in determining persons who are due for a fit test. To print the Outstanding Test Summary report:

- 1. Click the Reports menu.
- 2. Click Outstanding Test Summary.
- 3. In the *Outstanding Test Summary* dialog window, select an appropriate time period. The date selection will reflect those who have not been fit tested within the amount of days that is selected. (*A list of people who have not been tested in the last x number of days.*)
- 4. Click Print to start printing, or Cancel to abort.
- 5. In the *Report Query* dialog, enter the desired filter criteria. If a query is not needed, click the Print button to print all data.
- 6. Click Print to print the report, or Cancel to abort.

Printing the Fit Test Certification Card

This report allows the operator to print a certification card that the subject can keep in his or her wallet or pocket. To print the fit test card:

- 1. Click the **Reports** menu.
- 2. Click FitTest Card.
- 3. A graphic is shown of the position of ten cards. If you have a perforated sheet with other cards printed on it, you may select a starting point for where you want the current report to begin printing.

1	6	
2	7	
3	8	
4	9	
5	10	

- 4. In the *FitTest Card* dialog window, select by name or test date. Select multiple people by using "OR" between each selection.
- 5. Click **Print** to start printing, or **Cancel** to abort.
- 6. These cards will print on plain paper, or a standard pre-perforated business card sheet. You may laminate the cards in a pocket laminator.

Printing Detail Reports

Detail reports are provided for Company/Location Information, Protocol Information, and Respirator Information. Detail reports for Personnel Information and FitTest Information are provided on an individual Company/Location basis.

Printing the Company/Location Detail

To print the Company/Location Detail report, from the *Company/Location Information* dialog window, click **Print**.

Printing the Protocol Detail

To print the Protocol Detail report, from the *Protocol Details* dialog window, click **Print**.

Printing the Respirator Detail

To print the Respirator Detail report, from the *Respirator Details* dialog window, click **Print**.

Printing the Quantifit Detail

To print the Quantifit Detail report, from the *Quantifit Details* dialog window, click **Print**.

Printing the Calibration Detail

To print the Calibration Detail report, from the *Calibration Details* dialog window, click **Print**.

Printing the Personnel Detail

To print the Personnel Details report, from the *Personnel Details* dialog window, click **Print**.

Printing the FitTest Detail

To print the FitTest Details report, from the *Test Result Details* dialog window, click **Print**.

Filtering and Sorting Reports

Filtering Reports

🖗 Print FitTest Cards - Selection Criteria	
Filter Sort	<u>P</u> rint
Select all entries where:	Cancel
1. Test Date = 07/31/2008	
2.	
3.	
4.	
NOTE : Click the 'Print' button to continue if a query is not required.	

As you attempt to print each report, the **Report Query** box appears, defaulting to the **Filter** tab. If you do not have a need to filter the data, click the **Print** button. These instructions are to use the **Filter** function:

- 1. You can select from 4 different sets of criteria
- 2. In the first criteria box, select the first drop-down arrow in order to select which data you would like to use to filter. You may choose from Custom 1, Department, Equivalent Fit Factor, Job Code, and Test Date.
- 3. With the drop-down box to in the center of the line, you may select how you want qualifier to relate to your selection.
- 4. In the text entry field on the right side, type in the qualifying criteria.
- 5. Continue with step 2-4 as desired, using the AND and OR drop-down selection to relate to the previous filter criteria.
- 6. Click on **Print.**

Sorting Reports

🛱 Print FitTest Cards - Selection Criteria	
Filter Sort Sort entries by: 1	Cancel
NOTE : Click the 'Print' button to continue if a query is not required.]

As you attempt to print each report, the **Report Query** box appears, defaulting to the **Filter** tab. Select the **Sort** tab if you would like to sort the report by the Custom 1 field, Date Hired, Date of Birth, Department, Equivalent Fit Factor, First Name, Last Name, or Personnel ID. These instructions are to use the **Sort** function:

- 1. You can select up to 4 different sort citeria.
- 2. In the first criteria box, select the drop-down arrow to select which data you would like to use to sort.
- 3. You may select additional sort criteria
- 4. Click on Print.
- 5.

Printing Options

Customize FitTest Report Text

Customized text may be added to the lower left area of each FitTest Report. To add change, or delete text choose the **Customize FitTest Report Text** from the **Reports Menu.**

- 1. Add or edit text within the box provided.
- 2. Select **OK** to save or **Cancel** to abort

Print to Window

The Print to Window option allows for graphically viewing reports. This option aids in reviewing information without the expense and time of using a printer.

To select or de-select the Print to Window option:

- 1. Click the **System** menu.
- 2. Click Print to Window.

NOTE: FitTrack prints all reports to the Default System printer.

Custom Designed Reports

Customer Designed Reports

FitTrack utilizes a powerful output feature, which can be customized to meet almost any type of report need. OHD Technical Support can provide for a fee a customized report to meet your requirements. Please contact OHD to arrange a quote.

CHAPTER

16. Troubleshooting

In this chapter you will find information about problems and possible solutions.

Test Measurements

You may occasionally find a test measurement that is not as you expected. Descriptions of some of these common situations and possible solutions have been included to aid the user in obtaining more accurate measurements.

High Leakage

In many cases, the measured leakage exceeds the ability of the Quantifit to measure. Within the Quantifit, once the measuring cylinder reaches the maximum capacity, the cycle will immediately cease and abort. When the test time does not travel the full 8 seconds of the test, this is because the leak is too great. The FitFactor will equal "0" and the Leak Rate will equal "0.0." You will be required to retry the step and reach an understanding of why the leak is so great.



Large Leak

At other times the Quantifit will labor to create the negative pressure only to end the test measurement before the 8-second time. This leakage, although less than maximum, still fills the cylinder and abruptly ends the test. It will look something like this:



Possible Solutions

- 1. Check all connections for proper attachment.
- 2. Check to ensure that the Quantifit mask adapter is properly attached to the respirator. Look for cross-threading, loose connection, etc.
- 3. Check mask for proper tightness to the face and check that no hair, beard stubble, or other objects inhibit a good face-to-facepiece seal.
- 4. TRY A DIFFERENT MASK! Many masks SEEM to fit well but are NOT properly sized to a specific wearer. In other cases a different size or style may be better suited for the individual wearer.

Erratic Mask Pressure

The Quantifit is very sensitive to pressure changes inside the mask. If the pump motor sound alternates between high-and low-pitched whines and the pressure tracing line, even after challenge pressure is attained, is erratic, the Quantifit is sensing variations in pressure.

If the traceline varies significantly, and the Quantifit cannot obtain a consistent challenge pressure through the duration of the test, you would need to rerun the measurement. There are a number of causes for this type of reading.



Possible Solutions

- 1. Movement by the person being tested needs to be minimized. Actions such as swallowing, opening the mouth, and moving the tongue can adversely affect the pressure sensor.
- 2. Air inhalation or exhalation, even slightly, creates dramatic changes within the mask. Re-instruct the test subject to maintain breath holding during the test measurement.
- 3. A test subject may be unable to stop the flow of air through the nose while holding his breath. A nose clip can assist the subject (be sure that the nose clip does not interfere with the fit if the respirator).

Consistently Low Fit Factors

When you consistently get low fit factors, even when you know that a respirator should fit, and the pump motor is running slightly faster than normal, the graph could look normal.



When the leak rate is high, the graph can still look somewhat normal. The Quantifit will often be able to keep up with the leak and give a good test result, regardless of the fact that the leak is too large to yield a passing fit factor.

Possible Solutions

- 1. As in other leakage situations (see HIGH LEAKAGE), check all hose connections, adapters, and adapter connections to respirators.
- 2. Check for proper tension of respirator to face.
- 3. Try a different size or different respirator.
- 4. Have Adapter checked for leaks (call OHD for this service).

Rapid or Erratic Graph Movement

(Before or During Test)

When the Quantifit gives erratic, jerky movement during the test, especially before the challenge pressure is attained, and the challenge pressure takes awhile to attain, the problem might be an easy one to find and solve.



When the inhalation valve is not propped open or removed, the Quantifit is unable to get to the airspace touching the facepiece seal. The Quantifit is only looking at the seal of the inhalation valve, which can rapidly "flutter" with the sealing and breaking of the seal. The inhalation valve can easily be missed on some full-facepiece respirators that can be converted from SCBA or airline to Air Purifying Respiratory.

Possible Solution

Insure that the Inhalation Valve is propped open or removed.

OTHER PROBLEMS

DAILY CALIBRATION

The Daily Calibration normally functions to completion without any intervention by the user. Occasionally a problem may arise. The calibration procedure may stop abruptly or display an error message.

Possible Problem:

- 1. Something has blocked or partially obstructed the leak orifice on the Dual Tube Assembly and has rendered the tube out of tolerance.
- 2. Pressure in the transducer has not been zeroed.
- 3. The transducer needs factory calibration.

Possible Solutions

- 1. Turn Quantifit off at the power switch, wait 15 seconds, power on the Quantifit, zero pressure, and retry Dual Tube Calibration.
- 2. Replace Dual Tube Assembly.
- 3. Call OHD to evaluate problem or to arrange return for factory calibration.

What do I do when people are not passing a fit test?

This problem could include a number of variables, but most likely would fall into three categories: machine fault, adapter/mask fault, or subject/operator error. If it's a one-time problem when you are able to pass other people, the answer simply may be that the mask is not a good fit on the subject. When several subjects can't pass, you must look at the other variables.

Instrument Failure

- 1. You must do the Zero Pressure and Dual Tube Calibration at the beginning of each day.
- 2. If the FitTester finishes the dual tube calibration without an error message, this assures that the machine is operating properly and within tolerance.
- 3. If the FitTester does not complete the dual tube calibration, service might be needed. Please contact OHD customer service.

Mask/Fit Fault

- 1. You must first determine that there is a proper fit. Any facial hair, hair getting anywhere under the mask seal, temple hair too far forward, sunken temples or facial scarring, protrusions or blemishes, having the mask too loose or too tight, can all be reason enough to keep the FitTester from pulling a negative pressure within the mask. There are other obstacles that can come into play which are too numerous to list. With more experience fit testing, it's easier for one to see potential problems with fit.
- 2. To further check on the mask fit, do a user seal check for 10 seconds. Press the Seal Check button on the front of the instrument and take and take in a breath allowing for plenty of suction on the mask. If after 10 seconds the mask "drops" when releasing the Seal Check button, then there was a good seal in place. If there is no felt movement when the Seal Check button is released, then the air has leaked out in those 10 seconds.
- 3. Exhalation valves may be dirty or creased allowing air to be pulled into the mask. While the inhalation valves must be removed or propped open, the exhalation valve must remain in place and maintain a good seal.
- 4. On the mask, the apex of the head straps should sit on the crown of the head and not off to one side or the other.
- 5. Check the manufacturer's recommendation for properly donning a respirator and ensure that the user has been properly trained in donning that respirator as part of the OSHA requirements. All straps must be pulled to result in equal tension at each point.

Adapter Fault

- 1. The adapters must be kept clean and in good shape.
- 2. The squeeze bulb should inflate immediately when released. If it inflates slowly, this points to a problem either with the squeeze bulb or it means the diaphragm on the adapter is not working properly and must be replaced.
- 3. Disconnect and reconnect all tubes to make sure they all "snap" into place for a secure connection with a Phillips-head screwdriver, lightly turn the screws on the perimeter of the single-port side of the adapter. These screws are glued into place, but can become loose over time.
- 4. If the adapter had been dropped or crushed, a hairline crack might cause leakage.

Occupational Health Dynamics Operating Manual Quantifit

© Copyright Occupational Health Dynamics (OHD) agrees to a limited copyright release that allows you to reproduce manuals and other printed materials for use in service training programs and other technical publications. If you would like other reproductions or distributions, submit a written request to OHD

Unpacking and Inspection Follow standard receiving practices upon receipt of the instrument. Check the shipping carton for damage. If damage is found, stop unpacking the instrument. Notify the carrier and ask for an agent to be present while the instrument is unpacked. There are no special unpacking instructions, but be careful not to damage the instrument when unpacking it. Inspect the instrument for physical damage such as bent or broken parts, dents, or scratches.

Claims

Our routine method of shipment is via common carrier, FOB origin. Upon delivery, if physical damage is found, retain all packing materials in their original condition and contact the carrier immediately to file a claim.

If the instrument is delivered in good physical condition but does not operate within specifications, or if there are any other problems not caused by shipping damage, please contact Occupational Health Dynamics (OHD) or your local sales representative.

Standard Terms and Conditions

Refunds & Credits Please note that only serialized products (products labeled with a distinct serial number) and accessories are eligible for partial refund and/or credit. Nonserialized parts and accessory items (cables, carrying cases, auxiliary modules, etc.) are not eligible for return or refund. In order to receive a partial refund/credit of a product purchase price on a serialized product, the product must not have been damaged by the customer or by the common carrier chosen by the customer to return the goods, and the product must be returned complete (meaning all manuals, cables, accessories, etc.) within 90 days of original purchase and in "as new" and resellable condition. The Return Procedure must be followed to assure prompt refund/credit.

Restocking Charges Only products returned within 90 days from the date of original purchase are eligible for refund/credit. Products returned within 30 days of original purchase are subject to a minimum restocking fee of 15%. Products returned in excess of 30 days after purchase, but prior to 90 days, are subject to a minimum restocking fee of 20%. Additional charges for damage and/or missing parts and accessories will be applied to all returns. Products not returned within 90 days of purchase, or products which are not in "as new" and resellable condition, are not eligible for credit return and will be returned to the customer.

Return Procedure Every product returned for refund/credit must be accompanied by a Return Material Authorization (RMA) number, to be obtained from our Order

Processing Department. All items being returned must be sent freight prepaid to our factory location.

Certification This instrument was thoroughly tested and inspected and found to meet OHD manufacturing specifications when it was shipped from the factory. Calibration measurements are traceable to the National Institute of Standards and Technology (NIST). Devices for which there are no NIST calibration standards are measured against in-house performance standards using accepted test procedures.

Warranty

Warranty and Product Support This instrument is warranted by OHD against defects in materials and workmanship for two full years from the date of original purchase. During the warranty period, we will repair or, at our option, replace at no charge a product that proves to be defective, provided you return the product, shipping prepaid, to OHD. This warranty does not apply if the product has been damaged by accident or misuse or as the result of service or modification by other than OHD. IN NO EVENT SHALL OHD BE LIABLE FOR CONSEQUENTIAL DAMAGES.

Only serialized products and their accessory items (those items bearing a distinct serial number tag) are covered under this one-year warranty. PHYSICAL DAMAGE CAUSED BY MISUSE OR PHYSICAL ABUSE IS NOT COVERED UNDER THE WARRANTY. Items such as cables and nonserialized modules are not covered under this warranty.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state, province to province, or country to country. This

warranty is limited to repairing the instrument to OHD specifications. When you return an instrument to OHD., for service, repair, or calibration, we recommend using United Parcel Service, Federal Express, or Air Parcel Post. We also recommend that you insure your shipment for its actual replacement cost. OHD will not be responsible for lost shipments or instruments that are received in damaged condition due to improper packaging or handling. All warranty claim shipments must be made on a freight prepaid basis. Also, in order to expedite your claim, please include a properly completed copy of the Service Return Form. Recalibration of instruments, which have a recommended annual calibration frequency, is not covered under the warranty.

Use the original carton and packaging material for shipment. If they are not available, we recommend the following guide for repackaging:

- Use a double–walled carton of sufficient strength for the weight being shipped.
- Use heavy paper or cardboard to protect all instrument surfaces. Use nonabrasive material around all projecting parts.
- Use at least four inches of tightly packed, industrial-approved shockabsorbent material around the instrument.

Warranty Disclaimer Should you elect to have your instrument serviced and/or calibrated by someone other than OHD, please be advised that the original warranty covering your product becomes void when the tamper-resistant Quality Seal is removed or broken without proper factory authorization. We strongly recommend, therefore, that you send your instrument to OHD for factory service and calibration, especially during the original warranty period. In all cases, breaking the tamper-resistant Quality Seal should be avoided at all cost, as this seal is the key to your original instrument warranty. In the event that the seal must be broken to gain internal access to the instrument (e.g., in the case of a customer-installed firmware upgrade), you must first contact OHD technical support department at 205-980-0180. You will be required to provide us with the serial number for your instrument as well as a valid reason for breaking the Quality Seal. You should break this seal only after you have received factory authorization. Do not break the Quality Seal before you have contacted us! Following these steps will help ensure that you will retain the original warranty on your instrument without interruption.

WARNING Unauthorized user modifications or application beyond the published specifications may result in electrical shock hazards or improper operation. OHD will not be responsible for any injuries sustained due to unauthorized equipment modifications.

Occupational Health Dynamics 197 Cahaba Valley Parkway Birmingham, Alabama 35124 (205) 980-0180 (205) 980-5764 FAX

Index

Α

Accessories, 10 Adding Test Results, 96 Auto Save, 78, 94 Auto Step, 93

В

Back Up, 68

С

Calibration Errors, 46 CBRN Protocol, 32 Challenge Pressure, 24, 29 Clock, 44 Communications Settings, 87 Compact, 68 Company/Locations, 82 Connecting the Quantifit, 87 Contrast Adjust, 49 Create Record, 84 Creating Protocol, 78 CSA Protocol, 32

D

Daily Calibration, 17 Database Functions, 67 Database Utilities, 67 Datalog, 49 Defining Protocols, 78 Delete a Record, 85 Deleting a Protocol, 79 Detail Reports, 101 Display Test, 54 Driver, 58 Dual Tube Calibration, 45

Ε

Edit Name, 47 Edit Protocol Menu, 39 Editing Protocol Steps, 79 Erratic Mask Pressure, 106 Exporting Data, 74

F

Factory Protocol, 54 Features, 9 FF Auto Advance Fit Factor, 48 Filtering Reports, 102 Find, 85 Find Next, 85 Firmware Version, 49 Fit Factor, 20, 28 Fit Factor Calculation, 77 Fit Test Certification Card, 100 Front Connections, 13 Front Panel, 11, 12

Η

Help, 56 High Leakage, 105 HM Auto Advance Fit Factor, 48

I

Importing Data, 69 Installing FitTrack, 57 Instructing Test Subject, 22

Κ

Keyboard, 21 Keyboard Test, 54

L

Large Leak, 106 Leak Rate, 29 Login, 76 Low Fit Factors, 107

Μ

Manually Enter Test Results, 96 Menu Navigation, 21 MIL Protocol, 32 Minimum Passing Fit Factor, 30 Modeled Breathing Rate, 30 Modify a Record, 84 Modify Protocol, 79

Ν

NIST Calibration Date, 48

0

Operator Login, 76 Optical Sensor Knob, 12, 21

Ρ

Password, 74 Performing a Fit Test, 91 Personnel Information, 84 Preprogrammed Protocols, 31 Pre-Test, 26, 95 Pre-Test Parameters, 25 Print Help File, 54 Print to Window, 104 Printer and Keyboard Connections, 15 Printer Test, 54 Protocol, 19

Q

Query, 85 Quick Test Mode, 81

R

Rapid or Erratic Graph Movement, 107 Rear Connections, 13 Redon Protocol, 31 Removing FitTrack, 57 Repair Database, 69 Reset Pump, 89 Respirator Data, 80 Respirator Mask Pressure, 25 Restore, 68 Retrieve Calibration Data, 89 Run Step, 93 Running a Protocol, 34 Running a Protocol Test, 93 Running FitTrack, 61

S

Safe Mode, 81 Safety Considerations, 7 SCBA Protocol, 32 Seal Check, 12 Set Up, 11 Show Tips, 81 Sorting, 85 Sorting Reports, 102 Speaker Test, 54 Speaker Volume, 49 Summary Reports, 97 Synchronize, 67 System Menu, 43 System Reset, 44 System Setup, 47

Т

Technical Support, 56 Test Adapters, 16 Test Menu, 23 Test Parameters, 41 Test Results, 36 Test Time, 29 Test-Q, 29 Troubleshooting, 105

U

USB Devices, 14 USB PC Port, 14 User Definable Protocols, 34 User Options, 81 Utility Menu, 53

V

View Cycle Count, 54 Viewing Test Results, 95

W

Warranty, 112

Ζ

Zero Pressure, 47 Zero the Sensor, 17