

epotech cleaner



A water-based detergent for removing **Epotech aqua** and **epotech crystal** residues or stains.

Composition

- Contains benzyl alcohol.

Recommended use:

Cleaning off epoxy putty remains and film.

Instructions for use

Spread evenly across the surface to be cleaned or the epoxy residues, and leave to work for a few minutes. Then rub with a suitable scouring pad and rinse well with clean water. Repeat the operation if necessary. A prior test should first be conducted on a small patch before spreading the product across the whole area.

Conservation

- 36 months in its original container and protected from moisture and the weather. Store in a dry place, covered and protected from direct sunlight.

Safety and hygiene

- Use gloves.
- Do not use on alkali-sensitive surfaces.
- R10 Flammable.
- R36 Irritating to eyes.
- R20/22 Harmful by inhalation and if swallowed.
- S2 Keep out of the reach of children.
- S13 Keep away from food, drink and animal foodstuffs.
- S25 Avoid contact with eyes.
- S26 In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
- S56 Dispose of this material and its container at hazardous or special waste collection points.
- Do not swallow. In the event of an accident, phone (+34) 964 536 200

Technical Sheet Conditions

As it is not possible to know all the features and conditions of a building job, professionals must consider it and, if deemed appropriate, perform a previous test to confirm whether the product is suitable for the job.

The technical sheet cannot reflect all the applications and conditions entailed in the use of a material, so, in situations not described in this sheet, we recommend to perform a previous test and refer to our technical department.

This sheet has been updated in January, 2014.

References

SAP	Product description	Packaging
100120428	epotech cleaner 500 ml	500 ml Bottle

butech building technology, S.A.U.

Carretera Vila-real - Puebla de Arenoso (cv-20) km 2,5 - 12540 Vila-real - Castellón - España.

Apartado de correos: 297 - Teléfono (+34) 964 53 62 00 - Fax (+34) 964 53 00 34 - butech@butech.es - <http://www.butech.es>