

Room 1-1214, No.1888, Fax: +86-21-3375-8218 N. Shengxin Rd, Jiading, Shanghai, 201807, China www.permix-mixing.com

Tel: +86-133-9116-8218 www.permixtec.com

PVM - V Shaped Mixer

Introduction:



The PerMix PVM series V shaped Mixer, sometimes also called Y shaped Mixer, is one type of the so-called Tumbler Mixer (the other type is the PerMix PDC series Double Cone Mixer) which is very popular for the intimate blending of free flowing dry powders, granules, and crystals. It is featured by the very simple design and easy to clean construction.

The PerMix PVM series V shaped Mixer features a gentle high-flowing mixing process for solids/solids in a proportion of up to 1:100.000 with the possibility of using an intensifier bar to enhance the mixture, and solids/liquids in powder or granulate form with different specific weights.

Advantages:

- Minimized distortion to the materials due to absence of any moving blades
- No contamination due to the closed area by only stainless steel walls
- Especially suitable to mix powders or granules which are temperature sensitive, easily oxidizable, crystallized, volatile, poisonous or with irritating smell
- Many options are available as variable speed, automatic stop in discharge position, air operated valve, touch screen operating panel, safety fence, etc.

PerMix Tec Co., Ltd Room 1-1214, No.1888, Fax: +86-21-3375-8218 N. Shengxin Rd, Jiading,

Tel: +86-133-9116-8218 www.permixtec.com Shanghai, 201807, China www.permix-mixing.com

How It Works:



The PerMix PVM series V shaped Mixer has a "V" chamber made up by two cylinders. Powders and granules are fed into the V chamber either manually or by a vacuum conveyor.

A gear motor drives V chamber to roll in 360 degrees. This multi-dimensional motion makes the powders and granules inside tumbling up and down and colliding to each other all the time, and achieve uniform mixing in short time.

Features & Options:



The simplicity of design of the PerMix PVM series V shaped Mixer allows a low initial cost, easy maintenance and simple operation. It is available from the 2 liter laboratory to large industrial 6000 liter units. The PerMix PVM series V shaped Mixer can be supplied with a variety of accessories, including:

- Internal choppers
- Vacuum/Drying execution



PerMix Tec Co., Ltd Tel: +86-133-9116-8218 Room 1-1214, No.1888, Fax: +86-21-3375-8218 N. Shengxin Rd, Jiading,

www.permixtec.com Shanghai, 201807, China www.permix-mixing.com

- Special spray unit
- Special safety fence
- Mobile trolley
- PLC control & touch screen

Applications:

The PerMix PVM series V shaped Mixers are widely used in pharmaceuticals, colors, plastics resins, food products, ceramic glazes, metal powders, cosmetics, detergents, insecticides, explosives materials, and a lot of others.

- Pharmaceuticals

Supplements, Active ingredients, Silica, Sugar, Tablet coating

- Chemicals

Graphite, Alumina, Inorganic powder, Dye stuff, Silica, Adhesives, Agricultural supplements, Plastic powders, Colored cement mixes, Glass ingredients, Insulation materials

- Food & Beverage

Sugar, Aspartame, Fragrance, Spice, Dextrin, Chocolate mixes

- Cosmetics & Daily Care

Baby powder, Tooth paste, Cosmetic creams, Detergents, Cleaning compounds

Specifications:

Model	Total Volume, Liter	Operation Volume, Liter	Power, kW	Length,	Width, mm	Height, mm	Operation Height, mm
PVM-15	15	7	0.37	700	525	1,100	1,150
PVM-45	45	20	0.55	1,000	760	1,300	1,400
PVM-100	100	50	0.75	1,200	990	1,500	1,630
PVM-200	200	100	1.1	1,560	1,240	1,715	1,890
PVM-300	300	150	1.5	1,750	1,400	1,900	2,000
PVM-500	500	250	2.2	2,200	1,600	2,550	2,825
PVM-700	700	350	3	2,400	1,900	2,720	2,970
PVM-1000	1,000	500	4	2,670	2,120	2,850	3,150
PVM-2000	2,000	1,000	5.5	3,550	2,680	2,280	2,660
PVM-3000	3,000	1,500	7.5	4,050	3,060	2,620	3,050
PVM-4000	4,000	2,000	11	4,450	3,350	2,880	3,300
PVM-5000	5,000	2,500	15	4,800	3,570	3,070	3,550

- 1. All specifications are as accurate as is reasonably possible, but they are not binding.
- 2. Customized sizes are available against request.
- 3. PerMix reserves the right to modify the design without notice.



PerMix Tec Co., Ltd Room 1-1214, No.1888, N. Shengxin Rd, Jiading,

Tel: +86-133-9116-8218 Fax: +86-21-3375-8218 www.permixtec.com Shanghai, 201807, China www.permix-mixing.com

Gallery:



www.permix-mixing.com

PVM V Mixer with Safety Bar



www.permix-mixing.com

V Trough of Lab-size PVM Mixer



www.permix-mixing.com

Standard PVM V-shaped Mxier



www.permix-mixing.com

Special Design with Interchangeable Troughs



PerMix Tec Co., Ltd Room 1-1214, No.1888, N. Shengxin Rd, Jiading, Shanghai, 201807, China

Tel: +86-133-9116-8218 Fax: +86-21-3375-8218 www.permixtec.com www.permix-mixing.com



www.permix-mixing.com

PVM Tumbler Mixer in All Carbon Steel



www.permix-mixing.com

PVM Mixer in All Stainless Steel