

6116 Series Exit Devices


Exit Alarm Kit

Installation Instructions

ACCENTRA

ASSA ABLOY

For use with all 6000 Series Exit Devices except Surface Vertical Rod



NOTE: This kit may be used to upgrade the Touchbar Alarm on the following product series:

- 6100F
- 6130F
- 6150F
- 6160F
- 6220
- 6250

WARNING

This product can expose you to lead which is known to the state of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

WARNING

Attention Installer: Any retrofit or other field modification to a fire rated opening can potentially impact the fire rating of the opening, and ASSA ABLOY makes no representations or warranties concerning what such impact may be in any specific situation. When retrofitting any portion of an existing fire-rated opening, or specifying and installing a new fire-rated opening, please consult with a code specialist or local code official (Authority Having Jurisdiction) to ensure compliance with all applicable codes and ratings.

80-9460-6011-000 05/25

1-855-557-5078 Ext. 2 • www.accentra-assaabloy.com

Copyright © 2015, 2023-2025, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.


Experience a safer
and more open world

Table of Contents

- A. Verify Parts. 3
- B. 6116 Series Exit Alarm Kit - Exploded View 3
- C. Remove Device Assembly 4
- D. Remove Existing Cover 4
- E. Activate and Test the New Alarm Assembly. 5
- F. Mounting the Switch Lever 6
- G. Exit Bar Installation 10
- H. Testing 11
- I. Troubleshooting 11
- J. Maintenance. 11

Acronym	Definition
PPHMS	Phillips Pan Head Machine Screw
PFHUMS	Phillips Flat Head Under Cut Machine Screw
PFHWS	Phillips Flat Head Wood Screw
PPHSMS	Phillips Pan Head Sheet Metal Screw
PHPNHD	Phillips Pan Head Self Tapping Screw

Tools Required



6116 Series Exit Devices

Exit Alarm Kit
Installation Instructions



A. Verify Parts

- 1. Unpack and verify the components received using the parts list and the exploded view in **Figure 1**.
- 2. Read the entire instructions before installing this kit.
- 3. Follow all cautions, notes and warnings presented in these instructions.
- 4. All dimensions listed are in inches (") and millimeters (mm).

Important:

- Be sure to install the device on the correct door and confirm the device function, finish and size.
- Use site survey to verify the correct product was ordered.
- This product is intended to be a replacement alarm kit or an update for the Touchbar Exit Devices.

B. 6116 Series Exit Alarm Kit - Exploded View

The 6116 Series Exit Alarm Kit consists of the contents shown in **Figure 1**; additionally the kit requires a 9-Volt Battery which is not included, but is shown in the figure for placement.




Figure 1: Exploded View of the 6116 Series Exit Alarm Kit

P/N: 60-6700-0993-000:

Switch Lever with the magnet attached




Figure 1 - Exploded View of the 6116 Series Exit Alarm Kit

Table 1: Cylinder Collar Specifications		
Cylinder Collar Height	Cylinder Collar Finish	Cylinder Length
.156"	Brass or Bronze	1-1/4"
.281"	Brass or Bronze	1-3/8"
.406"	Brass or Bronze	1-1/2"
.594"	Brass or Bronze	1-11/16"

C. Remove Device Assembly


The Device Assembly must first be removed from the door to install the Exit Alarm Kit. Refer to **Figure 2** while following the steps to remove the Device Assembly:

1. Remove the following hardware (retain for re-installation):

- Cover Screws and Cover
- Device Endcap Screw and Device Endcap
- Clamp Screws and Clamp
- Device Assembly Screws

2. Remove the Device Assembly from the door and place it on a flat surface.


Figure 2:
Device
Assembly
Removal



D. Remove Existing Cover

1. Slide the existing cover off the Carrier, see **Figure 3**.
2. If a dogging mechanism exists, remove it.

Figure 3:
Cover Removal



6116 Series Exit Devices

Exit Alarm Kit Installation Instructions

ACCENTRA


ASSA ABLOY

E. Activate and Test the New Alarm Assembly

Important: Be sure to completely read through this section, in its entirety, prior to proceeding.

1. If necessary for retrofit applications, cut a new Cover Skirt the same size as the old cover. Dispose of the old cover.
NOTE: The Cover Skirt can be cut to a minimum length of 9-1/4" (235mm).
2. Place a 9-Volt battery securely into the Battery Bracket Clips found on the Back of the Alarm Assembly. Push the battery in to engage contacts (**Figure 4A**).
3. Press and hold the lever on the Touchbar Switch. Move the Cylinder Switch down. The Light-Emitting Diode (LED) will indicate that sensor power is on. A short chirp will indicate that the alarm is activated.
4. Release the lever on the Touchbar Switch and the alarm will sound.
5. Move the Cylinder Switch back up to the top position to turn off the alarm.

Figure 4A: Activate and Test the New Alarm Assembly



80-9460-6011-000 05/25


1-855-557-5078 Ext. 2 • www.accentra-assaabloy.com

Copyright © 2015, 2023-2025, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

Experience a safer
and more open world

1. Push the alarm assembly into the cover skirt assembly (**Figure 4B**).
2. Insert the cylinder, collar (if required) and activator and nut. Tighten nut. Be sure that the activator is sitting properly and can move freely.
3. Be sure the LED aligns with the LED opening on the Cover Skirt Assembly.
4. Screw the Lock Washer into the Cover Skirt Assembly.


Figure 4B:
Alarm Assembly



F. Mounting the Switch Lever

1. Remove the Rear End Cap using a #2 square socket screwdriver (**Figure 5A**).

Figure 5A :
Removing the Rear End Cap



6116 Series Exit Devices


Exit Alarm Kit Installation Instructions

ACCENTRA

ASSA ABLOY


2. Screw the Switch Lever onto the Rear Pivot Assembly using a self tapping screw (**Figure 5B**).
3. Screw the Rear End Cap back into the Assembly.

Figure 5B:
Switch Lever



- Slide the Cover Skirt Assembly while pressing the Touchbar down enough so the Touchbar Switch clears the top edge of the Rear End Cap (**Figure 5C**).

Figure 5C: Cover Skirt Assembly Placement



6116 Series Exit Devices


Exit Alarm Kit Installation Instructions

ACCENTRA

ASSA ABLOY

5. Push the Alarm Assembly until the Lockwasher prevents further advancement (**Figure 5D**).
When the Touchbar is pressed, the Switch Lever will move up and down enough to make contact with the Alarm Switch.
6. Reinstall all device covers and screws.

Figure 5D: Cover Skirt Assembly



80-9460-6011-000 05/25

1-855-557-5078 Ext. 2 • www.accentra-assaabloy.com


Copyright © 2015, 2023-2025, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

Experience a safer
and more open world

G. Exit Bar Installation


1. Reinstall the Device Assembly on the door (**Figure 6A**).

**Figure 6A:
Device Assembly
Installed on the Door**



2. Adhere the Emergency Exit Alarm Label onto the flat portion of the Touchbar (**Figure 6B**).

Figure 6B: Adhere Emergency Exit Alarm Label



6116 Series Exit Devices

Exit Alarm Kit Installation Instructions

H. Testing

1. Check the following parts to be sure they are operating properly:
 - Trim and Touchbar
 - Strike Plate and Bolt Engagement
 - Key
2. Test the alarm, as follows:
 - a. To actuate the alarm, turn the key clockwise. Wait 20 seconds to hear a confirmation chirp.
 1. Press the Touchbar to be sure the alarm sounds.
 2. Turn the key counter-clockwise to shut off the alarm.
 - b. Actuate the alarm again by turning the key clockwise. Wait 20 seconds to hear a confirmation chirp.
 1. Slide the Alarm Assembly as if removing it. The alarm should sound.
 2. Turn the key counter-clockwise to shut off the alarm.
3. Testing is complete if the alarm was activated successfully in numbers **2.a.1.** and **2.b.1.**
4. Refer to Section I if the alarm did not sound during testing.

I. Troubleshooting

If the Alarm will not sound, check the following:

- The Switch Lever may be out of position.
The end of the Switch Lever should be touching the Alarm Switch. Turn the Switch Lever Screw until the end contacts the Alarm Switch (**Section F**).
- The Battery is not connecting.
Be sure the battery is placed securely. Press to make contact (**Section E**).
- The Alarm is not armed.
To actuate the alarm, turn the key clockwise. Wait 20 seconds to hear a confirmation chirp. The Battery needs to be replaced.

If the Alarm chirps every 30 seconds:

- This is a low battery indicator and the battery needs to be replaced.

J. Maintenance

Periodically replace the 9-Volt battery to keep the Alarm Switch Activator working properly.

