

INSTRUKCJA MONTAŻU

MONTAŻ ZA POMOCĄ KLEJU



1. Przed instalacją wyczyść i osusz powierzchnię.



2. Posmaruj klejem brzegi dotykające ściany.



3. Przyklej do ściany i dociskaj przez 3-5 sekund.



4. Przyklej wieszak do ściany taśmą z zestawu- od zewnątrz.



5. Pozostaw na 48h.



6. Odklej taśmę. Gotowe do użytku!

UWAGI DODATKOWE

Jeżeli chcesz zdemontować wieszak, użyj suszarki do włosów.

Kieruj na wieszak gorący strumień powietrza przez 5 minut - to znacznie ułatwi usunięcie wieszaka i resztek kleju ze ściany.

OSTRZEŻENIE

Opakowanie oraz torby foliowe nie są zabawką, należy trzymać je poza zasięgiem dzieci, w przeciwnym przypadku istnieje ryzyko uduszenia lub poważnego uszczerbku na zdrowiu.

KONSERWACJA I CZYSZCZENIE

Zalecamy używać środków przeznaczonych do czyszczenia tworzyw sztucznych, nie zawierających środków chemicznych. Stosowanie się do powyższych zaleceń pozwoli na bezpieczną i długą eksploatację. Wady wynikające z niewłaściwego użytkowania nie są podstawą do roszczeń z tytułu reklamacji. Meble przeznaczone do użytku domowego. Elementy ruchome należy konserwować środkami do tego przeznaczonymi.

Installation Instructions

INSTALLING WITH GLUE



1. wipe clean the wall till



2. apply the drill-free glue



3. Press for 3-5 seconds

It is complete dry before install

on the mounting surface



4. Use ont-time adhesive tape



5. Wait 48hours



6. Finish ,use

NOTE:

IF YOU WANT TO REMOVE THE UNIT ,JUST AIM THE HAIR DRYER AT THE BONDING AREA AND BLAST IT WITH HEAT FOR 3-5MINUTES

WARNING!

Packaging and plastic bags are not toys, they should be kept out of the reach of children, otherwise there is a risk of suffocation or serious damage to health.

MAINTENACE AND CLEANING

We recommend that you use detergents intended for cleaning plastics, which do not contain chemicals. Following the above recommendations will allow for safe and long operation. Defects resulting from improper use do not constitute grounds for claims arising from the complaint. Intended for home use. Moving parts should be maintained with agents designed for this purpose.