

## USER MANUAL

Thank you for having chosen our product. For your own safety, please read the user manual carefully before installing it.

Random program for rotation direction: clockwise or counter clockwise in 360 degree.

### SPECIFICATIONS TECHNIQUES

Article	NA250	
Power Supply	AC110-120V AC220-240V	
Power Consumption	4W	
Rotation Speed	60s ±5s	
Max. Loading Weight	10kg 20kg 25kg 30kg	
Product Dimensions	Dia25cm, H6cm	
Net Weight	1.2kg/pc	

### OPERATION INSTRUCTIONS:

#### CAUTION!

**Be careful with your operations. With a dangerous voltage you can suffer a dangerous electrical shock when touching the wires.**

#### CAUTION!

**Be careful with your operations. With a dangerous voltage you can suffer a dangerous electrical shock when touching the wires.**

#### Important:

Damages caused by the disregard of this user manual are not subject to warranty. The dealer will not responsible for any resulting defects or problems.

- This product is designed for indoor use only.
  - Don't expose the device to extreme heat, moisture or dust.
  - The ambient temperature must always be between -5°C to +45°C.
  - The relative humidity must not exceed 50% with an ambient temperature of 45°C.
  - The device must only be operated in an altitude between 20 and 2000m.
  - Never operate or stockpile the device in surroundings where splash water, rain, moisture or fog which may harm it. Moisture or very high humidity can reduce the insulation and lead to mortal electrical shock or injury.
- 
- Never touch the device with wet hands, as it could lead to mortal electrical shock or injury.
  - Make sure that the power cord is never crimped or damaged by sharp edges, check device and power cord periodically.
  - If extension cords are used, make sure the core diameter is sufficient for the required power consumption of the device.
  - The voltage and frequency must exactly be the same as stated on the device. Wrong voltage or power outlet could lead to destruction of the device and to mortal electrical shock or injury.
  - Never pull out the plug by tugging the power cord, which could result in cord or plug damage and lead to mortal electrical shock and injury.
  - Never use the device during the thunderstorm, over voltage could destroy the device.
  - Operate the device only after having familiarized with its functions. Most damages are the result of improper operations.
  - Please use the original packaging in case the device is to be transported.

- Any unauthorized modifications on the device is forbidden due to safety consideration.
- No liquid or any objects enter into the device, otherwise malfunction or short-circuits may cause mortal injuries.
- Considering longer service life, the product should be suspended around 2 hours in case it has been working more than 12 hours continuously.
- Keep the children away from the device.

#### **MAINTENANCE AND REPAIR**

#### **DANGER TO LIFE!**

**Disconnect from mains before starting maintenance operation!**

**DANGER TO LIFE!**

**Disconnect from mains before starting maintenance operation!**

- We recommend a frequent cleaning of the device. Please use a soft lint-free dry cloth. Never use alcohol or solvents.
- There are no serviceable parts inside the device. Maintenance and service operations are only to be carried out by qualified professionals.
- Should you need any spare parts, please contact us.