

Picnic Tap 2.0™

no beer line • no excessive foam • no drip tray



How to use Picnic Tap 2.0:

- Sanitize & keep your Picnic Tap 2.0 cold to reduce foaming at first pour
- Do not overtighten the anodized tube more than necessary to avoid squeezing the last O-ring too much which would create tiny bubbles
- The **Compact Progress Flow Reducer** (CPFR) can be trimmed off at the downstream end (with narrow gaps) to increase the flow
- Hold on the anodized tube while swiveling the twist tap
- Always turn (twisting) the tap knob fully until you feel a click.

How to keep Picnic Tap 2.0 sanitized between uses:

1. Put a ball lock line cleaning cap adapter for soda bottle (\$7) on any squeeze-able soda bottle of your choice. *I find a 10-oz PET Canada Dry Club Soda is great because it has squeeze-able sturdy wall that bounces back.*
2. Fill it with your typical no-rinse Starsan solution.
3. Connect the Picnic Tap 2.0 to the ball lock cap with its twist tap opened and pointed up.
4. Hold the bottle upside down over a sink and squeeze to flush the Picnic Tap 2.0 with roughly 3 – 4 oz of Starsan solution
5. Set the bottle down in upright position to let Starsan solution drained back into the bottle.
6. Close the twist tap and store the Picnic Tap 2.0 preferably in a fridge to keep it cold ready for the next deployment.

To have good pour, you need:

- Cold beer
- Cold tap
- Slow flow

Coming soon on

KICKSTARTER

Contact **Trong Nguyen**
 to be an early adopter:
trong@homebrewerlab.com

Patent pending

