



Strike Preparation

Device Preparation

NOTES:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR active pair shown. Preparation is typical for both hands.
4. Minimum door stile width 4-1/2" (114).
5. Prepare mounting holes when installing the device.
6. Lock support by door manufacturer.
7. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components.
8. Holes for optional SNB: 9/32" (7.00) dia. inside door face; 3/8" (9.50) dia. outside door face

9. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.
10. For outside trim preparation see appropriate trim template.
11. Unless otherwise specified, door preparation and dimensional tolerances must conform to ANSI A115.1 (lock) and A115.14(strike).
12. Dimensions given about a centerline are symmetrical.
13. Latchbolt centerline is 23/32" (18.2) below & Auxbolt centerline is 3/16" (4.8) above the centerline of lockfront.
14. Strike clearance required 7/8" (22.2) deep on inside and 1/8" (3.2) deep on outside face.

RESPONSIBILITY
DOOR AND FRAME MANUFACTURERS ARE
RESPONSIBLE FOR PROVIDING ADEQUATE
CONSTRUCTION OR REINFORCEMENTS FOR
PROPER INSTALLATION OF HARDWARE SHOWN.
ALL ARCHITECTURAL BUILDERS HARDWARE MUST
BE INSTALLED ON PROPERLY REINFORCED
DOORS AND FRAMES, REGARDLESS OF TYPE,
MATERIAL, OR METHOD OF CONSTRUCTION.

1530 and 1530F Mortise Exit Devices with Optional 718 Open Back Strike

Application to Pair of Metal Doors without Mullion

1-855-557-5078 Ext. 2

www.accentra-assaabloy.com

Experience a safer
and more open world

Copyright © 1999, 2023, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES 7415-0032 (12/23)		DO NOT SCALE DRAWING	
TEMPLATE NUMBER		SHEET	DATE
7415-0032		1 of 1	05/24