



## Notes:

- 1. Do not scale drawing.
- 2. Dimensions are in inches (mm).
- 3. LHR door shown. Preparation is typical for both door hands.
- Minimum door stile width 4-1/2(114).
- 5. Prepare mounting holes when installing the device.
- 6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
- This hole MUST be field located using physical part as template, after installation is complete and device is fully operational.
- 8. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components.
- Holes for optional SNB: 9/32 (7.00) dia. inside door face; 3/8 (9.50) dia. outside door face.
- 10. Provide door stiffeners, as needed to prevent door collapse due to installation with power tools, door use, or abuse.
- 11. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.





## RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

## 2110 & 1810 **Surface Vertical Rod Panic Exit Devices** with Bottom Pullman Latch Option

(6)

Application for Metal Door and Frame with Latching Threshold

1-855-557-5078 Ext. 2 www.accentra-assaabloy.com **ASSA ABLOY** 

Experience a safer and more open world Copyright © 2010, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES DO NOT SCALE DRAWING 04/10 TEMPLATE NUMBER SHFFT 04-24 7421-0016 1 of 1

ACCENTRA