


Technical drawing showing the front view of a door lock assembly. The drawing includes the following dimensions and labels:

- Overall Height:** 1 (25)
- Distance from Top to Center:** 7/8 (22)
- Distance from Center to Left Handle:** 25/32 (20)
- Distance from Center to Right Handle:** 9/16 (14.3) (Typ.)
- Overall Width:** 1-9/16 (40)
- Labels:**
  - Rods & Strikes
  - Inside Face of Door
  - 10-24 Tap (2 Places)
  - 10-24 Tap (See Note 7)

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR door shown. Preparation is typical for both door hands.
4. Minimum door stile width: 4-1/2 (114).
5. Prepare mounting holes when installing the device.
6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
7. This hole **MUST** be field located using physical part as template, after installation is complete and device is fully operational.
8. For outside trim preparation see appropriate trim template.
9. Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse.
10. Device mount to hinge stile (not shown) requires hole location and preparation during device installation. Door structural requirements to support the device cases are similar for both door stiles.
11. Wood screws #14 x 1-1/2" (by others) permitted for solid core wood doors if pilot holes are used for installation, when door label allows its use.



SUPERSEDES 04/10		DO NOT SCALE DRAWING	
TEMPLATE NUMBER 7421-1011		SHEET 1 of 1	DATE 04/24