



791 STRIKE DETAIL




Notes:

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR door shown. Preparation is typical for both door hands.
4. Minimum door stile width: 4-1/2 (114).
5. Prepare mounting holes when installing the device.
6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
7. This hole **MUST** be field located using physical part as template, after installation is complete and device is fully operational.
8. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components.
9. Holes for optional SNB: 9/32 (7.00) dia., inside door face; 3/8 (9.50) dia., outside door face.
10. Provide door stiffeners, as needed to prevent door collapse due to installation with power tools, door use, or abuse.
11. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.
12. For outside trim preparation see appropriate trim template.
13. For electrical devices (suffixes "-B", "-G", "-O", "-P", "-S", MELR) also see template 7477-0001.



794 STRIKE DETAIL

Typical Top & Bottom Door Detail (Door Face Cutout Top Only, As Shown)



7120, 7125 & 7120F
Concealed Vertical Rod Exit Devices
 Application for Metal Door and Frame
 With 1/2" Threshold and 794 Optional Floor Strike
 1-855-557-5078 Ext. 2
www.accentra-assaabloy.com

ACCENTRA®
ASSA ABLOY

Experience a safer
 and more open world

Copyright © 2000, 2024, 2025, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

| | | | |
|-----------------|-----------|----------------------|-------|
| SUPERSEDES | 04/24 | DO NOT SCALE DRAWING | |
| TEMPLATE NUMBER | 7470-0021 | SHEET | DATE |
| | | 1 of 1 | 09/25 |