


INSIDE FACE OF DOOR

Face of stop

Notes:

- 1. Do not scale drawing.
- 2. Dimensions are in inches(mm).
- 3. LHR door shown. Preparation is typical for both door hands.
- 4. Minimum door stile width: 3-1/2(89).
- 5. Prepare mounting holes when installing the device.
- 6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
- 7. Dimension from door face.
- 8. For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device componenets.
- 9. Holes for optional SNB: 9/32(7.00) dia., inside door face; 3/8 (9.50) dia., outside door face.
- 10. Provide door stiffeners, as needed to prevent door collapse due to installation with power tools, door use, or abuse.
- 11. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.



RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

7200M & 7205M Rim Panic Devices for Narrow Escutcheon Trim - 757 Strike

Finished Floor

Application for Metal Door and Frame or Mullion (Not for Fire Labeled Devices) 1-855-557-5078 Ext. 2

www.accentra-assaabloy.com

ACCENTRA **ASSA ABLOY**

Experience a safer and more open world Copyright © 1999, 2008, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES 7473-0000 01/24

TEMPLATE NUMBER

FOR MULLION MODEL NUMBERS M200FWS AND KRM200FWS REFER TO TEMPLATE NUMBER 7400-0210.

> SHEET 7473-0000 1 of 1

06/24

DO NOT SCALE DRAWING