
Notes:




Inside Face Of Door

Vertical Reference

- 1. Do not scale drawing.
- 3. LHR door shown. Preparation is typical for both door hands.
- 4. Minimum door stile width: 3-1/2 (89).

2. Dimensions are in inches (mm).

- Prepare mounting holes when installing the device.
- Unreinforced frames require blind rivet nuts (by others) to mount the strike.
- Dimension from door face.
- For recommended door reinforcements see template 7400-0000. Unreinforced doors require SNB option to mount the device components and strike interlock.
- 9. Holes for optional SNB: 9/32 (7.00) dia. inside door face: 3/8 (9.50) dia. outside door face.
- 10. Provide door stiffeners as needed to prevent door collapse due to installation with power tools, door use, or abuse.
- 11. Device mount to hinge stile (not shown) requires hole location and preparation during device installation.



RESPONSIBILITY

DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

7200MF Rim Panic Devices for Narrow Escutcheon Trim - 757F Strike

Application for Fire Labeled Metal Door and Frame or Mullion

1-855-557-5078 Ext. 2 www.accentra-assaabloy.com ACCENTRA **ASSA ABLOY**

Experience a safer and more open world

Copyright © 2001, 2008, 2024, ASSA ABLOY Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES 7473-0002 01/24

7473-0002

DO NOT SCALE DRAWING

TEMPLATE NUMBER

SHEET 1 of 1

05/24