

Rods & Strikes

Inside Face of Door

10-24 Tap (2 Places)

10-24 Tap (See Note 7)

25/32 (20)


9/16 (14.3) (Typ.)

1-9/16 (40)

1 (25)

7/8 (22)

1. Do not scale drawing.
2. Dimensions are in inches (mm).
3. LHR door shown. Preparation is typical for both door hands.
4. Minimum door stile width: 4-1/2 (114).
5. Prepare mounting holes when installing the device.
6. Unreinforced frames require blind rivet nuts (by others) to mount the strike.
7. This hole **MUST** be field located using physical part as template, after installation is complete and device is fully operational.
8. For outside trim preparation see appropriate trim template.
9. Provide adequate structural support to maintain door integrity after device installation with power tools, door use, or abuse.
10. Device mount to hinge stile (not shown) requires hole location and preparation during device installation. Door structural requirements are similar for both door stiles.
11. For electrical devices (suffixes "-B", "-G", "-O", "-P", "-S", MELR) see also template 7477-0001.
12. Wood screws (#14 x 1-1/4", by others) permitted for solid core wood doors if pilot holes are used for installation.



Reinforcement for 791 Strike (See Note 6)

Lock Edge

Face of Door

2-3/4 (70)

Inside Face of Door

2-1/4 (57)

1-5/16 (33.3)

11/16 (17.5)

16-3/8 (416)

1-1/4 (31.8)

3-5/8 (92)

3-5/8 (92)

39-15/16 (1014)

1-1/4 (31.8)

15 (381)

1-5/16 (33.3)

1-7/8 (48)

1/4 (6) Recommended 3/4 (19) Maximum

702 Strike

CL Rods

CL Vertical Reference

CL Rods & Strikes

CL Horizontal Reference (Device Centerline)

140 (3.50) Dia. x 3/4 (19) Deep This Face (4 Places)

3/8 (9.50) Dia. Thru (6 SNB Holes) -See Note 12-

Bottom of Door

Finished Floor

Copyright © 1999, 2024, 2025, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.