



NOTES:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Prepare mounting holes when installing trim.
6. Provide adequate structural support to maintain door integrity during

Hole	Specification
A	1/2(12.50) Dia. Thru Door
B	3/8(9.50) Dia. X 3/4(19) Deep



<p><b>RESPONSIBILITY</b> DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.</p>	<p><b>513(F), 517(F), 518(F) and 519(F)</b> <b>Narrow Escutcheon Trim</b> With 7200(M) or 7200(MF) Series Rim and Vertical Rod Exit Devices Wood or Composite Door Preparation 1-855-557-5078 Ext. 2 <a href="http://www.accentra-assaabloy.com">www.accentra-assaabloy.com</a></p>	<p><b>ACCENTRA</b> <b>ASSA ABLOY</b></p>
<p>Experience a safer and more open world</p>	<p>Copyright © 1999, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.</p>	<p>SUPERSEDES 8/99 DO NOT SCALE DRAWING TEMPLATE NUMBER 7400-1513 DATE 04/24</p>