



**NOTES:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Prepare mounting holes when installing trim.
6. Provide adequate structural support to maintain door integrity during operation.
7. With rim and surface vertical rod exit devices, stock doors with ANSI A115.W2 cutout may be substituted (specifier's option). These doors require a filler plate for the door edge cutout (by others).
8. Dimensions given about a centerline are symmetrical.



**RESPONSIBILITY**  
DOOR AND FRAME MANUFACTURERS ARE  
RESPONSIBLE FOR PROVIDING ADEQUATE  
CONSTRUCTION OR REINFORCEMENTS FOR  
PROPER INSTALLATION OF HARDWARE SHOWN.  
ALL ARCHITECTURAL BUILDERS HARDWARE MUST  
BE INSTALLED ON PROPERLY REINFORCED  
DOORS AND FRAMES, REGARDLESS OF TYPE,  
MATERIAL, OR METHOD OF CONSTRUCTION.

Experience a safer  
and more open world

Copyright © 2015, 2023-2025, ASSA ABLOY Access and Egress Hardware Group, Inc.  
All rights reserved. Reproduction in whole or in part without the express written  
permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited

**541F, 546F, 549F and 548F Series Trim**  
With 2100(F), 6100(F), or 7100 (F) Series  
Rim and Vertical Rod Exit Devices  
Wood Door Preparation  
1-855-557-5078 Ext. 2  
[www.accentra-assaabloy.com](http://www.accentra-assaabloy.com)

**ACCENTRA**  
**ASSA ABLOY**

SUPERSEDES 7400-1541 (05/24)		DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7400-1541	SHEET	1 of 1
DATE	10/25		