

KVF-TDH Series 60W

Whole Family: KVF-XXXXX-TDH 12V/ 24V/ 48VDC - [30W 60W 80W 96W 100W 120W 150W 200W 300W 320W 360W 500W 600W]













Features

Output: Constant Voltage Range: 200-240VAC

PFC design: Built-in active PFC function

Efficiency: Up to 83%

Protections: Short circuit/ over load/ over temperature

Heat dissipation: Cooling by free air convection

Waterproof performance: IP20

Dimming features: Fine-tune the voltage by the knob

Dimming function: Phase dimming: work with leading edge, MLV and trailing edge, ELV, TRIAC dimmers.

Dimming range: 0-100%

Application: Suitable for the application of LED lighting

Warranty: 5 years warranty **PWM Output Frequency** 20KHz (Flicker-free)





Specification


Model		KVF-12060-TDH	KVF-24060-TDH	KVF-48060-TDH
Certificate		ENEC / SAA(GMA certificate) / CCC / CE / CB / RoHS / Reach		
Output	DC Voltage	12V (10-13V adjust by knob)	24V (21.5-25.5V adjust by knob)	48V (46-50V adjust by knob)
	Voltage Tolerance	±0.5V		
	Voltage Regulation	≤2% ≤1%		
	Rated current	5A	2.5A	1.25A
	Rated power	60W		
	Load Regulation	≤0.5%		
Input	Voltage Range	200-240VAC		
	Frequency Range	47 - 63Hz		
	THD(Typ.) @ full load	<20%@200VAC @230VAC @240VAC		
	Efficiency @ full load	83%@230VAC		
	AC Current (Max.)	0.5A		
	Inrush Current (Typ.)	80.8A,186us@230VAC		
	Leakage current	<0.5mA		
Protection	Short Circuit	Hiccup mode, re-power on to recover after fault condition removed		
	Over Load	≤120% Hiccup mode, recovers automatically after fault condition is removed		
	Over temperature	Shell surface temp.100℃±10℃ shut down o/p voltage,automatically recover after the		
	Overtemperature	temperature drops.		
Environment	Working TEMP.	-40~+60°C (see below derating curve)		
	Working Humidity	20 - 90%RH non-condensing		
	Storage TEM.,Humidity	-40 - +80℃,10 - 95% RH non-condensing		
	TEMP.coefficient	±0.03%/℃(0 - 50℃)		
	Vibration	10~500Hz, 2G 10min./1 cycle, period for 60min. each along X,Y,Z axes		
Safety & EMC	Safety standards	EN61347-1 EN61347-2-13 (EU)		
	Withstand voltage	I/P-O/P:3.75KVAC (EU)		
	Isolation resistance	I/P-O/P:100MΩ / 500VDC / 25°C / 70%RH		
	EMC Emission	EN55015 EN61000-3-2,3 (EU)		
Others	Net Weight	0.35Kg		
	Dimension	178*61*24mm(L*W*H)		
	Packing	290*215*140mm 20pcs /CTN		
Notes	 All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature. Tolerance: includes set up tolerance and load regulation. 			




Efficiency Curve (efficiency vs output load)







Derating Curve (output load vs TEMP.)





- 1. To extend their life, please refer to the Derating Curve and derate according to the temperature.
- 2. Please note that the rise in temperature of LED fixtures over a long period of time will cause their power to rise.


Therefore, we recommend the power supply to reserve a certain amount of load to avoid overloading.



Power Factor Curve








www.scpower.net.cn/en info@scpower.net.cn A/0

4/6



Mechanical Specification



12V&24V&48V Version

- 1. Input with DG126 terminals 3P: 3P Middle 1P is empty, Live Wire AC (L), Neutral Wire AC(N) .
- 2. Output LED SEC with DG126 terminals 2P: output Positive (LED+), output negative (LED-). Connected to LED Lamps.
- 3. Please make sure you connect these correctly otherwise your product will not function correctly and could be damaged.

Warm tips:


1. Any other requests for, we can customized.



Dimming Operation and Connecting Diagram

TRIAC/Phase cut dimming

- 1. The Pulse-Width Modulation (PWM) of output voltage can be adjusted through input terminal of the AC phase line(L) by connection a phase /Triac dimmer or lighting system.
- 2. Working with leading edge, MLV and trailing edge, ELV, TRIAC dimmers or light system.
- 3. Min. loading is about 10%.
- 4. Please try to use dimmers with power at least 1.5 times as the output power of the driver.





Instruction

- 1. This driver should be installed by qualified and professional person.
- 2. Please make sure the driver is installed with adequate ventilation around it to allow for heat dissipation.
- 3. Ensure that wiring is correct before test in order to avoid light and power supply damage.
- 4. If driver Cannot work normally, don't maintain privately.

Have any questions, please contact Zhuhai Shengchang.

Please visit our website or contact us for more information! www.scpower.net.cn/en