



NITRO AMP PRO

User Guide

TABLE OF CONTENTS

(1.0) Introduction	3
(1.1) Box Contents	3
(1.2) Support.....	3
(1.3) Setup	4
(1.3.1) Connection Diagram.....	4
(2.0) Features	5
(2.1) Top Panel	5
(2.2) Rear Panel.....	6
(3.0) Operation.....	7
(3.1) Bluetooth	7
(4.0) Appendix	8
(4.1) Technical Specifications	8
(4.2) Trademarks & Licenses	8

(1.0) Introduction

(1.1) Box Contents

Nitro Amp Pro

Power Cable

Quickstart Guide

Safety & Warranty Manual

(1.2) Support

For the latest information about this product (system requirements, compatibility information, etc.) and product registration, visit [alesis.com](https://www.alesis.com).

For additional product support, visit [alesis.com/support](https://www.alesis.com/support).


(1.3) Setup

1. Power on Nitro Amp Pro.
2. Connect your line-level devices (drum module, mixer, etc.) to the Channel 1 and Channel 2 **Inputs**.
3. Adjust the Nitro Amp Pro Channel 1 and Channel 2 **Volume knobs** to the 12 o'clock position.
4. Start with your sound device at its lowest setting. Begin playing, and slowly raise the volume control until the sound heard from Nitro Amp Pro's speaker is at your desired volume, clear and undistorted.


(1.3.1) Connection Diagram

Items not listed in [\(1.1\) Box Contents](#) are sold separately.

Example A: Nitro Amp Pro (Mono)




Example B: Two Nitro Amp Pros (Stereo)



(2.0) Features

(2.1) Top Panel



A. Power LED

This LED will be lit red when powered on.

B. Bluetooth® LED

This LED will be lit solid blue when paired to a Bluetooth device.

C. Input

Use 1/4" (6.35 mm) cables (not included) to connect your drum module or other input source to these balanced line-level inputs.

D. Input Volume

Turn this knob to adjust the gain of the input.

E. Lows Tone Control

Turn this knob to adjust the low-end frequency sound.

F. Highs Tone Control

Turn this knob to adjust the high-end frequency sound.

G. Bluetooth Volume

Turn this knob to enter pairing mode and adjust the volume of the Bluetooth audio. Turn all the way to the left until a click is heard to turn off Bluetooth pairing.

H. Power Switch

Use this switch to power the speaker on or off. It is normal to hear a popping sound when powering the speaker off.

(2.2) Rear Panel**A. Power Input**

Connect the included power cable here.

(3.0) Operation

(3.1) Bluetooth

1. Power on Nitro Amp Pro.
2. Turn the **Bluetooth Volume knob** from the OFF position to the right until a click is heard to power on Bluetooth and enter pairing mode.
3. Select “Alesis Nitro Amp Pro” from your Bluetooth device’s setup screen.
4. When paired successfully, the Bluetooth LED will be lit solid blue.

Note: When audio is being played from the connected Bluetooth device, the blue **Bluetooth LED** will blink indicating that Bluetooth audio is currently playing.

To control the input level, make sure your Bluetooth device volume is turned up and then adjust Nitro Amp Pro’s **Bluetooth Volume knob**.

To unpair, turn the **Bluetooth Volume knob** to the OFF position or disconnect from your Bluetooth device.

Note: The **Highs** and **Lows Tone Control** will not affect Bluetooth audio.

(4.0) Appendix

(4.1) Technical Specifications

Speakers	Low Frequency: 8" / 203 mm High Frequency: 2" / 50 mm
Frequency Response	45 - 18 kHz
Max SPL	102 dB
Wireless Technology	Bluetooth® <ul style="list-style-type: none"> - Classic Audio - Qualified against Bluetooth® Core 5.3 - Range: Up to 32.81 feet/10 meters - Transmitter Frequency Range: 2400 - 2500 MHz - Transmitter Power: 0.25 mW
Connectors	(2) 1/4" (6.35 mm) line-level inputs
Power	Input Voltage: 100 - 120 VAC, 220 - 240 VAC, 50/60 Hz Consumption: 30 W Fuse: 100-120V~F1AL AC250V, 220-240V~T0.5AL AC250V
Dimensions (height x width x depth)	12.7" x 13.0 x 14.0" / 32.3 x 33 x 36 cm
Weight	19.1 lbs. / 8.65 kg

Specifications are subject to change without notice.

* Bluetooth and wireless reception and range are affected by walls, obstructions, and movement. For optimal performance, place the product in the center of the room so it is unobstructed by walls, furniture, etc.

(4.2) Trademarks & Licenses

Alesis is a trademark of inMusic Brands, Inc., registered in the U.S. and other countries.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such marks by Alesis is under license.

All other product names, company names, trademarks, or trade names are those of their respective owners.

alesis.com