


Assembly Instructions

Niva Coffee Table


519287



Keep these instructions for future reference



WARNING

- ! Read instructions carefully. Check no parts are missing.
- ! Assemble the furniture on a soft level surface to avoid damaging the furniture or your floor.
- ! Carefully identify each component, especially those that are similar.
- ! The most common mistake is getting things back to front.
- ! Separate and identify each component from the hardware pack and rest each one in it's proper location before fastening.
- ! We recommend furniture be assembled near where they will be placed, to avoid moving the product unnecessarily once assembled.
- ! If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.
- ! Regularly check and re-tighten (if necessary) all bolts on furniture that you have assembled yourself.



ALLOW 60 MIN


2 Persons Required



DO NOT USE ON PRODUCT

Tools Required






Parts list

Box 1: Top Panel (P1); Bottom Panel (P2); Left Side Panel (P3); Right Side Panel (P4); Divider Panel (P5); Short Rail (P6); Long Rail (P7); 4 x Leg (P8); Back Panel (P9); Drawer Front (P10); Drawer Left Side (P11); Drawer Right Side (P12); Drawer Base (P13); Drawer Back (P14); Drawer Rail (P15); Big Middle Leg (P16); Small Middle Leg (P17); Metal Rail (P18); Hardware Pack.

Hardware Pack



45 x Cam Bolts
(H1)




39 x Big Cam
Nuts (H2)



30 x Dowels
(H3)




6 x Small Cam
Nuts (H4)



9 x Screws
(H5)
#10x38 mm



12 x Screws
(H6)
#6x12 mm



2 x Slides
(H7)



4 x Felt Feet
(H8)




4 x Screws
(H9)
#10x38 mm



1 x Adjustable
Foot (H10)






6 x Stickers
(H11)



4 x Screws
(H12)
#8x12 mm



Step 1


You will need	
	
13 x Cam bolts (H1)	Phillips head screwdriver



Screw 13 x cam bolts (H1) into bottom panel (P2) as shown, tighten with a Phillips head screwdriver.




Step 2


You will need	
	
14 x Dowels (H3)	Mallet



Insert 3 x dowels (H3) into each short rail (P6) as shown.
 Insert 4 x dowels (H3) into each long rail (P7) as shown.
 Use a mallet to gently tap the dowels into place if needed.



Step 3

You will need	
	
8 x Cam bolts (H1)	Phillips head screwdriver
	
4 x Felt feet (H8)	




Screw 2 x cam bolts (H1) into each leg (P8) using a Phillips head screwdriver.
Attach 1 x felt foot (H8) onto each leg (P8) as shown.


Step 4

You will need	
	
4 x Big cam nuts (H2)	Flat head screwdriver

Fit each short rail (P6) between 2 x legs (P8).
Insert 2 x big cam nuts (H2) each into short rail (P6).
Using a flat head screwdriver, turn the big cam nuts (H2) clockwise to lock.






This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Step 5


You will need	
	
4 x Big cam nuts (H2)	Flat head screwdriver



Position 2 x long rails (P7) between the assembled unit as shown.
Insert 4 x big cam nuts (H2) into long rails (P7), using a flat head screwdriver turn clockwise to lock.




Step 6




You will need	
	
10 x Big cam nuts (H2)	Flat head screwdriver



Position the leg assembly onto bottom panel (P2), making sure the cam bolts on the bottom panel (P2) are inserted into the holes on the leg assembly. Insert 10 x big cam nuts (H2) into short rails (P6) and long rails (P7), using a flat head screwdriver turn clockwise to lock. Carefully turn the unit over.



Step 7


You will need	
	
2 x Dowels (H3)	Phillips head screwdriver
	
#10x38 mm	
1 x Screw (H5)	



Insert 2 x dowels (H3) into small middle leg (P17) and big middle leg (P16). Attach small middle leg (P17) to big middle leg (P16) with 1 x screw (H5), tighten with a Phillips head screwdriver.

Step 8

You will need	
	
3 x Big cam nuts (H2)	1 x Adjustable foot (H10)
	
Flat head screwdriver	






Position middle legs (P16) & (P17) to bottom panel (P2).

Insert 3 x big cam nuts (H2) into middle legs (P16) & (P17), and turn clockwise to lock using a flat head screwdriver.

Screw 1 x adjustable foot (H10) into big middle leg (P16) as shown.

Step 9

You will need	
	
6 x Cam bolts (H1)	Phillips head screwdriver
	
#10x38 mm	
4 x Screws (H9)	2 x Stickers (H11)




Screw 6 x cam bolts (H1) into bottom panel (P2) as shown, tighten with a Phillips head screwdriver.

Screw 4 x screws (H9) into bottom panel (P2), tighten with a Phillips head screwdriver.

Paste 2 x stickers (H11) onto bottom panel (P2) to cover the holes as shown.




Step 10

You will need	
	
2 x Cam bolts (H1)	4 x Dowels (H3)
	
Mallet	Phillips head screwdriver




Insert 4 x dowels (H3) into divider panel (P5) as shown. Use a mallet to gently tap the dowels into place if needed. Screw 2 x cam bolt (H1) into divider panel (P5), using a Phillips head screwdriver as shown.


Step 11

You will need	
	
2 x Slides (H7)	3 x Screws (H6)
	
Phillips head screwdriver	



Separate the 2 sets of slide runners (H7-2) and slide tracks (H7-1) from slides (H7) by following the steps below: Extend the slide runner all the way forward. Press the plastic release lever of the slide down and pull the slide runner (H7-2) completely out.




Adjust runner to access the screw holes.





Note the position of the rubber stopper




Attach 1 x separated slide track (H7-1) onto divider panel (P5) with 3 x screws (H6), using a Phillips head screwdriver as shown. Pay attention to ensure the slide are in correct direction as shown.






Step 12


You will need	
	
2 x Cam bolts (H1)	8 x Dowels (H3)
	
Phillips head screwdriver	Mallet



Insert 4 x dowels (H3) each into side panels (P3) & (P4) as shown. Use a mallet to gently tap the dowels into place if needed. Screw 2 x cam bolts (H1) into left side panel (P3) using a Phillips head screwdriver.



Step 13


You will need	
	
1 x Slide track (H7-1)	3 x Screws (H6)
	
Phillips head screwdriver	



Attach 1 x separated slide track (H7-1) onto left side panel (P3) with 3 x screws (H6), using a Phillips head screwdriver as shown. Pay attention to ensure the slide are in correct direction as shown.



Step 14


You will need	
	
2 x Dowels (H3)	Mallet



Insert 2 x dowels (H3) into back panel (P9) as shown. Use a mallet to gently tap the dowels into place if needed.



Step 15


You will need	
	
4 x Big cam nuts (H2)	Flat head screwdriver



Attach side panel (P3) and divider panel (P5) to back panel (P9) with 4 x big cam nuts (H2), turn the big cam nuts (H2) clockwise to lock using a flat head screwdriver.




Step 16


You will need	
	
8 x Cam bolts (H1)	Phillips head screwdriver



Screw 8 x cam bolts (H1) into top panel (P1) using a Phillips head screwdriver as shown.



Step 17


You will need	
	
8 x Big cam nuts (H2)	Flat head screwdriver
	
2 x Stickers (H11)	



Attach panels (P3), (P4), (P5) and (P9) to top panel (P1) as shown.
 Insert 8 x big cam nuts (H2) into panels (P3), (P4), (P5) and (P9),
 turn the cam nuts (H2) clockwise to lock using a flat head screwdriver.
 Paste 2 x stickers (H11) onto right side panel (P4) to cover the cam nuts as shown.




Step 18


You will need	
	
#8x12 mm	
4 x Screws (H12)	Phillips head screwdriver



Position metal rail (P18) between divider panel (P5) and top panel (P1) as shown,
 fasten with 4 x screws (H12) using a Phillips head screwdriver.

Step 19

You will need	
	
6 x Big cam nuts (H2)	Flat head screwdriver
	
2 x Stickers (H11)	






Attach bottom panel (P2) to assembled unit as shown.

Insert 6 x big cam nut (H2) into panels (P3), (P4) and (P9), turn clockwise to lock using a flat head screwdriver.

Paste 2 x stickers (H11) onto right side panel (P4) to cover the cam nuts as shown.



Step 20


You will need	
	
#10x38 mm	
2 x Screws (H5)	Phillips head screwdriver



Fasten bottom panel (P2) to divider panel (P5) with 2 x screws (H5) using a Phillips head screwdriver as shown.



Step 21

You will need	
	
6 x Cam bolts (H1)	Phillips head screwdriver




Screw 6 x cam bolts (H1) into drawer front (P10), using a Phillips head screwdriver as shown.

Step 22


You will need	
	
6 x Small cam nuts (H4)	Flat head screwdriver

Position drawer sides (P11), (P12) and drawer rail (P15) onto drawer front (P10). Insert 6 x small cam nuts (H4) into drawer sides (P11), (P12) and drawer rails (P15). Turn small cam nuts (H4) clockwise to lock using a flat head screwdriver.





Step 23


Slide drawer base (P13) into the grooves of panels of drawer assembly.



Step 24




You will need	
	
#10x38 mm	
6 x Screws (H5)	Phillips head screwdriver



Ensure screw holes in (P11) & (P12) align with pilot holes in (P14) & (P15).



Attach drawer back (P14) to each drawer assembly with 6 x screws (H5), using a Phillips head screwdriver as shown.




Step 25

You will need	
	
2 x Slide runners (H7-2)	#6x12 mm
	6 x Screws (H6)
Phillips head screwdriver	




Attach 1 x slide runners (H7-2) to each drawer side (P12) and (P11) with 3 x screws (H6), using a Phillips head screwdriver as shown.


Step 26



Move inner ball bearing track to front of slide track (H7-1).




Gently insert drawer slide runner into ball bearing Track.



Position drawer so that slide runners (H7-2) align with slide tracks (H7-1) as shown. Gently push drawer into the closed position.

Step 27



Job complete!

In the interest of our environment please dispose
of all packaging thoughtfully.