

150 Litre Garden Dump Cart



EROBOTYKOSZACE.PL

1. GENERAL DESCRIPTION

DO NOT USE THE DEVICE UNLESS YOU HAVE THOROUGHLY READ AND UNDERSTOOD THIS USER MANUAL.

To increase the product life of the device and to ensure a trouble-free operation, use it in accordance with this user manual and regularly perform the maintenance tasks. The technical data and specifications in this user manual are up to date. The manufacturer reserves the right to make changes associated with quality improvement.

ATTENTION! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in serious injury or even death.

Whenever „device“ or „product“ are used in the warnings and instructions, it shall mean Garden Dump Cart.


2. Usage safety

ATTENTION! Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in serious injury or even death.

Whenever „device“ or „product“ are used in the warnings and instructions, it shall mean Garden Dump Cart.

- Do not put more than 350 kg into the load area
- The product is not intended for children, it is not a toy.
- Distribute the load weight evenly over the entire surface.
- Do not store components on plastic edges.
- In case of damage or destruction of any of the components, it is necessary to cease using them.
- Do not use the truck on surfaces / areas that may cause damage of tires.
- The tire inflation pressure must not exceed 30 PSI (2.07 BAR).

3. Device description




1. Load box
2. Blocking assembly
3. Frame
4. Rear axle
5. Front axle
6. Wheels
7. Handle
8. Mounting kit
 - A. Bolt M8x60 (x1)
 - B. Nut M8 (x13)
 - C. Carriage bolt M8x20 (x4)
 - D. Carriage bolt M8x20 (x4)
 - E. Bolt M8x20 (x4)
 - F. Wheel nut (x4)
 - G. Washer M8 (x1)
 - H. Washer M8 (x12)
 - I. Washer M12 (x4)
 - J. Wheel separator
9. Strut
10. Front axle support
11. Plastic coupling
12. Yoke


4. Preparation for work / working with the device

Assembling of the product:


1. Fasten the rear axle (4) to the load box (1) using the mounting kit (C, H, B). Fasten the right and left strut by means of the M8x20 screw (2x C), washers (2x H) and nut (2x B).




2. Screw the locking unit (2) to the load box (1) by means of the M8x20 screw together with the washer and the nut (4x D + H + B).



3. Fasten the front axle (5) to the frame (3) by means of the M8x20 screw, the washer and the nut (E + H + B). Then fasten the support (10) to the frame (3) using the mounting kit (E + H + B).




4. After installing the front axle, the frame (3) must be fastened to the plastic load box (1) using the M8x20 screw, the washer and the nut (D + H + B).



5. In the course of installing the wheels, it is necessary to firstly put the separators (J) on the axle (4/5), then the wheel (6) and then secure with the washer and the nut (I + F).



6. After turning the truck onto the wheels it is necessary to fasten the handle (7) from the side of the plastic coupling (11) to the yoke (12) by means of the screw, washer and nut (A + G + B).



Usage tips:

In order to remove the load, it is necessary to pull the handle of the blocking assembly outwards so as to release the plastic tube from the safety mechanism. Then this handle must be pulled up so that the truck will be tilted to the position of strewing the load.




Cleaning and maintenance

- Use cleaners without corrosive substances to clean each surface.
- Dry all parts well after cleaning before the device is used again.
- Store the unit in a dry, cool place, free from moisture and direct exposure to sunlight.
- Use a soft cloth for cleaning.



ROBOTYKOSZACE.PL

3. Opis urządzenia



1. OGÓLNY OPIS

**PRZED PRZYSTĄPIENIEM DO PRACY NALEŻY
DOKŁADNIE PRZECZYTAĆ I ZROZUMIEĆ
NINIEJSZĄ INSTRUKCJĘ.**

Dla zapewnienia długiej i niezawodnej pracy urządzenia należy dbać o jego prawidłową obsługę oraz konserwację zgodnie ze wskazówkami zawartymi w tej instrukcji. Dane techniczne i specyfikacje zawarte w tej instrukcji obsługi są aktualne. Producent zastrzega sobie prawo dokonywania zmian związanych z podwyższeniem jakości.



UWAGA! Ilustracje w niniejszej instrukcji obsługi mają charakter poglądowy i w niektórych szczegółach mogą różnić się od rzeczywistego wyglądu produktu.

Instrukcją oryginalną jest niemiecka wersja instrukcji. Pozostałe wersje językowe są tłumaczeniami z języka niemieckiego.

2. Bezpieczeństwo użytkowania



UWAGA! Przeczytaj wszystkie ostrzeżenia dotyczące bezpieczeństwa oraz wszystkie instrukcje. Niezastosowanie się do ostrzeżeń i instrukcji może spowodować ciężkie obrażenia ciała lub śmierć.


Termin „urządzenie” lub „produkt” w ostrzeżeniach i w opisie instrukcji odnosi się do wózka ogrodowy transportowy.

- Nie należy wkładać do przestrzeni ładunkowej więcej niż 350kg
- Produkt nie jest przeznaczony dla dzieci, nie jest zabawką.
- Rozkładać ciężar ładunku równomiernie na całej powierzchni.
- Nie składać elementów na plastikowych brzegach.
- W przypadku uszkodzenia lub zniszczenia któregoś z elementów zaprzestać użytkowania.
- Nie używać wózka na powierzchniach/terenach które mogą spowodować uszkodzenia opon.
- Ciśnienie pompowania opony nie może przekroczyć 30 PSI (2,07 BAR).


1. Skrzynia ładunkowa
2. Zespół blokujący
3. Rama
4. Oś tylna
5. Oś przednia
6. Koła
7. Uchwyt
8. Zestaw montażowy
 - A. Śruba M8x60 (x1)
 - B. Nakrętka M8 (x13)
 - C. Śruba zamkowa M8x20 (x4)
 - D. Śruba zamkowa M8x20 (x4)
 - E. Śruba M8x20 (x4)
 - F. Nakrętka do koła (x4)
 - G. Podkładka M8 (x1)
 - H. Podkładka M8 (x12)
 - I. Podkładka M12 (x4)
 - J. Separator kół
9. Rozpórka
10. Wspornik osi przedniej
11. Plastikowe sprężęło
12. Jarzmo

4. Przygotowanie do pracy/ praca z urządzeniem
Składanie produktu:


1. Przymocować oś tylną (4) do skrzyni ładunkowej (1) za pomocą zestawu montażowego (C, H, B). Zamocować prawą i lewą rozpórkę za pomocą śruby M8x20 (2x C), nakrętki (2x H) i podkładki (2x B).




2. Do skrzyni ładunkowej (1) przykręcić zespół blokujący (2) za pomocą śruby M8x20 wraz z podkładką i nakrętką (4x D+H+B).



3. Oś przednią (5) przymocować do ramy (3) za pomocą śruby M8x20, podkładki i nakrętki (E+H+B). Następnie należy przymocować wspornik(10) do ramy (3) za pomocą zestawu montażowego (E+H+B).




4. Po zamontowaniu osi przedniej ramę (3) należy przymocować do plastikowej skrzyni ładunkowej (1) za pomocą śruby M8x20, podkładki i nakrętki (D+H+B).



5. Podczas montażu kół w pierwszej kolejności na oś (4/5) założyć separatory (I) następnie koło (6) po czym zabezpieczyć podkładką i nakrętką (I+F).



6. Po obróceniu wózka na koła przymocuj uchwyt (7) od strony plastikowego sprzęgła(11) do jarzma (12) za pomocą śruby, podkładki i nakrętki (A+G+B)



Wskazówki użytkowania

W celu pozbycia się ładunku należy pociągnąć uchwyt zespołu blokującego do zewnątrz tak aby uwolnić plastikową rurkę z mechanizmu zabezpieczającego. Następnie należy uchwyt ten pociągnąć do góry tak aby wózek przechylił do pozycji wysypującej ładunek.



Czyszczenie i konserwacja

- Do czyszczenia powierzchni należy stosować wyłącznie środki niezawierające substancji żrących.
- Po każdym czyszczeniu wszystkie elementy należy dobrze wysuszyć, zanim urządzenie zostanie ponownie użyte.
- Urządzenie należy przechowywać w suchym i chłodnym miejscu chronionym przed wilgocią i bezpośrednim promieniowaniem słonecznym.
- Do czyszczenia należy używać miękkiej ściereczki.