


(Fig. 7)

#### Lower bracket installation step:

1. Install the threaded nut in the lower rail of the left and right beams and match the dimensions of the roof beams or rails installed on your car. Complete this activity by tightening all screws.

(2) Once adjusted, install the lower bracket using a bolt (M6x10), and tighten the nut with a hex key. (Fig. 7)



(Fig. 8)

#### Roof beam assembly step:

1. Place the assembled rack on the crossbar.

2. Installing the T-clamp: insert the screw (M6x50) into the oval hole of the bottom bracket, insert the plastic knob, secure with the M6 nut, turn the plastic knob and tighten the tube crossbar.

3. Installing the U-shaped clamp: screw the U-shaped screw into the two elliptical holes of the bottom clamp plate, insert the plastic knob, and finally use the M8 nut and turn the plastic knob to clamp the crossbar. (Fig. 8)

#### Lower bracket installation step:

1. Install the threaded nut in the lower rail of the left and right crossbars and match the dimensions of the roof beams or rails installed on your car. Complete this activity by tightening all screws.

(2) Once adjusted, install the lower bracket using a bolt (M6x10), and tighten the nut with a hex key. (Fig. 7)