




ENGLISH



H = Height
D = Diameter
G = Tread
L = Stud Length

Parabolic Rubber Buffers and Suspension Bump Stops

The design of the parabolic buffer is designed to offer the progressive absorption of energy, whilst allowing the mount to deform, dampen the force and reduce the rate of return.

Features:

- Parabolic rubber profile
- Easy to install
- Low cost
- Available in natural rubber as standard, other compounds available on request

Applications:

- Small buffers are used to isolate panel doors on enclosed generators, car bonnets, compressors and pumps
- Large buffers are used for suspension of heavy containers on vehicles

RS Part No	Item Code	Description	D (mm)	H (mm)	G x L (mm)	Max Compression Load (kg)
1623247	DP5050M1025-2	Parabolic Buffer (M) 50x50mm M10x25 60 ShA NR	50	50	M10x25	184