Schneider Electric

APPLICATION GUIDE
Hotel Product

CAT. NO.

|	
E8431D	E8431BPDM
E8432DM	E8431DS
E8431BPM	E8432DMS
E8431BPD	

ZENcelo

Thank you for choosing **Schenider Electric** ZENcelo Hotel Products. To ensure proper application of our product, please read through the following information before installation and use.

**This application guide applies to the following product.**

|	Cat.no.	Description
	E8431D	Illuminated "Do not Disturb" Symbol
	E8432DM	Illuminated "Do Not Disturb" & "Please Clean Up" Symbols
	E8431BPM	1 Gang Full-Flat Bell Switch with Illuminated "Please Clean Up" Symbol

|		
	E8431BPD	1 Gang Full-Flat Bell Switch with Illuminated "Do Not Disturb" Symbol
	E8431BPDM	1 Gang Full-Flat Bell Switch with Illuminated "Do Not Disturb" & "Please Clean Up" Symbols
	E8431DS	1 Gang Full-Flat Switch with Illuminated "Do not Disturb" Symbol
	E8432DMS	2 Gang Full-Flat Switch with Illuminated "Do not Disturb" & "Please Clean Up" Symbols

SPECIFICATIONS

|	
Voltage	: 250V
Load Type & Ratings	: Bell Switch - 10A, Electric bell application; Switch - 16AX (Resistive Load), Fluorescent lamp & Incandescent lamp
Illuminated Symbols Light	: Neon and LED
Illuminated Symbols Color	: Amber - "Do Not Disturb"; Green - "Please Clean Up"
Dimension	: 87mm x 87mm
Mounting Centre	: 60.3mm (wall box with 35mm depth or above)
Compliance	: E8431BPM/E8431BPD/E8431BPDM – GB16915.1, IEC60669-1, BSEN60669-1, MS IEC60669-1; E8431DS/E8432DMS – IEC60669-1, GB16915.1, BSEN60669-1, MS IEC60669-1, SS227-1

E8431D

"DND"control switch

N

"DND"

L

E8432DM

"PCU"

N

1-way switch

2-way switch

"DND"

L

E8431BPM

"DOOR BELL"
"PCU"
"PCU" control switch
L
N

E8431BPD

"DOOR BELL"
"DND"
"DND" control switch
L
N

E8431BPDM

"DOOR BELL"

"DND"

2-way switch

1-way switch

"PCU"

L

N

E8431DS

Connect to Bell Press

N

L

Connect to 'DND' indicator

E8432DMS

Connect to Bell Press

N

L

Connect to 'DND' indicator

Connect to 'PCU' indicator

MOUNTING INSTRUCTION

Please refer to the following diagram for proper installation.

Remarks: For surround mounting, align the clip locks on the faceplate and press firm on the surround. Complete engagement of the clip locks is indicated by a clear "click" sound.