



HPE Aruba Networking CX 6200F Switches and Accessories

Start Here: Installation, Safety, and Regulatory Information



Hewlett Packard
Enterprise

Copyright Information

© Copyright 2025 Hewlett Packard Enterprise Development LP.

Open Source Code

This product includes code licensed under certain open source licenses which require source compliance. The corresponding source for these components is available upon request. This offer is valid to anyone in receipt of this information and shall expire three years following the date of the final distribution of this product version by Hewlett Packard Enterprise Company. To obtain such source code, please check if the code is available in the HPE Software Center at <https://myenterpriselicense.hpe.com/cwp-ui/software> but, if not, send a written request for specific software version and product for which you want the open source code. Along with the request, please send a check or money order in the amount of US \$10.00 to:

Hewlett Packard Enterprise Company
Attn: General Counsel
WW Corporate Headquarters
1701 E Mossy Oaks Rd, Spring, TX 77389
United States of America



Legal Disclaimer

The resource assets in this document may include abbreviated and/or legacy terminology for products. See www.arubanetworks.com for current and complete product lines and names.



All Product Documentation

For the latest release of hardware and software documentation for HPE Aruba Networking switches and accessories, including the *Installation and Getting Started Guide*, which provides detailed installation instructions, visit the Networking Support Portal at the following link: <https://networkingsupport.hpe.com/home>
See the rest of this guide for important pre-setup information.



NOTE:

There are no user-serviceable parts in this product. For switch or accessory service needs, contact an authorized HPE Aruba Networking representative.

Applicable products

Non-TAA	TAA
HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W Switch (R8Q72A)	HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W TAA Switch (R8V13A)
HPE Aruba Networking CX 6200F 24G 4SFP+ Switch (JL724B)	HPE Aruba Networking CX 6200F 24G 4SFP+ TAA-compliant Switch (S0M86A)
HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W Switch (JL725B)	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W TAA-compliant Switch (S0M87A)
HPE Aruba Networking CX 6200F 48G 4SFP+ Switch (JL726B)	HPE Aruba Networking CX 6200F 48G 4SFP+ TAA-compliant Switch (S0M88A)
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W Switch (JL727B)	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W TAA-compliant Switch (S0M89A)
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W Switch (JL728B)	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W TAA-compliant Switch (S0M90A)
Aruba 6200F 24G 4SFP+ Switch (JL724A)	HPE Aruba Networking CX 6200F 24G 4SFP TAA-compliant Switch (S0G13A)
Aruba 6200F 24G Class 4 PoE 4SFP+ 370W Switch (JL725A)	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W TAA-compliant Switch (S0G14A)
Aruba 6200F 48G 4SFP+ Switch (JL726A)	HPE Aruba Networking CX 6200F 48G 4SFP TAA-compliant Switch (S0G15A)
Aruba 6200F 48G Class 4 PoE 4SFP+ 370W Switch (JL727A)	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W TAA-compliant Switch (S0G16A)
Aruba 6200F 48G Class 4 PoE 4SFP+ 740W Switch (JL728A)	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W TAA-compliant Switch (S0G17A)

Non-TAA	TAA
HPE Aruba Networking CX 6200F 24G 4SFP Switch (S0M81A)	
HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W Switch (S0M82A)	
HPE Aruba Networking CX 6200F 48G 4SFP Switch (S0M83A)	
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W Switch (S0M84A)	
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W Switch (S0M85A)	

Overview

The HPE Aruba Networking CX 6200F Switch Series is a family of edge networking stackable switches, ideal for enterprise network access. They provide the foundation for high-performance networks supporting IoT, mobile, and cloud applications.

These switches are intended for indoor use only. They are for use in commercial applications. A typical installation is in an environmentally controlled location. The end use environment may or may not be a restricted access location.

A tool is required to remove the top cover; however, the product is not considered serviceable by an operator.

Installation precautions and guidelines

To help avoid personal injury or product damage when installing your switch, read the following installation precautions and guidelines.

WARNING:



- With the exception of HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W Switch (R8Q72A) and HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W TAA Switch (R8V13A), do not mount the switch on a wall, under a table, or under any other horizontal surface.
- Mount devices installed in a rack or cabinet as low as possible. Put the heaviest devices at the bottom and progressively lighter devices positioned higher.
- To prevent the rack or cabinet from becoming unstable and/or falling over, ensure that it is adequately secured.

This section provides precautions and guidelines to observe when installing your switch. For full installation instructions, see the *Installation and Getting Started Guide*.

CAUTION:

- Do not ship any switch in a rack without checking for restrictions in the latest *Installation and Getting Started Guide*. Otherwise, you may void the switch warranty.
- Ensure the power source circuits are properly grounded. Then connect the switch to the power source by using the power cord supplied with the switch. For more information on power cords, see the [Power cords](#) section.
- When installing the switch, the AC outlet should be near the switch and be easily accessible in case the switch must be powered off.
- Ensure that the power cord and network cables at the switch mounting location do not create a tripping hazard.
- Do not install the switch in an environment where the operating ambient temperature exceeds its specification. See the environmental operating temperature information in the latest *Installation and Getting Started Guide*.
- Ensure that the switch does not overload the power circuits, wiring, and over-current protection. To determine the possibility of overloading the supply circuits, add the ampere ratings of all devices installed on the same circuit as the switch. Then compare the total with the rating limit for the circuit. The maximum ampere ratings for a device are usually printed near the device AC power connectors.
- Do not block any ventilation openings on the front or rear of the switch. Ensure that the air flow around the switch is not restricted.
 - **For all other 24- and 48-port 6200F models:** In the front or the rear of the switch, leave at least 7.6 cm (3 inches) of space for the twisted-pair and fiber-optic cabling. For the air flow direction, see the latest *Installation and Getting Started Guide*.
 - **For HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W Switch (R8Q72A) and HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W TAA Switch (R8V13A) models:** In the front or the rear of the switch, leave at least 15.24 cm (6 inches) of space for the twisted-pair and fiber-optic cabling.
- Marking label (includes power rating) is at the bottom of the switch.
- The switch equipment is not suitable for use in locations where children are likely to be present.

NOTE:

- Use only supported HPE Aruba Networking transceivers and DAC cables.
- The HPE Aruba Networking CX 6200F switch port side transceiver slots support SFP and SFP+ transceivers.
- For more information, see the latest version of the following two guides:
 - *Installation and Getting Started Guide*
 - *Transceiver Guide*

Power cords

HPE Aruba Networking includes the power cord intended for use with your HPE Aruba Networking switch. Different countries/regions may require different power cords. For a list of the power cords that apply to your switch, see the section that lists power cords in the latest edition of the *Installation and Getting Started Guide* for your switch.

CAUTION:

Only HPE Aruba Networking-approved power cords may be used with HPE Aruba Networking devices. To access power cord information for your switch, see the latest edition of the HPE Aruba Networking 6200 *Installation and Getting Started Guide*. Lost or damaged power cords must be replaced only with HPE Aruba Networking-approved power cords. If your installation requires a different power cord than the one supplied with the switch, be sure that the cord is adequately sized for the current requirements of the switch. In addition, be sure to use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country/region. The mark is your assurance that the power cord can be used safely with the switch.

CAUTION:

Do not use a damaged or non-recommended power cord with your switch. Using such power cords voids the switch warranty. It can also cause serious electrical problems, including injury or death to personnel, and damage to the switch and other property. If you cannot verify that you have a power cord approved for use with your switch model, contact your authorized HPE Aruba Networking dealer or sales representative for assistance.

WARNING:

Remove the power cord from the switch before mounting or dismounting the switch.

Japan power cord warning

製品には、同梱された電源コードをお使い下さい。
同梱された電源コードは、他の製品では使用出来ません。

CAUTION:

FOR INDOOR USE ONLY. The switch, power cords, and all connected cables are not designed for outdoor use.

Brazil Statement

Este equipamento deve ser conectado obrigatoriamente em tomada de rede de energia elétrica que possua aterramento (três pinos), conforme a Norma NBR ABNT 5410, visando a segurança dos usuários contra choques elétricos.)



CAUTION: Shock hazard. To completely remove power from the switch, disconnect all power cords.

Environmental specifications

Table 1: Environmental Specifications for all HPE Aruba Networking CX 6200F switch models

HPE Aruba Networking CX 6200F Switches	
Operating temperature	32°F to 113°F (0°C to 45°C) up to 5,000 ft; Derate 1°C for every 1,000 ft from 5,000 ft to 10,000 ft
Operating relative humidity	5% to 95% @ 104°F (40°C) non-condensing
Non-operating temperature	-40°F to 158°F (-40°C to 70°C) up to 15,000 ft
Non-operating storage relative humidity	5% to 95% @ 149°F (65°C) non-condensing
Max operating altitude	10,000 ft (3.048 km) Max
Max non-operating altitude	15,000 ft (4.6 km) Max

Table 2: Dimensions and weights for HPE Aruba Networking CX 6200F switch models

Switch	Weight	Dimensions (W x D x H)
HPE Aruba Networking CX 6200F 24G 4SFP+ Switch (JL724B)	3.77 kg (8.32 lbs)	44.25 cm x 28.45 cm x 4.37 cm (17.42 in x 11.2 in x 1.72 in)
HPE Aruba Networking CX 6200F 24G 4SFP Switch (S0M81A)		
HPE Aruba Networking CX 6200F 24G 4SFP+ TAA-compliant Switch (S0M86A)		
HPE Aruba Networking CX 6200F 24G 4SFP TAA-compliant Switch (S0G13A)		
HPE Aruba Networking CX 6200F 48G 4SFP+ Switch (JL726B)	3.90 kg (8.59 lbs)	
HPE Aruba Networking CX 6200F 48G 4SFP Switch (S0M83A)		
HPE Aruba Networking CX 6200F 48G 4SFP+ TAA-compliant Switch (S0M88A)		
HPE Aruba Networking CX 6200F 48G 4SFP TAA-compliant Switch (S0G15A)		

Switch	Weight	Dimensions (W x D x H)
HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W Switch (JL725B)	4.39 kg (9.68 lbs)	44.25 cm x 30.43 cm x 4.37 cm (17.42 in x 11.98 in x 1.72 in)
HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W Switch (S0M82A)		
HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W TAA-compliant Switch (S0M87A)		
HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W TAA-compliant Switch (S0G14A)		
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W Switch (JL727B)	4.87 kg (10.74 lbs)	
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W Switch (S0M84A)		
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W TAA-compliant Switch (S0M89A)		
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W TAA-compliant Switch (S0G16A)		
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W Switch (JL728B)	5.13 kg (11.32 lbs)	44.25 cm x 32.66 cm x 4.37 cm (17.42 in x 12.86 in x 1.72 in)
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W Switch (S0M85A)		
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W TAA-compliant Switch (S0M90A)		
HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W TAA-compliant Switch (S0G17A)		
HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W Switch (R8Q72A)	3.24 kg (7.14 lbs)	25.4 cm x 30.5 cm x 4.39 cm (10.0 in x 12.0 in x 1.73 in)
HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W TAA Switch (R8V13A)		

Switch	Weight	Dimensions (W x D x H)
Aruba 6200F 24G 4SFP+ Switch (JL724A)	4.36 kg (9.61 lbs)	44.25 cm x 32.7 cm x 4.37 cm (17.42 in x 12.9 in x 1.72 in)
Aruba 6200F 24G Class4 PoE 4SFP+ 370W Switch (JL725A)	4.9 kg (10.8 lbs)	
Aruba 6200F 48G 4SFP+ Switch (JL726A)	4.45 kg (9.81 lbs)	
Aruba 6200F 48G Class4 PoE 4SFP+ 370W Switch (JL727A)	5.05 kg (11.13 lbs)	
Aruba 6200F 48G Class4 PoE 4SFP+ 740W Switch (JL728A)	5.10 kg (11.24 lbs)	

Safety and regulatory information



NOTE:

For important safety, environmental, and regulatory information, see *Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products*, available at <http://www.hpe.com/support/Safety-Compliance-EnterpriseProducts>.

Table 3: Safety and Regulatory information for HPE Aruba Networking CX 6200F switches

	JL724A, JL725A, JL726A, JL727A, JL728A	R8Q72A, R8V13A	JL724B, JL725B, JL726B, JL727B, JL728B, S0M81A, S0M82A, S0M83A, S0M84A, S0M85A, S0M86A, S0M87A, S0M88A, S0M89A, S0M90A, S0G13A, S0G14A, S0G15A, S0G16A, S0G17A
Safety-EU	EN 62368-1:2014 +A11:2017 2nd Ed. EN 62368-1:2020 +A11:2020 3rd Ed.		
Safety-Worldwide	IEC 60950-1:2005 + A1:2009 + A2:2013 with all known National Deviations IEC 62368-1:2014 2nd Ed. with all known National Deviations IEC 62368-1:2018 3rd Ed. with all known National Deviations		IEC 62368-1:2014 2nd Ed. with all known National Deviations IEC 62368-1:2018 3rd Ed. with all known National Deviations
Safety-North America	US:UL 60950 2nd Ed. CAN:CSA-C22.2 No. 60950-1-07	US:UL 62368-1 3rd Ed. CAN:CSA-C22.2 No. 62368-1:19 3rd Ed.	
EMC	BS/EN 55032:2015 +A11:2020/CISPR 32, Class A BS/EN 55035:2017 +A11:2020/CISPR 35		
	FCC 47 CFR part 15B: 2020, Class A		

	JL724A, JL725A, JL726A, JL727A, JL728A	R8Q72A, R8V13A	JL724B, JL725B, JL726B, JL727B, JL728B, S0M81A, S0M82A, S0M83A, S0M84A, S0M85A, S0M86A, S0M87A, S0M88A, S0M89A, S0M90A, S0G13A, S0G14A, S0G15A, S0G16A, S0G17A
	ICES-003 Issue 7: 2020, Class A AS/NZS CISPR 32: 2015, Class A VCCI-CISPR 32, Class A CNS 15936: 2020 KS C 9832:2019 KS C 9835:2019		
	BS/EN 61000-3-2:2014 BS/EN 61000-3-3:2013	BS/EN 61000-3-2:2019 BS/EN 61000-3-3:2013/A1:2019	
RoHS	EN IEC 63000:2018		

Table 4: Regulatory Model Numbers for HPE Aruba Networking CX 6200F switches

Regulatory Model Number	Model Number	Descriptions
RSVLC-1910	JL728A	Aruba 6200F 48G Class4 PoE 4SFP+ 740W Switch
RSVLC-1911	JL727A	Aruba 6200F 48G Class4 PoE 4SFP+ 370W Switch
	JL725A	Aruba 6200F 24G Class4 PoE 4SFP+ 370W Switch
RSVLC-1912	JL726A	Aruba 6200F 48G 4SFP+ Switch
	JL724A	Aruba 6200F 24G 4SFP+ Switch
RSVLC-2108	R8Q72A	HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W Switch
	R8V13A	HPE Aruba Networking CX 6200F 12G Class4 PoE 2G/2SFP+ 139W TAA Switch
RSVLC-2205	JL726B	HPE Aruba Networking CX 6200F 48G 4SFP+ Switch

Regulatory Model Number	Model Number	Descriptions
	JL724B	HPE Aruba Networking CX 6200F 24G 4SFP+ Switch
	S0M83A	HPE Aruba Networking CX 6200F 48G 4SFP Switch
	S0M81A	HPE Aruba Networking CX 6200F 24G 4SFP Switch
	S0M88A	HPE Aruba Networking CX 6200F 48G 4SFP+ TAA-compliant Switch
	S0M86A	HPE Aruba Networking CX 6200F 24G 4SFP+ TAA-compliant Switch
	S0G13A	HPE Aruba Networking CX 6200F 24G 4SFP TAA-compliant Switch
	S0G15A	HPE Aruba Networking CX 6200F 48G 4SFP TAA-compliant Switch
RSVLC-2206	JL727B	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W Switch
	JL725B	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W Switch
	S0G14A	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W TAA-compliant Switch
	S0G16A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W TAA-compliant Switch
	S0M84A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W Switch
	S0M82A	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W Switch
	S0M89A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W TAA-compliant Switch
	S0M87A	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W TAA-compliant Switch
RSVLC-2207	S0M85A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W Switch
	S0G17A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W TAA-compliant Switch
	JL728B	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+

Regulatory Model Number	Model Number	Descriptions
		740W Switch
	S0M90A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W TAA-compliant Switch



NOTE:

Environmental and other switch specifications, such as acoustics data, are included in the latest version of the *Installation and Getting Started Guide* or the HPE Aruba Networking CX 6200 Datasheet.



IMPORTANT:

IMPORTANT: Use only supported HPE Aruba Networking transceivers with your switch. For more on transceivers, see the latest edition of the HPE Aruba Networking Switch Operating System (AOS-S) and HPE Aruba Networking CX Switch Operating System (AOS-CX) Transceiver Guide. When selecting a fiber SFP and/or SFP+ device, make sure it can function at a temperature that is not less than the recommended maximum operational temperature of the product. Use only an approved Laser Class 1 SFP and/or SFP+ transceivers.

Electrical

Model	Description	AC voltage	Maximum current	Frequency range	Maximum power
JL724B	HPE Aruba Networking CX 6200F 24G 4SFP+ Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
JL725B	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
JL726B	HPE Aruba Networking CX 6200F 48G 4SFP+ Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
JL727B	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
JL728B	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W Switch	100-120V	10.3A	50/60 Hz	950W
		200-240V	5.0A		
S0M81A	HPE Aruba Networking CX 6200F 24G 4SFP Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		

Model	Description	AC voltage	Maximum current	Frequency range	Maximum power
S0M82A	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
S0M83A	HPE Aruba Networking CX 6200F 48G 4SFP Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
S0M84A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
S0M85A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W Switch	100-120V	10.3A	50/60 Hz	950W
		200-240V	5.0A		
S0M86A	HPE Aruba Networking CX 6200F 24G 4SFP+ TAA-compliant Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
S0M87A	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP+ 370W TAA-compliant Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
S0M88A	HPE Aruba Networking CX 6200F 48G 4SFP+ TAA-compliant Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
S0M89A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 370W TAA-compliant Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
S0M90A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP+ 740W TAA-compliant Switch	100-120V	10.3A	50/60 Hz	950W
		200-240V	5.0A		
S0G13A	HPE Aruba Networking CX 6200F 24G 4SFP TAA-compliant Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
S0G14A	HPE Aruba Networking CX 6200F 24G Class 4 PoE 4SFP 370W TAA-compliant Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		
S0G15A	HPE Aruba Networking CX 6200F 48G 4SFP TAA-compliant Switch	100-120V	0.9A	50/60 Hz	120W
		200-240V	0.6A		
S0G16A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 370W TAA-compliant Switch	100-120V	5.2A	50/60 Hz	500W
		200-240V	2.6A		

Model	Description	AC voltage	Maximum current	Frequency range	Maximum power
S0G17A	HPE Aruba Networking CX 6200F 48G Class 4 PoE 4SFP 740W TAA-compliant Switch	100-120V	10.3A	50/60 Hz	950W
		200-240V	5.0A		
R8Q72A	HPE Aruba Networking 6200F 12G Class4 PoE 2G/2SFP+ 139W Switch	100-127V	2.6A	50/60 Hz	180W
		200-240V	1.3A		
R8V13A	HPE Aruba Networking 6200F 12G Class4 PoE 2G/2SFP+ 139W TAA Switch	100-127V	2.6A	50/60 Hz	180W
		200-240V	1.3A		
JL724A	Aruba 6200F 24G 4SFP+ Switch	100-120V	2.5A	50/60 Hz	200W
		200-240V	1.4A		
JL725A	Aruba 6200F 24G Class4 PoE 4SFP+ 370W Switch	100-127V	7.5A	50/60 Hz	500W
		200-240V	3.5A		
JL726A	Aruba 6200F 48G 4SFP+ Switch	100-120V	2.5A	50/60 Hz	200W
		200-240V	1.4A		
JL727A	Aruba 6200F 48G Class4 PoE 4SFP+ 370W Switch	100-127V	7.5A	50/60 Hz	500W
		200-240V	3.5A		
JL728A	Aruba 6200F 48G Class4 PoE 4SFP+ 740W Switch	100-120V	11A	50/60 Hz	950W
		200-240V	6A		

Battery Statements

NOTE:



- Where a battery incorporated by Hewlett Packard Enterprise is too small to bear the CE marking, it conforms with applicable requirements.
- These switches use a lithium battery. Do not attempt to replace the battery. Return the switch to Hewlett Packard Enterprise for battery replacement.
- The only indicator of battery failure is the failure of the switch internal clock to keep the correct time across a reboot or power cycle. If a battery failure occurs, contact your authorized Hewlett Packard Enterprise representative for assistance. Batteries are not customer-serviceable and battery failures should be referred only to service personnel authorized by Hewlett Packard Enterprise.
- For important safety, environmental, and regulatory information, see *Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products*, available at <http://www.hpe.com/support/SafetyCompliance-EnterpriseProducts>.

ATTENTION

Il y a danger d'explosion s'il y a remplacement incorrect de la batterie.
Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

ATTENTION

The battery supplied with this product may contain perchlorate material. Special handling may apply in California and certain other states. See <http://www.dtsc.ca.gov/hazardouswaste/perchlorate> Web site for more information.



WARNING: A risk of explosion exists if a battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

China altitude warning

安全说明和标记

仅适用于海拔 2000m 以下地区安全使用。

Taiwan EMC Class A Statement

警告：為避免電磁干擾，本產品不應安裝或使用於住宅環境。

Japan VCCI Class A statement

この装置は、クラスA機器です。この装置を住宅環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI - A

Korea EMC Class A statement

사용자 안내문

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.

United Kingdom Marking



EU & UK Regulatory Contact:
HPE, Postfach 0001, 1122 Wien, Austria

European Community

The product herewith complies with the requirements of Directive 2014/35/EU relating to electrical equipment designed for use within certain voltage limits, Directive 2014/30/EU relating to electromagnetic compatibility, Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment, and carries the CE marking accordingly.

FCC Class A Statement

This equipment has been tested and found to comply with the limits of a Class A Digital device, pursuant to part 15 of the FCC rules.

Kazakhstan marking



For manufacturer and local representative information, see *Safety and Compliance Information for Server, Storage, Power, Networking, and Rack Products* at <http://www.hpe.com/support/Safety-Compliance-EnterpriseProducts>.

India

This product conforms to the relevant Essential Requirements of TEC, Department of Telecommunications, Ministry of Communications, Govt of India, New Delhi-110001.

China

The NAL Label can be found near product packaging regulatory label.

Preview of installing a HPE Aruba Networking CX 6200F Switch



NOTE:

This section previews the steps for installing the HPE Aruba Networking CX 6200F Switch. To find detailed switch installation steps, information on configuration tools, and other instructions and information, see the latest *Installation and Getting Started Guide* for your switch.

1. Prepare the installation site. (See the latest *Installation and Getting Started Guide* for more information.)
2. Unpack the switch and verify that you have received the correct parts.
3. Connect power to the switch and observe the switch self-test, then remove power from the switch.
4. Mount the switch. Note that weight and mounting restrictions apply. See the "Warning" information in the [Installation precautions and guidelines](#) section.
5. Connect the switch to a power source.
6. (Optional) Install transceivers.
7. Connect the network cables.
8. Configure the switch for network operation.

Documentation feedback

Send any errors, suggestions, or comments to Documentation Feedback (hpe-aruba-techpub@hpe.com).

