


Tools Needed:
4mm Hex Key




kuat[®]


- ① Using the 4mm Hex Key, remove the two M6 countersunk screws from the Crossbar. Remove the old Crossbar.



- ② Slide the old T-Nuts to the access cutouts in the side extrusion to remove. **Note the removal of multiple Crossbars may be required,**



- ③ Slide the new T-Nuts into position and install the aluminum spacers into the ends of the new Crossbar.



- ④ Install the new Crossbar and torque the M6 countersunk screws to 12 Nm. Reinstall any other Crossbars as needed by following the same instructions.