



Part No. 2321-0170

MEK1940

REVISION 0

Kawasaki 1600 Vulcan Classic / Vulcan Nomad Batwing Fairing, Metric Mounting kit.

Detachable system allows easy removal. Stylish and Functional

Before assembly, read Warnings inside



WARNING


1. During installation, make sure that the fairing and hardware do not interfere with any cables or wiring when the forks are turned all the way in either direction. Also make sure , through the full range of adjustment, that the fairing and hardware do not hit the gas tank.
2. This is a detachable fairing, ALWAYS make sure the locking mechanism is fully engaged after installing the fairing.
3. The improper installation of this kit and related components could result in serious injury or death.



CAUTION

1. Memphis Shades fairings are made from Lucite® acrylic, and will last for years with proper care. Clean your fairing with plenty of soapy water (mild dishwashing liquid is best) and a soft cotton cloth. Use your bare hands to feel and dislodge bugs, or cover with a wet, soapy towel and let it soak. Don't use paper towels and scrape with anything. Small scratches can be removed with NOVUS #2.
2. Never use any glass cleaning products, petroleum based chemicals, or cleaning agents with ammonia, bleach or any other harsh chemicals. This includes (but not limited to) RainX, brake fluid, acetone, paint thinner, benzene and gasoline. "If it hurts your nose, it will hurt the plastic."
3. Glass cleansing agents will cause severe damage to your fairing, and will void your warranty.
4. At certain times of the day the Sunlight can reflect off the curvature of a fairing and cause extreme heat build-up on motorcycle instruments and instrument panel. Take care when parking. Park facing the sun, place an opaque object over the instruments or adjust the fairing to avoid reflections.

1. Kit Contents



Ref	Code	Description	Qty
①	I1940	Mounting Instructions	1
②	M1444	Clutch side plate assembly	1
③	M1445	Throttle side plate assembly	1
④	K49	Upper bushing assembly	2
⑤	K50	Lower bushing assembly	2
⑥	M310	3/16 Short arm allen wrench	1
⑦	M311	6mm Short arm allen wrench	1
⑧			
⑨			
⑩			

2. Mounting Instructions

Additional tools required, that are not included in this kit. 7/16" or 11mm wrench.

1. Cover gas tank and front fender with towels to avoid damage during installation.
2. Locate the upper and lower mounting bolts located on the sides of the front fork covers and remove them. Nomad: Remove OEM windshield and hardware.
3. Using the new bolts and spacers included, install the new Upper bushing assemblies ④ (with spacer) and Lower bushing assemblies ⑤ (with washer). (Fig 1)
4. Attach the Mounting plates ② & ③ to the Fairing using the acorn nuts and washers supplied with the Fairing. The Mounting tabs should be pointing in towards the headlight when installed correctly. (Fig 2)

Continued overleaf.....

Memphis Shades warrants all product components, metal and plastic, against defects in materials and workmanship for 24 months.

For Parts and Warranty Help, Contact:

Memphis Shades, Inc.

P.O. Box 429

Rossville, TN 38066

(901) 853 0293

Visit us on the web at www.memphisshades.com or you can also reach us by email:

customerservice@memphisshades.com

**Kawasaki 1600 Vulcan Classic / Vulcan Nomad
Batwing Fairing, Metric
Mounting kit.**

2. Mounting Instructions, continued

5. Install the fairing by placing the lower slots of the mounting plates **2** **3** into the lower mounting bushings. Slip the upper slots into the upper mounting bushings and gently but firmly seat the slots into place. (Fig 3). Lock the locking mechanism into place.

6. Adjust the height, angle and alignment of the fairing and tighten ALL bolts.

Note: This is a detachable fairing, ALWAYS make sure the Locking Mechanism is Fully Engaged after installing the fairing

Fig. 1




Fig. 2





Fig. 3



1. Place lower slot into lower bushing.
2. Rotate top slot into place.
3. Secure locking Mechanism.
4. Loosen Allen Bolt to adjust angle, then re-tighten Allen Bolt.

